
Z80185/195 DEVELOPMENT KIT

USER'S MANUAL

TABLE OF CONTENTS

TITLE	PAGE
CHAPTER 1: INTRODUCTION	
OVERVIEW	1-1
KEY FEATURES OF THE Z80185/195 DEVELOPMENT KIT	1-1
SUPPORTED ZILOG DEVICES	1-1
HARDWARE SPECIFICATIONS	1-2
Z80185/195 DEVELOPMENT KIT FUNCTIONAL BLOCK DIAGRAM	1-2
SUPPORT PRODUCTS PACKAGE CONTENTS	1-3
REQUIREMENTS AND RESTRICTIONS	1-4
CHAPTER 2: SETUP AND INSTALLATION	
INTRODUCTION	2-1
INSTALLING THE SOFTWARE	2-1
CREATING TZ PROGRAM ICON (WINDOWS)	2-2
ZASM-CROSS ASSEMBLER/MOBJ-OBJECT UTILITY INSTALLATION (OPTIONAL)	2-2
SETTING UP THE HARDWARE	2-3
SETTING UP THE SERIAL CHANNELS	2-3
SETTING UP THE PARALLEL CHANNEL (OPTIONAL)	2-8
OTHER JUMPER OPTIONS	2-8
CONNECTING TO A POWER SUPPLY	2-10
Z80185/195 DEVELOPMENT BOARD-TO-PC HOOKUP DIAGRAM	2-10
INITIAL CHECKOUT/SAMPLE SESSION	2-11
CHAPTER 3: USING THE MONITOR PROGRAM	
INTRODUCTION	3-1
GETTING STARTED	3-2
STARTING UP THE TZ PROGRAM	3-2
EXITING THE TZ PROGRAM	3-2
TZ PROGRAM RESTRICTIONS	3-3
PC MODELS/SERIAL BAUD RATES	3-3
PROGRAM COMMANDS	3-4
OTHER FEATURES	3-15
NMI	3-15
TRAP	3-15
RST 20H SERVICES	3-16
CHAPTER 4: REFERENCE	
MEMORY CONFIGURATIONS AND JUMPER SETTINGS	4-1
DEBUG MONITOR MEMORY MAP	4-6
Z80185/195 DEVELOPMENT BOARD SCHEMATIC	4-7

TABLE OF CONTENTS

(Continued)

TITLE	PAGE
APPENDIX A: DEVICE DRIVERS OVERVIEW	A-1
APPENDIX B: HOW TO ACCESS THE ZBBS.....	B-1
APPENDIX C: PROBLEM / SUGGESTION REPORT FORM	C-1