
PJL Technical Reference Manual



Edition 4
E0594

5961-0636
Printed in U.S.A. 5/94

Notice

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated without the prior written consent of Hewlett-Packard Company.

Copyright © 1994 by HEWLETT-PACKARD CO.

Adobe, PostScript, and the PostScript logo are trademarks of Adobe Systems Incorporated which may be registered in certain jurisdictions. AppleTalk is a registered trademark of Apple Computer, Inc. Centronics is a U.S. registered trademark of Centronics Data Computer Corporation. Bi-Tronics and HP Explorer Software are trademarks and PCL and Resolution Enhancement are registered trademarks of Hewlett-Packard Company. Epson is a registered trademark of Epson America, Inc. Harvard Graphics is a registered trademark of Software Publishing Corporation. IBM is a registered trademark and ProPrinter is a trademark of International Business Machines Corporation. Lotus and 1-2-3 are registered trademarks of Lotus Development Corporation. Microsoft is a registered trademark and Word, Windows, MS-Mincho, and MS-Gothic are trademarks of Microsoft Corporation. ESC/ P is a trademark of Seiko-Epson Corporation. WordPerfect is a registered trademark of WordPerfect Corporation.

First Edition — September 1992 (P/N 5961-0512)

Second Edition — May 1993 (P/N 5961-0998)

Third Edition — July 1993 (P/N 5961-0603)

Fourth Edition — May 1994 (P/N 5961-0636)

Inside This Manual

What You Can Learn From This Manual

Printer Job Language (PJL) was developed by Hewlett-Packard to provide a method for switching printer languages at the job level, and for status readback between the printer and the host computer. PJL offers application programs an efficient way to remotely control LaserJet printers. Using PJL, developers can provide applications with the ability to programmatically switch printer languages, monitor printer status, request the printer model and configuration, change control panel default settings, modify control panel messages, and more.

This manual is written for experienced users such as application developers and technical support personnel. Before using PJL commands, programmers should be familiar with the introductory information in Chapters 1, 2, and 3, and with the programming tips in Chapter 9. In addition, users of this manual should be acquainted with the HP LaserJet printer language (PCL) and with LaserJet printer features.

Application Developers

This PJL Technical Reference Manual provides developers with all the information necessary to add PJL to their applications. Examples are used throughout the manual to help developers write efficient and well-behaved code.

Technical Support Personnel

This manual provides reference information for network administrators and other technical support personnel who manage multi-user systems. PJL provides the potential for significantly enhancing network printer operation.

Non-Technical Users

Non-technical users can use the features of PJL by using HP Explorer Software, or by using software that supports PJL. Since improperly used PJL commands can cause problems in a network situation, inexperienced users are advised against using PJL commands on any system other than a dedicated workstation.

Manual Organization

This manual is comprised of nine chapters and four appendices. The first three chapters introduce you to the range of PJL features, PJL syntax and format, some rules about using PJL, and a brief description of each command. Chapter 4 explores the essential “kernel” commands—those commands that are part of almost every PJL job. Chapters 5 through 8 each describe a separate group of related commands. The remaining chapters cover programming tips and related PJL information. A brief description of each chapter is provided below.

Chapter 1. Introduction to PJL

This chapter explains what PJL is, who should use PJL, and the benefits of using PJL in application programs. It also covers compatibility with non-PJL HP LaserJet printers.

Chapter 2. PJL Command Syntax and Format

Chapter 2 explains the conventions used to describe PJL command syntax. The chapter also explains the formats that PJL commands follow and describes what happens when the printer receives an illegal command.

Chapter 3. Using PJL

This chapter explains how PJL commands are used, including the requirements of a PJL job and examples showing basic PJL command structure. In addition, the chapter categorizes the PJL commands in this manual by their functionality, along with a brief command summary.

Chapter 4. Kernel Commands

This chapter explains the three core commands used in most PJL jobs: the Universal Exit Language (UEL) command, the COMMENT command, and the ENTER command. The chapter also describes the related topics of implicit and explicit printer language switching.

Chapter 5. Job Separation Commands

Chapter 5 describes the JOB and EOJ commands, which are used in combination to define job boundaries and provide job-related feedback, such as job completion.

Chapter 6. Environment Commands

This chapter explains setting the printer to a known state. The DEFAULT, INITIALIZE, RESET, and SET commands are explained here.

Chapter 7. Status Readback Commands

Chapter 7 describes status readback, the format of status readback responses, using software tools to interpret status readback, and the commands associated with status readback (INQUIRE, DINQUIRE, ECHO, INFO, USTATUS, and USTATUSOFF). This chapter also covers the processes involved in job recovery and monitoring the printer control panel.

Chapter 8. Device Attendance Commands

Chapter 8 describes the commands used to display messages on the printer control panel: the RDYMSG, OPMSG, and STMSG commands.

Chapter 9. Programming Tips

This chapter demonstrates how to create well-formed jobs and discusses common problems and things to watch for when using PJI commands. Samples are included to demonstrate different types of applications.

Appendix A. Product-Specific Feature Support

This chapter lists all of the PJI commands and shows which commands are supported by the different PJI printers. It also shows which environment variables are supported, and includes printer-specific information about several PJI printers.

Appendix B. PJJ Command Summary

This appendix lists all of the PJJ commands in alphabetical order, and shows the format of each command.

Appendix C. Programming Examples

Appendix C shows an example of a PJJ job in both the generic format used in the rest of this manual, and in the C programming language. The appendix also includes a batch file that modifies the control panel display message during job processing.

Appendix D. Status Codes

This appendix describes the status code information available when using status readback.

Index

This manual includes an index for easy access to PJJ information.

Quick Index

The inside back cover includes an alphabetical listing of each PJJ command, with accompanying page numbers for accessing information about specific commands.

Related Documents

The following documents provide related information about Hewlett-Packard PCL 5 printers.

PCL 5 Printer Language Technical Reference Manual

The PCL 5 Printer Language Technical Reference Manual provides a description of the printer command language that controls PCL 5 printers. The manual provides explanations of each PCL command, and examples demonstrating how the commands are used to manipulate the printer. A large portion of the manual is devoted to HP-GL/2, the vector-based graphics language that is part of all PCL 5 printers.

PCL 5 Comparison Guide

This document provides printer-specific information on paper handling, internal fonts, PCL command support, and control panel information. It identifies feature differences between the PCL 5 printers, and how the printers implement the commands described in the PCL 5 Printer Language Technical Reference Manual.

PCL/PJL Technical Quick Reference Guide

This booklet is designed to provide quick access to the syntax of each PCL and PJL command. The commands are grouped by their function so that those familiar with PCL and/or PJL can find the syntax of a specific command without opening the manual.

Contents

1. Introduction to PJJ	
The Benefits of PJJ	1-2
Who Should Use PJJ?	1-3
Compatibility With Non-PJJ LaserJet Printers	1-3
PCL Jobs.	1-4
PostScript Jobs.	1-4
Other Printer Languages	1-4
2. PJJ Command Syntax and Format	
Document Conventions	2-1
Format of PJJ Commands.	2-3
PJJ Syntax Rules.	2-4
Types of Variables	2-6
Processing Invalid Commands	2-8
3. Using PJJ	
Overview of How Commands are Used	3-1
PJJ Job Requirements	3-2
Some Sample PJJ Jobs	3-3
What's Next?	3-4
Command Groupings by Functionality	3-5
4. Kernel Commands	
Universal Exit Language (UEL) Command.	4-2
ENTER Command.	4-4
COMMENT Command	4-6
Methods of Printer Language Switching	4-8

5. Job Separation Commands	
JOB Command	5-2
EOJ Command	5-7
PJL Job Security	5-9
6. Environment Commands	
Print Environments	6-2
Changing Environment Settings	6-5
Environment Summary	6-6
PJL Reset Conditions	6-8
Key Points to Remember About Environments	6-9
PJL Environment Variables	6-10
General PJL Environment Variables	6-11
Port-Specific Variables	6-18
PCL-Specific Variables	6-19
PostScript-Specific Variables	6-22
ESC/P-Specific Variables	6-23
Setting the Printer to a Desired State	6-24
DEFAULT Command	6-26
INITIALIZE Command	6-30
RESET Command	6-33
SET Command	6-36
7. Status Readback Commands	
Printer Status Requirements	7-2
Synchronizing Status Readback Responses	7-2
Format of Status Readback Responses	7-3
INQUIRE Command	7-4
DINQUIRE Command	7-9
ECHO Command	7-14
INFO Command	7-16
ID Category	7-17

CONFIG Category	7-18
MEMORY Category	7-21
PAGECOUNT Category	7-22
STATUS Category	7-23
VARIABLES Category	7-24
USTATUS Category	7-28
USTATUS Command	7-29
DEVICE Variable	7-31
JOB Variable	7-33
PAGE Variable	7-36
TIMED Variable	7-37
USTATUSOFF Command	7-39
Job Recovery	7-40

8. Device Attendance Commands

RDYMSG Command	8-2
OPMSG Command	8-4
STMSG Command	8-6

9. Programming Tips for Using PJJ

PJJ Services	9-2
Print Data Generators	9-3
Print Data Generator Examples	9-4
Printer Utilities	9-5
Printer Utility Examples	9-7
Spoolers	9-10
Spooler Examples	9-12
Requesting Printer Status	9-17
Using Status Readback in a Multi-User System	9-17
Example Printing System	9-18
Printer Status Readback and Printer Sharing	9-18
Printer Status Readback Usage	9-21

Determining If Printer Status Readback Available. . .	9-22
Printer Status Readback and Printer I/O Switching .	9-23
Old Printer Status Readback Responses	9-25
Response Data Buffer Overflow	9-25
Handling Unexpected Printer Responses	9-27
Application Design Ideas	9-28

A. Product-Specific Feature Support

PJL Feature Support	A-2
PJL Environment Variable Support.	A-4
HP LaserJet IIISi Comments	A-13
HP LaserJet 4 Family Comments	A-14
LaserJet Printers Without a Control Panel.	A-20

B. PJL Command Summary

C. Programming Examples

D. PJL Status Codes

Status Code Groupings	D-1
Informational Messages (10xxx)	D-2
Background Paper Loading (11xyy)	D-3
PJL Parser Errors (20xxx)	D-4
PJL Parser Warnings (25xxx)	D-6
PJL Semantic Errors (27xxx)	D-7
Auto-Continuable Conditions (30xxx)	D-8
Potential Operator Intervention Conditions (35xxx)	D-9
Operator Intervention Conditions (40xxx)	D-10
Foreground Paper Loading (41xyy)	D-12
Hardware Errors (50xxx)	D-13

Glossary

Index

Quick Index

(Inside Back Cover)

Introduction to PJJ

What is PJJ?

Hewlett-Packard's Printer Job Language (PJJ) was developed to give software applications more job-level printer control, and to provide printer status information to applications. PJJ provides for the special needs of networks and other multi-user systems, in addition to enabling applications to simulate control panel functions that previously could not be controlled without pressing control panel keys.

For the HP LaserJet printers and other PCL 5 printers that support it, PJJ allows job-level control that cannot be accomplished with PCL, PostScript, or other printer languages. To provide this control, PJJ functions "above" the level of PCL and other printer languages, providing four major functions:

- Printer language switching between jobs
- Job separation
- Printer configuration
- Status readback from the printer to the host computer




Figure 1-1. PJJ Resides Above Other Printer Languages

Note



Some PJJ printers, such as the HP LaserJet 4L printer, do not support printer language switching or job separation. See Appendix A for feature support information.

Using PJJ, software applications can request information such as printer model, configuration, and status. PJJ also can be used to change control panel settings and modify the message displayed on the control panel, or change feature settings in printers without a control panel, such as the LaserJet 4L printer. For those printers supporting more than one printer language, applications can print one job using PCL, and then print the next job using PostScript or another printer language—without any operator intervention.

The Benefits of PJJ

Listed below are some of the benefits PJJ provides:

- Programmatic printer language switching—PJJ provides fully reliable switching between printer languages, such as PCL, Epson, IBM ProPrinter, and PostScript, directly from within applications.
- Printer status readback—printer model information, configuration, printer feature settings, and other printer status information can be obtained using PJJ.
- Programmatic front panel control—control panel settings, including control panel messages, can be changed remotely.
- Ease of use—All PJJ commands except the Universal Exit Language (UEL) command consist of printable characters and plain-English words or abbreviated words. Learning to use PJJ can be accomplished by reading the first three chapters of this manual and following the examples provided in the text.
- Better spooler control—PJJ allows spoolers improved printer management, especially in a network environment.

Who Should Use PJJL?

PJJL is designed to be used by experienced programmers, such as software application developers and technical support personnel. Although PJJL is very straight-forward, it is a powerful tool, and should be used only by experienced users who can create jobs that cause no adverse effects on other jobs in a shared environment. Applications containing PJJL commands used as described in this manual provide users with smooth transitions between print jobs. Conversely, improperly used PJJL commands can create problems in multi-user printing environments.

Compatibility With Non-PJJL LaserJet Printers

Since all HP LaserJet printers do not support PJJL, it is important to know what happens when PJJL commands are sent to a non-PJJL printer.

PJJL commands are recognized by the following HP printers:

- LaserJet IIISi, LaserJet 4Si and LaserJet 4SiMx
- LaserJet 4 and LaserJet 4M
- LaserJet 4 Plus and LaserJet 4M Plus
- LaserJet 4L and LaserJet 4ML
- LaserJet 4P, LaserJet 4MP, and LaserJet 4PJ
- DeskJet 1200C
- PaintJet XL300
- DesignJet Family

The printers listed above are designed to handle any PJJL command, even those not supported by the particular printer. On the other hand, all PCL 4 printers, and all PCL 5 printers not listed above, do not support PJJL. When PJJL commands are sent to a non-PJJL printer, the results differ depending on which commands are used and which printer language is used. The following paragraphs explain what happens when PCL and PostScript jobs containing PJJL commands are sent to non-PJJL printers.



For best results, do not send PJJL commands to a non-PJJL printer.

PCL Jobs

When non-PJJL printers receive PCL jobs, any PJJL commands that precede the initial PCL printer reset command (<ESC>E) print as ASCII text. When the initial printer reset command is received, it causes a page eject and the PCL job begins on a new page. The end result is a page or more of PJJL commands followed by the PCL job, and possibly followed by more PJJL commands. The PCL job should print as it would without any PJJL commands, as long as the PCL portion of the job begins and ends with a PCL printer reset command. However, a page of PJJL commands printed before and probably after the PCL job can be expected.

For those PCL applications that do not begin with a PCL printer reset command (or another PCL command that forces a page eject when preceded by printable data), the PJJL commands are printed as ASCII text on the same page as the PCL job. A good portion of the job may be unusable due to unpredictable page breaks and overprinted text on the first page.

PostScript Jobs

When non-PJJL LaserJet printers are running in PostScript mode, PJJL commands cause a PostScript error and prevent the job from printing. Pressing the printer's Continue key removes the error message, but the error causes the printer to discard the PostScript job.

Other Printer Languages

PJJL code is interpreted differently when running different printer languages on non-PJJL printers. To avoid printing problems, do not use PJJL commands when printing to any non-PJJL printer, regardless of which printer language is used.

PJL Command Syntax and Format


This chapter explains the conventions used to describe PJL command syntax. This chapter also describes the several different formats that PJL commands may take, giving examples of each. The chapter provides an explanation of how PJL-compatible printers handle illegal commands.

Document Conventions

The following syntax conventions are used to describe the PJL commands in this manual:

<i>variables</i>	Items in italics indicate names of variables.
COMMANDS	Items in uppercase letters indicate PJL command names and words that you type verbatim. PJL command names referred to in text are also in uppercase.
[]	Items in brackets [. . .] indicate optional parameters. The brackets themselves are not typed.
< >	Identifies a control code character, such as <CR> for carriage return, or a special defined identifier. The table on the next page lists the control codes and special identifiers used in the PJL syntax. (The < and > symbols themselves are not typed, but are replaced with the control codes or special identifiers they represent. For example, replace <FF> with the form feed character [ASCII 12].)
↪	This character indicates that the current line of code is a continuation of the previous line. For example, “This text belongs on the ↪same line.”
	A vertical bar indicates there is more than one optional parameter, such as LPARM and IPARM: [LPARM : <i>personality</i> IPARM : <i>port</i>].

The following illustration is an example of a PjL command line containing the ENTER command:



The table below lists the control codes and special identifiers used in this manual:

<HT>	Horizontal tab character (ASCII 9).
<LF>	Line feed character (ASCII 10).
<CR>	Carriage return character (ASCII 13).
<SP>	Space character (ASCII 32).
<ESC>	Escape character (escape character) (ASCII 27).
<FF>	Form feed character (ASCII 12).
<WS>	White space, a result of one or more <SP> or <HT>.
<words>	Printable characters (ASCII characters 33 through 255) and <WS>, starting with a printable character.
^D	PostScript end-of-file indication. It is not part of PjL, but is used to end PostScript examples.

Format of PJL Commands

All PJL command lines follow one of the following four formats. Each format defines how commands using that format are structured.

Format #1 <ESC>%-12345X

The only command that uses this format is the Universal Exit Language (UEL) command.

Format #2 @PJL [<CR>]<LF>

This format allows a PJL line with no command, and is used to add clarity to PJL command listings. You can use one or more of these commands to visually break up several lines of PJL commands.

Format #3 @PJL *command* [<words>] [<CR>]<LF>

The COMMENT and ECHO commands currently are the only PJL commands using format number 3.

Format #4 @PJL *command* [*command modifier* : *value*]
↳ [*option name* [= *value*]] [<CR>]<LF>


This format is used for all of the other PJL commands and is described in more detail below.

command — *command* is one of the assigned PJL command names, such as ENTER, RDYMSG, or RESET.

[*command modifier* : *value*] — The *command modifier* enables the user to specify what is effected by the command. For example, with the command modifier LPARM you can specify language-specific variables. A PJL command with a command modifier of LPARM : PCL only affects PCL-specific settings. A PJL command can contain only one command modifier. For example, in the command: @PJL SET
↳ [LPARM : *personality*] | [IPARM : *port*] *variable* = *value*
↳ [<CR>] <LF>, you can use either the LPARM command modifier or the IPARM command modifier, but not both.

[option name [= value]] — The option parameter specifies an option or sets a command option to a certain value. Examples include “@PJL INQUIRE COPIES” and “@PJL LANGUAGE = *personality*.” The range of values varies with each specific command and each printer model. A PJL command may have no options, or one or more options (an unlimited number).

The DEFAULT command shown below illustrates format number 4. The command sets the default PCL point size to 14.25.



PJL Syntax Rules



Following are the rules governing the use of PJL commands:

- The PJL prefix “@PJL” always must be uppercase. The remainder of the PJL command is not case-sensitive. For clarity, however, this manual shows other portions of PJL commands in uppercase to indicate portions that are not variable and that should be typed as shown (such as the first three words in the following command):
`@PJL STMSG DISPLAY = "message" [<CR>]<LF>`
- Spacing between characters, or “white space,” is comprised of one or more of either the space character (ASCII 32) or the horizontal tab character (ASCII 9). For clarity and consistency, this manual shows all white space as one blank space.

- The placement of white space in PJJL commands depends on its location within the command. Some white space is required and some is optional:

- White space is required between the @PJJL prefix and the PJJL command name, and between the PJJL command name and command modifiers. For example:
 @PJJL OPMSG DISPLAY or
 @PJJL ENTER LANGUAGE
- If white space is shown in any other place in the command, it is optional (see the examples below).
- If white space is not shown between two portions of a command, white space is not allowed. An example is between the optional carriage return and required line feed character that terminate most commands.

For clarity, this manual consistently shows white space as one blank space. The PJJL language requirements are shown in both examples below:



Types of Variables

PJL uses *alphanumeric variables*, *numeric variables*, and *strings*. The following explains the three types of variables and their ranges.

- ***Alphanumeric variables***—any combination of letters and digits, with the stipulation that the first character always must be a letter. Letters consist of the uppercase letters (ASCII 65 through 90) and lowercase letters (ASCII 97 through 122). Digits consist of numbers 0 through 9 (ASCII 48 through 57).

Examples of *valid* alphanumeric variables include:

LaserJet279

J1953

Examples of *invalid* alphanumeric variables include:

279LaserJet

(Alphanumeric variables must begin with a letter)

J 1953

(Space characters [ASCII 32] are not allowed in alphanumeric variables)

- ***Numeric variables***—any number consisting of digits, with one optional decimal point and an optional + or – sign preceding the first digit. Only one decimal point may be used, and it must be placed somewhere after the first digit. Digits are not required after the decimal point.

Examples of *valid* numeric variables include:

0.123456

-123.456

+657000

2468.

Examples of *invalid* numeric variables include:

.123456

(The decimal point must be preceded by at least 1 digit)

-123.45.6

(Only 1 decimal point is allowed in a numeric variable)

+657,000

(Commas are not allowed in numeric variables)

- **Strings**—enclosed in quotation marks, strings consist of any combination of characters from ASCII 32 through 255, plus ASCII 9 (horizontal tab), excluding ASCII 34 (quotation marks).

Examples of *valid* strings include:

"<HT>This is a valid string."

(Tabs are allowed in strings)

"Print job #4655"

Examples of *invalid* strings include:

"This is not a valid" string."

(Strings cannot contain quotation marks)

"This is also not<CR>valid."

(<CR> is not within the valid range of ASCII characters for a string.)

Note



When the LaserJet 4PJ language is set to Japanese, strings which correspond to a control panel message are displayed on the control panel using the JIS X0201-76 character set.

Processing Invalid Commands

There are two general types of invalid commands: those commands with *syntax errors*, and those that have *syntax* or *semantic warnings*. Each type is handled differently.

- *Syntax errors* cause the printer to ignore the entire PJI command, and include errors such as unrecognized commands and command modifiers, strings missing closing double-quotes, numeric values missing digits before the decimal point, and numeric values encountered when alphanumeric values are expected. When the printer receives commands with syntax errors, it ignores the entire command.

For example, the value part of the JOB command's NAME option is a string and requires double quotes around the value (as shown below). In the second example below, the JOB command is ignored since the string (April Paychecks) contains the opening but not the required closing quotes.

Valid command:

```
@PJI JOB NAME = "April Paychecks" <LF>
```

Invalid command:

```
@PJI JOB NAME = "April Paychecks <LF>
```

- *Syntax warnings* and *semantic warnings* are issued for commands such as those having unsupported options, values that are out of range, values that are the wrong type or missing, or values that are included when none are allowed. When the printer receives commands with syntax or semantic warnings, it executes as much of the command as possible, but the portion of the command containing the warning is ignored.

For example, in the following two sample PJL commands, START is a valid option for the JOB command, but FINISH is not a valid option (the END option should be used). The START option is executed, but the FINISH option is ignored.

Valid command:

```
@PJL JOB START = 1 <LF>
```

Invalid command:

```
@PJL JOB START = 1 FINISH = HOME <LF>
```

Note



Any errors that occur during PJL parsing can be received by enabling device status as described in Chapter 7 (send the USTATUS DEVICE = VERBOSE command). Appendix D lists the status codes that are received by the host when an invalid command is received and unsolicited verbose device status is enabled.

Using PJP

This chapter describes how PJP commands are used. After reading this chapter, you can create basic jobs and perform simple PJP tasks, such as printer language switching and changing some PJP feature settings.

To give you an understanding of where to look for more PJP information, this chapter explains how the manual categorizes PJP commands into five groups of related commands. Each command has a brief description of its function to help familiarize you with the PJP language.

Note



Each PJP printer has its own implementation of PJP commands. See Appendix A for printer-specific information.

Overview of How Commands are Used

As previously explained, PJP resides “above” other printer languages such as PCL and PostScript. PJP commands encapsulate the printer language jobs, as shown in Figure 3-1. The UEL command allows the printer to alternate between interpreting PJP commands and printer language commands. (Although PCL and PostScript are shown in Figure 3-1, other printer languages can be involved.)

PJP Code	PCL Job	PJP Code	PostScript Job	PJP Code
----------	---------	----------	----------------	----------

Figure 3-1. PJP Commands Encapsulate Print Jobs

PJL Job Requirements

PJL has certain job requirements that must be met to work correctly. Jobs that satisfy the following requirements are “well-formed” and work well with all PJL printers, both in single-computer/single-printer environments and network environments. The following explains these requirements.

- All PJL jobs must begin and end with a Universal Exit Language (UEL) command (<ESC>%-12345X). This command exits the current printer language and returns control to PJL.
- The Universal Exit Language (UEL) command at the beginning of the job must be immediately followed by the PJL command prefix (@PJL). The “@PJL” can be followed by an optional carriage return and a required line feed character, or it can be the prefix of another PJL command (see the two following examples). No other characters, including control characters, are allowed between the UEL command and the @PJL prefix.
- The UEL command at the job end must not be followed by anything (except the first character of the next job).
- Line Termination—a line feed character (<LF>) is required to terminate all PJL commands (except the UEL command). A carriage return can precede the terminating line feed, however the carriage return is optional and is ignored.
- No blank command lines are allowed. The command @PJL [<CR>]<LF> is provided for situations where a blank line is needed to add space between command lines.

The following command lines demonstrate two ways to begin a job while satisfying PJL requirements. Both lines begin with a UEL command, are immediately followed by @PJL, and are terminated with a line feed character. All PJL jobs also must end with a UEL command. The examples on the following page demonstrate how to begin and end a PJL job.

```
<ESC>%-12345X@PJL <CR><LF>
```

```
<ESC>%-12345X@PJL COMMENT *Start Job* <CR><LF>
```

Some Sample PJJ Jobs

This section consists of two basic PJJ jobs that illustrate how to use PJJ. The first job changes a few printer control panel settings and prints a PCL file. The second job prints a PCL file followed by a PostScript file. (The \hookrightarrow symbol indicates that the command line is actually part of the previous line.)

Example: Changing Control Panel Settings

This example simulates using PJJ to control printer features that are not available in a particular application program. In this case, the features to be modified are: number of copies, Resolution Enhancement setting, and page protection.

```
<ESC>%-12345X@PJJ COMMENT *Start Job* <CR><LF>
@PJJ JOB NAME = "Sample Job #1" <CR><LF>
@PJJ SET COPIES = 3 <CR><LF>
@PJJ SET RET = MEDIUM <CR><LF>
@PJJ SET PAGEPROTECT = OFF <CR><LF>
@PJJ ENTER LANGUAGE = PCL <CR><LF>
<ESC>E. . . . PCL job . . . .<ESC>E
 $\hookrightarrow$ <ESC>%-12345X@PJJ <CR><LF>
@PJJ EOJ<CR><LF>
<ESC>%-12345X
```

Example: Switching Printer Languages

This example contains two print jobs, one PCL and one PostScript. The PCL job prints first, then PJJ code switches the printer language to prepare for the PostScript job.

```
<ESC>%-12345X@PJJ <CR><LF>
@PJJ COMMENT ** Beginning PCL Job ** <CR><LF>
@PJJ ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . . . PCL job . . . .<ESC>E
 $\hookrightarrow$ <ESC>%-12345X@PJJ COMMENT End PCL <CR><LF>
@PJJ COMMENT Ready for PostScript Job <CR><LF>
@PJJ ENTER LANGUAGE = POSTSCRIPT <CR><LF>
%!PS-ADOBE ... PostScript print job ... ^D
 $\hookrightarrow$ <ESC>%-12345X
```

What's Next?

Now that you have learned the PjL requirements and have seen how to use PjL commands in the sample programs described on the previous page, look through the following “Command Groupings” table. It can help you find the information you need to add PjL capabilities to your application. If your application only uses PjL to switch printer languages, you may need to read only Chapter 4. However, if you want to do more with PjL, be sure to look through Chapter 9 (Programming Tips), and the other chapters that pertain to your application. Also, be sure you know which PjL commands are supported by the printer you are using. See Appendix A for feature support information.

- Chapter 5 explains commands that enable you to create jobs for keeping track of printing status, and explain a non-printing mode that allows printing of specific pages of print jobs.
- Chapter 6 describes commands that enable you to change control panel settings and default configuration settings. The commands in this chapter enable you to set the printer features to a known state.
- Chapter 7 covers status readback commands, enabling you to request configuration and status information from the printer.
- Chapter 8 explains the commands that can alter the messages displayed on the printer control panel.

Command Groupings by Functionality

This manual categorizes the PJI commands into related groups. Each group of commands is covered in a separate chapter, as indicated in the following table. This table lists each command and gives a short description of each.

Command Group	Command	Command Description
Kernel Commands (Chapter 4)	Universal Exit Language (UEL)	Exits current printer language and returns control to PJI. Resets the PJI parser to start at the beginning of the line.
	COMMENT	Causes PJI to accept the command line as a comment.
	ENTER	Selects a printer language for processing the current job.
Job Separation Commands (Chapter 5)	JOB	Informs printer of the start of a print job, resets the page count, allows naming of the job, supports non-printing mode for printing portions of jobs. Where supported, it adds PJI password security.
	EOJ	Tells printer the print job is complete, resets the page count.
Environment Commands (Chapter 6)	DEFAULT	Sets default value for environment variables.
	SET	Sets an environment variable to a specified value for the duration of a PJI job.
	INITIALIZE	Resets current and default PJI variables to factory default values.
	RESET	Resets current PJI variables to default values.

Command Group	Command	Command Description
Status Readback Commands (Chapter 7)	INQUIRE	Requests the current value for a specified environment variable.
	DINQUIRE	Requests the default value for a specified environment variable.
	ECHO	Returns the <words> portion of the command to the host computer.
	INFO	Requests a specified category of printer information, such as printer model number, printer memory available, configuration, page count, status, environment variables, and unsolicited status variables.
	USTATUS	Allows printer to send unsolicited status messages for device status changes, end-of-job status, and pages printed. Status can be sent at specified time intervals.
	USTATUSOFF	Turns off all unsolicited status.
Device Attendance Commands (Chapter 8)	RDYMSG	Specifies a message that replaces the READY message on the printer control panel. Does not affect online state.
	OPMSG	Displays specified message on printer control panel and takes printer offline.
	STMSG	Displays specified message on printer control panel and takes printer offline. If status readback is enabled, returns name of the key (ON LINE, CONTINUE, or RESET) that operator presses to return the printer online.

Kernel Commands

Introduction

This chapter explains the following three PJI commands:

- Universal Exit Language (UEL) command—exits the current printer language and returns control to PJI.
- ENTER command—selects a printer language for processing the current job.
- COMMENT command—enables developers to add comments to their PJI commands.

Together, these commands provide a minimum set of tools necessary to implement job control. These commands allow applications to set job boundaries, add comments, and programmatically select printer languages.

Besides programmatic printer language switching, you can configure some LaserJet printers to switch printer languages automatically between print jobs. Following the descriptions of the UEL, ENTER, and COMMENT commands, this chapter describes the different methods used to switch printer languages.

Universal Exit Language (UEL) Command

The Universal Exit Language (UEL) Command causes the printer to exit the active printer language. The printer then returns control to PJJ.

Note



Use the UEL command at the beginning and end of every PJJ job. You do not need a UEL command before every PJJ command. The examples demonstrate using this command.

Syntax: <ESC>%-12345X

Parameters: The UEL command does not use any parameters.

Comments: The UEL command is a data stream sequence recognized by all printer languages in PJJ printers. The UEL command instructs the active printer language to finish processing the current job and relinquishes control to PJJ. If PJJ is active, any unprocessed PJJ commands are discarded and the printer is ready to accept the next PJJ command.

Note



If the printer is processing a PostScript job and TBCP is enabled, the UEL command causes the printer to exit PostScript and enable PJJ.

Remember that:

- All jobs must start and end with the UEL command. Printers that support I/O switching use the UEL command as one way to determine job boundaries, indicating when to perform I/O switching (see the “Timeouts” section in Appendix A).
- At the beginning of a PJJ job, the PJJ command prefix (@PJJ) must immediately follow the UEL command. If the printer receives any characters, spaces, or control codes before @PJJ, it enables the default printer language and processes the job in that printer language (if

PERSONALITY =AUTO, the data stream is sampled for context-sensitive switching—see the “Methods of Printer Language Switching” later in this chapter). Instead of relying on implicit switching, use the ENTER command to specify the printer language, even if the printer has only one printer language.

The following example demonstrates the use of the UEL command.

**Example:
Using the
UEL Command**

This example enters PCL and prints a PCL job. Notice how the job begins and ends with the UEL command, and how the first UEL command is followed immediately by the @PJL prefix.

```
<ESC>%-12345X@PJL COMMENT PCL Job <CR><LF>  
@PJL ENTER LANGUAGE = PCL <CR><LF>  
<ESC>E . . . . PCL Job . . . . <ESC>E  
↳<ESC>%-12345X
```

If the print job was a PostScript job instead, the following would be sent:

```
<ESC>%-12345X@PJL COMMENT PostScript <CR><LF>  
@PJL ENTER LANGUAGE = POSTSCRIPT <CR><LF>  
%!PS-ADOBE ... PostScript print job ... ^D  
↳<ESC>%-12345X
```

ENTER Command

The ENTER command enables the specified personality (such as PCL or PostScript). Use this command to select the printer language for printing subsequent data.

Syntax: @PJL ENTER LANGUAGE = *personality* [<CR>]<LF>

Parameters:

Parameter	Range
personality	PCL, POSTSCRIPT, ESCP, Others *

* Other personalities may be supported.

- **personality** — The personality variable must be set to PCL, POSTSCRIPT, ESCP or one of the supported personalities. Personalities besides PCL and POSTSCRIPT can be added to some LaserJet printers by plugging in additional hardware, such as cartridges or ROM SIMMs. If your application handles status readback, you can request a list of all valid personalities present in the printer (see the “INFO CONFIG” section in Chapter 7).

Comments:

The ENTER command must be positioned immediately before any printable data. The selected personality begins parsing immediately after the <LF> that terminates the ENTER command.

If the printer does not receive the ENTER command requesting a specific printer language, the printer enables the default printer language as set from the control panel (or if the printer supports context switching, such as the LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P, or 4MP printers, it samples the data stream if PERSONALITY is set to AUTO—see the “Methods of Printer Language Switching” later in this chapter).

For any job containing printable data, send the ENTER command if the intended printer language is known, instead of relying on the printer's ability to switch to the default printer language. This is true even if there is only one available personality.

When a printer language is specified, that language currently must be installed in the printer. If the printer receives a request for an invalid printer language, the printer consumes the data stream until it finds the next UEL command, and then discards the data. The printer also posts a clearable warning message and, if enabled, returns a status message.



In spooling applications, performance is not adversely affected if both the application file and the spooler send the ENTER LANGUAGE command.

**Example:
Using the
ENTER Command**

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Beginning PostScript Job <CR><LF>
@PJL ENTER LANGUAGE = POSTSCRIPT <CR><LF>
%!PS-ADOBE ... PostScript print job ... ^D
↳<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT End of PostScript Job <CR><LF>
@PJL <CR><LF>
@PJL <CR><LF>
@PJL COMMENT Prepare for PCL Job <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . . . PCL Job . . . . <ESC>E
↳<ESC>%-12345X
```

COMMENT Command

The COMMENT command enables you to add a line of information as a comment. Use this command whenever you want to add an explanation to PJI commands.

Syntax: @PJI COMMENT *remarks* [<CR>]<LF>

Parameters:

Parameter	Range
remarks	ASCII characters 33 through 255 and <WS>, starting with a printable character.

Comments: The COMMENT command is useful for documenting lines of PJI commands. Comments may be placed anywhere in the PJI code between the initial UEL command and the ENTER command. (Comments placed after the ENTER command are considered printable data and are printed as determined by the active printer language.)

Like other PJI commands, the COMMENT command is terminated by a line feed character. You cannot extend comments onto the next line. Comments longer than one line require a separate COMMENT command for each line.

See the following page for an example demonstrating the use of the COMMENT command.

**Example:
Using the COMMENT
Command**

This example demonstrates using the COMMENT command to add clarity to your PJJ command listings.

```
<ESC>%-12345X@PJJ <CR><LF>
@PJJ COMMENT ***** <CR><LF>
@PJJ COMMENT ** D. Thiel- 10/22/92 ** <CR><LF>
@PJJ COMMENT ***** <CR><LF>
@PJJ <CR><LF>
@PJJ <CR><LF>
@PJJ JOB NAME = "Using Comments" <CR><LF>
@PJJ <CR><LF>
@PJJ <CR><LF>
@PJJ COMMENT *** TURNING OFF RET & ** <CR><LF>
@PJJ COMMENT *** PAGE PROTECTION *** <CR><LF>
@PJJ SET RET = OFF <CR><LF>
@PJJ SET PAGEPROTECT = OFF <CR><LF>
@PJJ <CR><LF>
@PJJ COMMENT ***** ENTERING PCL ***** <CR><LF>
@PJJ ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . . . PCL Job . . . . <ESC>E
↳<ESC>%-12345X@PJJ <CR><LF>
@PJJ EOJ <CR><LF>
<ESC>%-12345X
```

Methods of Printer Language Switching

There are three methods of switching printer languages, two of which are supported by all PJI printers. All three methods are described below:

- **Explicit Switching**—with explicit switching, the PJI ENTER LANGUAGE command is used to “explicitly” select the desired printer language. This is the preferred switching method because it ensures that the specified printer language always is selected (see Figure 4-1).
- **Implicit Switching**—if the printer has a default printer language configured, and the print job does not explicitly select a printer language using the PJI ENTER LANGUAGE command, the printer automatically switches to the default printer language. (See the User’s Manual for each LaserJet printer for instructions about specifying a default printer language.) This switching method does not always ensure that the proper printer language is used, since the printer simply uses the default printer language.
- **Context Switching (HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P and 4MP only)**—If the printer is set to automatically select a printer language (see the printer user’s manual), and the print job does not explicitly select a printer language using the PJI ENTER LANGUAGE command, the printer samples the incoming data and looks for indications of a particular printer language. Once it recognizes the printer language, the printer backs up to the beginning of the sampled print data and switches to the printer language determined to be most appropriate. Then it begins to parse the data in the newly selected printer language.

Although printers supporting context switching can select printer languages accurately, we recommend that every job containing printable data include an ENTER LANGUAGE command to explicitly select the correct printer language. This method improves performance and eliminates unintentional printer language switching, which can potentially cause data loss. Performance is not

adversely affected if both the application and the spooler send the ENTER LANGUAGE command.




Figure 4-1. Switching Printer Languages

Job Separation Commands

Introduction

This chapter explains the JOB and EOJ commands. These commands are used to describe the boundaries of a job, indicating where the PJJ job begins and ends. The commands can be used to name a job, and they support a non-printing mode for printing selected pages within a job. When used in combination with status readback, the printer also can send status information regarding when the printer starts processing the job and when the job is complete. This chapter also describes PJJ security and its relation to the JOB command.

JOB Command

The JOB command informs the printer of the start of a PJI job and synchronizes the job and page status information. It also is used to specify which pages of a job are printed. Use the JOB/EOJ commands for spooling and related applications to monitor printing status, name a job, or print portions of a job, or to mark job boundaries to keep the printer from treating a single print job as multiple jobs (for example, when printing a job with a banner page). Also, in jobs sent to the LaserJet 4 Plus, 4M Plus, 4Si, and 4SiMx printers, use the JOB command to specify the correct password.



The JOB and EOJ commands always are used in pairs. Do not use one without the other.

Syntax: @PJI JOB [NAME = "*job name*"] [START=*first page*] ➔ [END = *last page*] [PASSWORD = *number*] ➔ [<CR>]<LF>

Parameters:

Parameter	Functional Range	Default
NAME = " <i>job name</i> "	ASCII 33 thru 255, <SP>, <HT>	N/A
START = <i>first page</i>	1 to 2,147,483,647	1
END = <i>last page</i>	1 to 2,147,483,647	prints entire job
PASSWORD = <i>number</i>	0 to 65,535	0

- **NAME = "*job name*"** — The command option NAME tags the print job with a job name. The variable *job name* can be any combination of printable characters and spaces or horizontal tab characters, with a maximum of 80 significant characters. The *job name* variable is a string and must be enclosed in double quotes, as shown in the command syntax. If the NAME option is included, the unsolicited job status includes the job name (if unsolicited job status is enabled).

- **START = *first page*** — The command option START is used to provide a non-printing mode for skipping to a selected portion of the job. It indicates the first page that is printed. If the START option is omitted, the printer starts printing at the beginning of the job. If the end of the job comes before the START page, no pages are printed.
- **END = *last page*** — The command option END indicates the page number of the *last page* to be printed. The *last page* variable is relative to page 1 of the print job. If the END variable is omitted, the printer prints to the end of the job. If the end of the job is encountered before the START page, no pages are printed. If the end of job is encountered before the END page, printing terminates. Additionally, if the START page is greater than the END page, no pages are printed.
- **PASSWORD = *number*** — (LaserJet 4 Plus, 4M Plus, 4Si, 4SiMx only) The command option PASSWORD allows the application to modify the NVRAM variables if the password matches the active password variable. (Using PjL, the NVRAM variables are modified using either the DEFAULT or INITIALIZE commands; some printer language commands may also modify NVRAM variables.) Passwords are set using the DEFAULT command. The default password value is 0, which indicates PjL security is disabled—any job can modify printer feature settings using the DEFAULT or INITIALIZE commands. If any other password value is active, PjL jobs must issue the correct password value or they are disabled from using the DEFAULT or INITIALIZE commands. (See the “PjL Security” section at the end of this chapter.)

Comments: When a JOB command is received, the printer does not recognize the UEL command as a PjL job boundary until an EOJ command is received. UEL commands within a PjL JOB/EOJ command pair are treated as printer language resets; they default the print environment to the PjL Current Environment settings, instead of the User Default Environment.

If your application has status readback capabilities, you can monitor the job status using the USTATUS command with the JOB option. If job status is enabled and the printer receives a JOB command, it returns a job status message.

Note



Resetting the page count associated with unsolicited page status affects only future pages. Pages already processed, but not yet printed, are not affected.

JOB commands can be nested. For example, a spooling application can send a PJI job that uses the JOB command to another spooler that encapsulates the spooled job with another JOB/EOJ command pair. When this is done, note that the job name from the outer JOB command is cleared or overwritten by the inner command.

**Example:
Using the JOB
Command to
Print Selected Pages**

You can use the JOB command with the START and END options to print selected pages of a job. The entire job must be sent to the printer and formatted, but the printer does not begin printing until the page indicated in the START option.

Note



If there is a need to print more than one copy of each page, send the job multiple times using the START and END options to print collated copies. Using the SET command or a printer language “number of copies” command to print multiple copies of selected pages causes unexpected results, because the printer counts physical pages, not multi-copy collated pages.

In this example, the JOB command:

- Informs the printer of the beginning of a print job.
- Names the print job “Jim’s Job.”
- Instructs the printer to begin printing on page three of the job. (Since the END option is missing, the job prints from page three through the end of the job.)

Notice that the name option for the JOB and EOJ commands need not be the same. If desired, you can use different names for each.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL JOB NAME = "Jim's Job" START = 3 <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . . . PCL Job . . . . <ESC>E
↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "End of Jim's Job" <CR><LF>
<ESC>%-12345X
```

**Example:
Using the
JOB Command to
Monitor Job Status**

This example demonstrates a PostScript print job that is spooled before printing. The job actually consists of three separate sections (notice the UEL commands that bound the three sections—the first section does not need a closing UEL command since the printer is already in PJL mode):

- The first section is sent by the spooler. These lines name the print job and send the USTATUS command so the spooler can monitor job status.
- The next section is a PostScript job sent to the spooler from a software application.
- The last section is sent by the spooler to end the job. When the last page is completely printed (in the output tray), the printer returns unsolicited status information notifying the spooler that the job is complete.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT **Beginning of Job ** <CR><LF>
@PJL JOB NAME = "TF's Monitor Job" <CR><LF>
@PJL USTATUS JOB = ON <CR><LF>

    <ESC>%-12345X@PJL <CR><LF>
    @PJL ENTER LANGUAGE = POSTSCRIPT <CR><LF>
    %!PS-ADOBE .. PostScript print job ... ^D
    ↳<ESC>%-12345X

↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "End of TF's Job" <CR><LF>
<ESC>%-12345X
```

Note 

If the spooler received a print job that did not use PJL (that is, the application generated a print job that consisted of just "%!PS-ADOBE .. PostScript print job ... ^D", a LaserJet printer using context-sensitive switching would still print properly and the spooler would still receive the unsolicited job status information.

**Example:
Nested JOB
Commands**

This example shows a PCL job that was sent to spooler 1, which in turn was sent to spooler 2 (the nested jobs are indented). Note that the first job name is overwritten by the second job name ("Spooler 1 Job") when the second JOB command is processed.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL JOB NAME = "Printing Job Sent From
↳Spooler 2" <CR><LF>

<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Printing a PCL job <CR><LF>
@PJL JOB NAME = "Spooler 1 Job" <CR><LF>
@PJL SET RESOLUTION = 600 <CR><LF>
  <ESC>%-12345X@PJL <CR><LF>
    @PJL ENTER LANGUAGE = PCL <CR><LF>
    <ESC>E . . PCL print job . .<ESC>E
    ↳<ESC>%-12345X
    ↳<ESC>%-12345X@PJL <CR><LF>
    @PJL EOJ NAME = "End Spooler 1 Job" <CR><LF>
    <ESC>%-12345X

↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "End Spooler 2 Job" <CR><LF>
<ESC>%-12345X
```

Related Commands: EOJ, USTATUS, DEFAULT

EOJ Command

The EOJ command informs the printer that the job has completed. Use this command whenever you use the JOB command.



The JOB and EOJ commands are always used in pairs. Do not use one without the other.

Syntax: @PJL EOJ [NAME = "*job name*"] [<CR>]<LF>

Parameters:

Parameter	Functional Range	Default
NAME = " <i>job name</i> "	ASCII 33 thru 255, <SP>, <HT>	N/A

- **NAME = "*job name*"** — Using the EOJ command, you can name your print job. The job name variable is a string and must be enclosed in double quotes as shown in the command syntax. The job name string need not be the same name used in the JOB command. If the NAME option is included, the unsolicited end-of-job status includes the job name (if unsolicited job status is enabled).

Comments: The EOJ command marks the end of the job started with the previous JOB command. The EOJ command:

- Resets the PJL Current Environment variables to their default (NVRAM) values, as if the printer powered down and then powered up again.
- Resets the page number associated with unsolicited page status.

- Terminates the non-printing mode (enabled by using the START/END options). The non-printing mode, if enabled by the last JOB command, only applies to the previously received data, and does not effect any future pages until another JOB command enables the non-printing mode again.

**Effect on
Unsolicited Job Status**

When the printer receives this command, it returns unsolicited job status information, if enabled, when the last page of the job exits the printer and is in the output tray. The EOJ command resets the page number associated with unsolicited page status. Resetting the page count associated with unsolicited page status only affects future pages. Pages already processed, but not yet printed, are not affected.

Related Commands: JOB, USTATUS

PJL Job Security

The HP LaserJet 4 Plus, 4M Plus, 4Si, and 4SiMx printers support two types of PJL security:

- Password protection of default feature settings—this type of security prevents applications from modifying the printer's default feature settings unless the correct password is specified.
- Control panel lock—control panel lock prevents users from modifying control panel settings using the control panel keys.

Both types of security are set using the DEFAULT command.

Password Protection of Default Feature Settings

You can use a password to protect the printer's default features by sending the @PJL DEFAULT PASSWORD = number command, specifying a number between 1 and 65,535 (the 0 value disables password protection). Once password protection is enabled, the DEFAULT or INITIALIZE commands are disabled unless the correct password is specified in the JOB command. Printer languages, such as PCL and PostScript, are also prevented from changing default variables.

Secure PJL jobs are able to use the DEFAULT and INITIALIZE commands (or printer language commands) to set default features, including the value of the PASSWORD and CPLOCK variables, until the next EOJ command is received.

Control Panel Lock

You can “lock” the control panel by sending the @PJL DEFAULT CPLOCK = ON command. When the control panel is locked, the user cannot change any control panel settings. If the user tries to change any control panel settings, the message “MENUS LOCKED” appears on the control panel display for about five seconds. If the password feature is enabled (that is, if the PASSWORD variable is anything other than 0), the CPLOCK variable can only be changed from within a “secure” PJL job (a job that includes the correct PASSWORD value in the JOB command).

Example: Using PJJ Security

This example demonstrates how to set a password and how to lock the control panel so that users cannot modify control panel settings. It is assumed that the password value at the start of the job is 7654. The example changes the password to 1776.

```
<ESC>%-12345X@PJJ <CR><LF>  
@PJJ COMMENT **Set Password** <CR><LF>  
@PJJ COMMENT **& Lock Control Panel**<CR><LF>  
@PJJ JOB PASSWORD = 7654 <CR><LF>  
@PJJ DEFAULT PASSWORD = 1776 <CR><LF>  
@PJJ DEFAULT CPLOCK = ON <CR><LF>  
@PJJ EOJ <CR><LF>  
<ESC>%-12345X
```

To unlock the control panel, you would send a job similar to the following job. This job specifies the correct password with the JOB command, and then uses the DEFAULT command to unlock the control panel.

```
<ESC>%-12345X@PJJ <CR><LF>  
@PJJ COMMENT **Unlock Control Panel** <CR><LF>  
@PJJ JOB PASSWORD = 1776 <CR><LF>  
@PJJ DEFAULT CPLOCK = OFF <CR><LF>  
@PJJ EOJ <CR><LF>  
<ESC>%-12345X
```

Environment Commands

Introduction

Hewlett-Packard LaserJet printers have many features you can set using printer commands or by pressing control panel keys. Since previous jobs can change feature settings to unwanted values, applications should set printer features affecting the print job to a desired state at the beginning of the job.

Setting features to a desired state is easily accomplished using a combination of PJP and printer language commands. This chapter describes sets of printer features known as print environments, and the PJP commands you use to set printer features to a desired state, such as:

- **DEFAULT**—sets the default value for environment variables, storing these values in non-volatile RAM.
- **INITIALIZE**—resets the current and default PJP variables to the factory default values.
- **RESET**—resets the current PJP variables to the default values.
- **SET**—sets an environment variable to a specified value until the next PJP reset condition.

Note



For a list of default feature settings, see Appendix A.

Print Environments

At any time during printer operation, the printer's current feature settings are referred to collectively as the print environment. When certain printer events occur, such as the incidence of a printer language reset, PJI RESET command, or other PJI reset condition, the print environment settings can default to the settings of other stored environments.

The printer constantly maintains four environments, which are listed below in priority order:

- Factory Default Environment (lowest priority)
- User Default Environment
- PJI Current Environment
- Modified Print Environment (highest priority)

The *Factory Default Environment* holds the initial feature values set at the factory, which can be used for default values when a complete reset is needed. The *User Default Environment* holds the settings modified with the DEFAULT command, or set from the control panel. The print environment defaults to the User Default values when various printer conditions occur, such as the end of a PJI job, a PJI reset condition, or when certain PJI commands are executed. The *PJI Current Environment* contains the current PJI feature settings. When a printer language is entered or a new job begins, the PJI Current Environment settings are loaded into the *Modified Print Environment*, providing a base feature set which the application can modify if needed. After a printer language is entered, feature settings are recorded in the Modified Print Environment.

Each environment is explained in more detail below:

- **Factory Default Environment**—This environment consists of a group of feature settings that are permanently stored in the printer. The printer uses these settings when it is powered on for the first time after leaving the factory, and after the @PJL INITIALIZE command is received.
- **User Default Environment**—This environment contains the values that are set using the @PJL DEFAULT command or the control panel keys. These values are stored in non-volatile RAM (in those printers containing NVRAM). Following any PJJ reset condition, these values are placed into the PJJ Current Environment. If the printer has a control panel, the User Default values are displayed on the control panel under the appropriate menu.
- **PJJ Current Environment**—This environment contains the current PJJ feature settings. Current settings are based on the User Default values and any settings modified using the @PJJ SET command. These values default to the User Default values when a PJJ reset condition occurs.
- **Modified Print Environment**—This environment is active as soon as a printer language is entered. At that time, the PJJ Current Environment values are loaded into the Modified Print Environment and act as a base set of features. Printer language commands then are used to modify feature settings to the desired state. The PJJ Current Environment settings are loaded into the Modified Print Environment whenever a personality is activated or a reset is received, including any printer language reset or PJJ reset condition.

Figure 6-1 illustrates how the environments interact, and how they affect the modified print environment.




Figure 6-1. How Environments Affect the Print Job

Changing Environment Settings

The following scenario elaborates on how the print environment changes during printer operation. The “number of copies” feature is used to show feature changes as events occur.

1. The first time the printer is turned on after it leaves the factory (or after the @PJJ INITIALIZE command), the number of copies feature is set to the factory default value of 1 copy.
2. At any point following the initial power-on or the @PJJ INITIALIZE command, the number of copies feature can be set using the @PJJ DEFAULT COPIES command in a PJJ job or by changing the COPIES = setting on the control panel. This changes the User Default Environment setting to a new value, such as number of copies = 3. The User Default Environment values are not loaded into the PJJ Current Environment until the next PJJ reset condition occurs. (For printers with control panels, if the printer is currently not processing a job while the feature is changed from the control panel, the printer treats the feature change as a PJJ reset condition and loads the newly changed value into non-volatile RAM.)
3. If the PJJ job uses the @PJJ SET COPIES = 5 command to change the number of copies, the PJJ Current Environment value changes to the selected setting (for example, 5). Otherwise, the number of copies setting remains the same as set using the DEFAULT command or the control panel.
4. If the printer language (such as PCL or PostScript) changes the number of copies setting to another value, such as 8, the newly specified printer language value overrides the PJJ Current Environment value. If the printer has a control panel, however, it still displays the User Default Environment value set using the control panel keys or the DEFAULT command.
5. The next PJJ reset condition defaults the number of copies setting to the value set from the control panel or by using the DEFAULT command (User Default Environment). In

this example, the number of copies feature setting then defaults to 3 after a PJJ reset condition.

All other features operate similarly—if any feature is not modified by a higher priority action, it keeps its current value setting.

**Example:
Changing
Environment
Settings**

This example shows the values stored in the different environments when commands are issued. The example begins with the number of copies set to 1 in all environments (the Factory Default Environment setting). The table reflects the current settings after each command.

Command Sent	Environment Setting			
	Factory Default	User Default	PJJ Current	Modified Print
After PJJ INITIALIZE or RESET MENU	1	1	1	1
@PJJ DEFAULT COPIES=3	1	3	1	1
@PJJ SET COPIES = 4	1	3	4	4
@PJJ ENTER LANGUAGE=PCL<LF> <ESC>&15X	1	3	4	5
<ESC>%-12345X	1	3	3	3

**Environment
Summary**

As indicated previously, each environment differs in relation to how it is stored, how the settings are changed, and how the PJJ Current Environment can be defaulted. The table beginning on the following page summarizes the characteristics of each environment. For those printers without a control panel, disregard any mention of control panels. In these printers, User Default Environment features are controlled using just the @PJJ DEFAULT command.

Note



See Appendix A of this manual for a list of environment variables for the various PJJ printers.

Factory Default Environment	Stored permanently in printer memory—settings cannot be modified.
	Factory default settings cannot be read programmatically, but they are listed in the <i>PCL 5 Comparison Guide</i> .
User Default Environment	The User Default Environment is set to the factory default values when the printer initially is powered on—before printer commands are sent from an application or any control panel settings are changed.
	Stored in non-volatile RAM in printers that have it—can be changed using the @PJM DEFAULT command or control panel keys.
	The @PJM INITIALIZE command loads the Factory Default settings into the User Default Environment.
	User default settings can be read using the @PJM DQUIRE command.
PJM Current Environment	Any PJM reset condition loads the User Default Environment feature settings into the PJM Current Environment.
	Always reflects the PJM-level settings currently in use.
	Stored in RAM—can be changed using @PJM SET command. These values override feature settings until the next PJM reset condition.
	The @PJM INITIALIZE command loads the Factory Default settings into the PJM Current Environment.
	PJM Current Environment settings can be read using the @PJM INQUIRE command.
Modified Print Environment (Printer-Language Specific)	Active as soon as printer receives any printer language commands (such as PCL or PostScript commands). This environment contains all of the feature settings currently in effect at any point after a printer language is entered.
	Printer language resets (such as the <ESC>E command in PCL), any printer language switch, or the @PJM ENTER command load the PJM Current Environment into the Modified Print Environment.
	Stored in RAM—can be changed using printer language commands (PCL, PostScript, and others). The printer language values override any PJM Current Environment feature for the duration of the printer language job (until the printer language is changed or a printer language-specific reset is executed).
	The Modified Print Environment settings can be read if the active printer language supports this capability.

PJL Reset Conditions

“PJL reset conditions” are listed below. Note that *PJL reset conditions* differ from *printer language resets* (such as <ESC>E). Printer language resets load the PJL Current Environment values into the Modified Print Environment. PJL reset conditions are more powerful. They load the User Default values into the PJL Current Environment, and also into the Modified Print Environment.

In this document, the term *PJL reset condition* refers to any of the following events:

- Power-on
- UEL command (when not between a JOB and EOJ command pair)
- @PJL INITIALIZE command
- @PJL RESET command
- @PJL JOB or EOJ command
- Control panel reset
- Other printer-specific events (see Appendix A for information about job boundaries)

Key Points to Remember About Environments

When using PJJ to set the printer to a desired state, remember the following points.

- At the beginning of a PJJ job, the current feature settings are the same as the control panel values or those features set with the DEFAULT command.
- When a printer language is entered, the current feature settings (Modified Print Environment) become the same as the PJJ Current Environment. From this starting point, the printer language commands modify the feature settings. Printer language commands override all other settings.
- The PJJ Current Environment settings can be changed using the SET command. These settings take effect until the next PJJ reset condition.
- The control panel settings (User Default Environment) can be changed using the control panel or the DEFAULT command. In printers without a control panel, the default settings are modified with only the DEFAULT command.
- The Modified Print Environment settings are changed using printer language commands. These settings take effect for the duration of the printer language job. After a printer language-specific reset, such as <ESC>E for PCL, the PJJ Current Environment feature settings are loaded into the Modified Print Environment.
- If the SET command is used in a PJJ job, always use the PJJ RESET command after the job is completed.

PJL Environment Variables

This section lists the PJL environment variables. General PJL environment variables (those not printer language-specific) are listed first, followed by printer language-specific variables. For most variables except the read-only variables, value settings can be modified using the following commands:

- **@PJL SET**—sets PJL Current Environment settings that remain active until the next PJL reset condition.
- **@PJL RESET**—the PJL RESET command defaults the PJL Current Environment to the User Default Environment (feature settings set with the DEFAULT command or the control panel keys).
- **@PJL DEFAULT**—modifies the User Default settings (stored in NVRAM in those printers containing NVRAM).
- **@PJL INITIALIZE**—defaults all environments to the Factory Default settings.

You can request value settings for printer features using the following two commands:

- **@PJL INQUIRE**—requests the PJL Current Environment settings.
- **@PJL DINQUIRE**—requests the User Default (control panel) settings.

(The INQUIRE and DINQUIRE commands are discussed in Chapter 7.)

Note



Whenever possible, use printer language commands to set printer features. Use PJL commands only when there are no printer language commands available for a desired feature.

When setting printer features with PJL, use the SET and RESET commands if you want to affect the current PJL job only. Using the DEFAULT and INITIALIZE commands affects the current job *and* succeeding jobs (these commands should only be used when you require a command that affects more than just the current job).

General PJP Environment Variables

The following table lists the PJP environment variables that are not printer language-specific. When you use these variables, do not use the LPARM : *personality* option. The range of values for each variable may differ for the various HP LaserJet printer models. Appendix A lists the environment variables and indicates which printers support each variable. Another method of obtaining a list of valid variables and the range of values for each variable is to send the @PJP INFO VARIABLES command to request this information directly from the printer. See the INFO command section later in this chapter for more information (@PJP INFO VARIABLES). You can find valuable information about environment variables in the control panel sections of the user's manual for each LaserJet printer.



Some environment variables can be modified using the DEFAULT command but not the SET command, some can be SET but not modified using DEFAULT, and some are read only variables. Appendix A lists environment variables, including read only variables, for all of the PJP printers.

General PJP Environment Variables		
Variable	Description	Sample Value Range
AUTOCONT	Returns the configuration for the auto continue feature.	ON, OFF
BINDING	Sets the default relationship of the front and back images on pages printed in duplex.	LONGEDGE, SHORTEGE

General PJI Environment Variables		
Variable	Description	Sample Value Range
CLEARABLE-WARNINGS	Returns the configuration for displaying clearable warnings. (Clearable warnings are those non-fatal error messages cleared by pressing the Continue key.) If the value is set to JOB, then clearable warnings generated by a job are displayed only until the start of the next job. If the value is set to ON, then clearable warnings are displayed until the user acknowledges them by pressing the Continue key. The factory default value is ON.	JOB, ON
COPIES	Number of uncollated copies for each page of the job.	1 to 999
CPLOCK	Default control panel lockout state. If CPLOCK is set to ON, users cannot modify feature settings using the control panel keys.	ON, OFF
DENSITY	Returns the toner density setting.	1 to 5
DUPLEX	Sets the default mode to enable/disable printing on both sides of the paper. OFF enables simplex and ON enables duplex printing.	ON, OFF
ECONOMODE	Default for the ECONOMODE toner-saving feature of the LaserJet 4 Plus, 4M Plus, 4L, 4ML, 4P, 4PJ, and 4MP printers.	ON, OFF
FORMLINES	Number of lines per page. This variable is tied to both the PAPER and ORIENTATION variables. If the value of either of those variables is changed, then the FORMLINES variable automatically is updated to maintain the same line spacing.	5 to 128

General PJI Environment Variables		
Variable	Description	Sample Value Range
IMAGEADAPT	Default for Image Adapt feature. ON enables Lossy compression for use on any images that need to have compression performed. AUTO causes the printer to evaluate other compression alternatives first before Lossy is considered. OFF disables use of Lossy compression.	ON, OFF, AUTO
INTRAY1	Returns the auto-selection lock status for the MP tray (LaserJet 4, 4M, 4 Plus, 4M Plus) or upper tray (LaserJet 4Si, 4SiMx).	LOCKED, UNLOCKED
INTRAY2	Returns the auto-selection lock status for the standard cassette (LaserJet 4, 4M, 4 Plus, 4M Plus) or lower cassette (LaserJet 4Si, 4SiMx).	LOCKED, UNLOCKED
INTRAY3	Returns the auto-selection lock status for the optional cassette (LaserJet 4, 4M, 4 Plus, 4M Plus) or envelope feeder (LaserJet 4Si, 4SiMx). INTRAY3 is a valid variable only if installed. If it is not installed, the printer returns "?" instead of LOCKED or UNLOCKED, indicating that the variable is unknown.	LOCKED, UNLOCKED
INTRAY1SIZE	Returns the size of the paper currently installed in the MP tray (LaserJet 4, 4M, 4 Plus, 4M Plus) or upper tray (LaserJet 4Si, 4SiMx).	LETTER, LEGAL, A4, EXECUTIVE, COM10, B5, MONARCH, C5, DL
INTRAY2SIZE	Returns the size of the paper currently installed in the standard cassette (LaserJet 4, 4M, 4 Plus, 4M Plus) or lower cassette (LaserJet 4Si, 4SiMx).	LETTER, LEGAL, A4, EXECUTIVE

General PJI Environment Variables		
Variable	Description	Sample Value Range
INTRAY3SIZE	Returns the size of the paper currently installed in the optional cassette (LaserJet 4, 4M, 4 Plus, 4M Plus) or envelope feeder (LaserJet 4Si, 4SiMx). INTRAY3SIZE is a valid variable only if currently installed. If it is not installed, the printer returns “?” instead of a paper size, indicating that the variable is unknown.	LETTER, LEGAL, A4, EXECUTIVE
INTRAY4SIZE	Returns the size of the paper currently installed in the envelope feeder. INTRAY4SIZE is a valid variable only if the envelope feeder currently is installed. If it is not installed, the printer returns “?” instead of an envelope size, indicating that the variable is unknown.	COM10, MONARCH, C5, DL, B5
IOBUFFER	Sets the value of the I/O buffering variable.	ON, OFF, AUTO
IOSIZE	Sets up the size, in Kbytes, of the configurable I/O buffers when IOBUFFER=ON. The size is set in increments of 10 Kbytes (up to 100 Kbytes, then in 100 Kbyte increments).	10 to maximum available memory
JOBOFFSET	Sets the default job offset state.	ON, OFF
LANG	Sets the default display language for the display panel and unsolicited status feedback display panel messages.	ENGLISH, FRENCH, GERMAN, ITALIAN, SPANISH, SWEDISH, DANISH, NORWEGIAN, DUTCH, FINNISH, PORTUGUESE, POLISH, TURKISH, JAPANESE

General PJI Environment Variables		
Variable	Description	Sample Value Range
LOWTONER	Returns the configuration for low-toner messages. If ON or CONTINUE, the printer remains online when the LOW TONER message is displayed; if OFF or STOP, the printer goes offline and waits until the On Line or Continue key is pressed.	ON, OFF, STOP, CONTINUE
MANUALFEED	Manual feed mode.	ON, OFF
MPTRAY	Returns the configuration value of the multi-purpose tray.	CASSETTE, MANUAL, FIRST
ORIENTATION	Page orientation.	PORTRAIT, LANDSCAPE
OUTBIN	Sets the default output tray. For the LaserJet 4Si/4SiMx printers, the UPPER output tray is a face-down, correct-order tray. The LOWER output tray is a face-up reverse-order output tray.	UPPER, LOWER

General PJI Environment Variables		
Variable	Description	Sample Value Range
PAGEPROTECT	Page protection configuration. The page protection feature reserves a block of printer memory to prevent printer overrun errors (error 21) when formatting very dense or complex images, especially HP-GL/2 images. This variable can be set to any legal value at any time, regardless of the current amount of free memory or the currently set resolution. When a job is sent, if there is not enough memory to print correctly with the current resolution and page protection configuration, the system temporarily overrides the resolution and/or page protect values to run the job. In these cases, the job may be printed at 300 dpi and without page protection. When the page protection status is changed, memory is reconfigured and all downloaded fonts, PCL macros, and PostScript dictionaries are lost (however, no I/O data is lost). Refer to “Commands that Affect Printer Memory” in Appendix A.	OFF, LETTER, LEGAL, A4, AUTO, ON
PAPER	Physical paper (and envelope) sizes. Letter, Legal, A4, Executive, and JISB5 are paper sizes; Com10, C5, DL, Monarch, and B5 are envelope sizes; JPOST and JPOSTD are Japanese postcard sizes; CUSTOM is for feeding different sizes, such as 3 x 5 cards and labels.	LETTER, LEGAL, A4, EXECUTIVE, COM10, C5, DL, MONARCH, B5, CUSTOM, JISB5, JPOST, JPOSTD
PASSWORD	Default password for PJI security.	0 to 65535

General PJL Environment Variables		
Variable	Description	Sample Value Range
PERSONALITY	<p>Personality for implicit switching (implicit switching refers to switching to the default personality without explicitly doing so with the @PJL ENTER command). Note that the value string (PCL, POSTSCRIPT, and so on) for each installed personality is defined by the personality itself. If the AUTO option is selected, and a job is sent without an ENTER LANGUAGE command, the printer looks for context clues to determine which personality takes effect. When the personality is changed, memory is reconfigured and all downloaded fonts, PCL macros, and PostScript dictionaries are lost (however, no I/O data is lost). Refer to “Commands that Affect Printer Memory” in Appendix A.</p> <p>For the LaserJet 4PJ, this variable is assigned on a per-port basis (see “Port-Specific Variables”).</p>	AUTO, PCL, POSTSCRIPT, ESCP
POWERSAVE	Enables or disables power-saving feature.	ON, OFF
POWER- SAVETIME	Sets the time (in minutes) the printer will remain idle before it enters powersave mode if powersave is on.	15, 30, 60, 120, 180
RESOLUTION	Print resolution in dots per inch. When a job is sent, if there is not enough memory to run with the current resolution and page protection configuration, the system temporarily overrides the resolution and/or page protect values to run the job. When the resolution is changed, memory is reconfigured and all downloaded fonts, PCL macros, and PostScript dictionaries are lost (however, no I/O data is lost). Refer to “Commands that Affect Printer Memory” in Appendix A.	300, 600

General PJI Environment Variables		
Variable	Description	Sample Value Range
RESOURCE- SAVE	Sets the value of the resource saving variable.	ON, OFF, AUTO
RESOURCE- SAVESIZE	(This variable is set as a personality-specific variable using LPARM : <i>personality</i> .) Sets the size of the resource saving area for the specified personality if RESOURCESAVE=ON.	0 to maximum available memory (in 100 Kbyte increments)
RET	Configuration of the Resolution Enhancement hardware. Resolution Enhancement technology (REt) improves the print quality of characters and graphics by smoothing the edges of lines. Most users do not need to adjust this feature since the default setting works well for almost every type of job.	LIGHT, MEDIUM, DARK, OFF
TIMEOUT	Duration of I/O timeouts in seconds. If the printer waits longer than the timeout value without receiving any data, it ends the print job and begins accepting data from other I/O ports, if any. In most cases, do not adjust this feature unless the printer times out during normal operation, in which case you can try extending the timeout duration. (See the “Timeouts” description in Appendix A.)	5 to 300

**Port-Specific
Variables
(LaserJet 4PJ Only)**

The following variable is I/O port-specific in the LaserJet 4PJ printer, and can be set and requested using PJJ. This variable must be set using the IPARM : *port* option. For the LaserJet 4PJ, the valid values for *port* are SERIAL and PARALLEL.

Port-Specific Variables		
Variables	Description	Sample Value Range
PERSONALITY	Personality for implicit switching (implicit switching refers to switching to the default personality without explicitly doing so with the @PJJ ENTER command). Note that the value string (PCL, ESCP, and so on) for each installed personality is defined by the personality itself. When the personality is changed, memory is reconfigured and all downloaded fonts and PCL macros are lost (however, no I/O data is lost). Refer to “Commands that Affect Printer Memory” in Appendix A.	PCL, ESCP

PCL-Specific Variables

The following variables are PCL-specific and can be set and requested using PJJ. These variables must be set using the LPARM : PCL option. A sample value range is shown in this table. See Appendix A for the actual value range for each PJJ printer, or use the @PJJ INFO VARIABLES command to request these values from the printer.

PCL-Specific Variables		
Variables	Description	Sample Value Range
FONTNUMBER	Font number. The valid range for this variable depends on the currently set font source. If the font source contains a default-marked font, the values start at 0; otherwise, the values start at 1. The upper limit depends on the number of installed fonts in the font source. For example, if there are 50 fonts in the font source and there is a default-marked font, the FONTNUMBER values range from 0 to 49. In the same situation without a default-marked font, the values range from 1 to 50. (continued on the following page)	0, 1, 2, . . . n

PCL-Specific Variables		
Variables	Description	Sample Value Range
FONTNUMBER (continued)	<p>If the value of the FONTSOURCE changes, then the FONTNUMBER variable automatically is changed to the lowest numbered font in the new font source (0 if the new font source contains a default-marked font; 1 if it does not). If the SYMSET variable changes, the FONTSOURCE and FONTNUMBER default to the highest priority default-marked font (lowest numbered font). Cartridges have the highest priority, then SIMMs, then internal default-marked fonts. NOTE: the recommended order for setting FONTNUMBER, FONTSOURCE, and SYMSET is SYMSET first, then FONTSOURCE, then FONTNUMBER.</p> <p>Also, if the currently set font source is S while the currently set font number is the highest-numbered soft font, and a soft font is deleted, the FONTSOURCE variable is changed to its factory default value, and the FONTNUMBER variable value is changed to the lowest numbered font in the new font source (0 or 1). The FONTNUMBER variable is tied to both the FONTSOURCE and SYMSET variables.</p>	0, 1, 2, . . . n

PCL-Specific Variables		
Variables	Description	Sample Value Range
FONTSOURCE	<p>The valid values for FONTSOURCE are:</p> <p>I (Internal Fonts) C, C1, C2 (Cartridge Fonts) S (Permanent Soft Fonts) M1, M2, M3, M4 (Fonts stored in one of the printer's four ROM SIMM slots)</p> <p>The valid values for this variable depend on the currently installed font base. If a font source is specified which does not contain any fonts, then the value is ignored, causing a PJJ 27001 error (if verbose unsolicited device status is enabled).</p> <p>Certain events automatically change the value of this variable. If the currently set font source is C, C1, or C2, and the cartridge is removed from the printer, then the value of this variable automatically is changed to the factory default value. If the currently set font source is S and all soft fonts are deleted, then the value of this variable automatically is changed to the factory default value. Also, if the currently set font source is S, while the currently set font number is the highest-numbered soft font, and any soft font is deleted, then the value of this variable automatically is changed to the factory default. NOTE: the recommended order for setting FONTNUMBER, FONTSOURCE, and SYMSET is SYMSET first, then FONT-SOURCE, then FONTNUMBER.</p>	I, M1, M2, M3, M4, C, C1, C2, S

PCL-Specific Variables		
Variables	Description	Sample Value Range
PITCH	Pitch of the default font in units of characters per inch (the default font must be a fixed-pitch scalable font). The pitch value can be specified to two decimal places.	0.44, 0.45, . . . 99.99
PTSIZE	Height of the default font in units of points (the default font must be a proportional scalable font). The point size is significant to a quarter of a point.	4.00, 4.25, . . . 999.75
SYMSET	Symbol set. (If the currently selected SYMSET is WIN3.1J [available in the HP LaserJet 4PJ only], then the default PCL text parsing method is set to Shift-JIS compatible parsing.)	ROMAN8, ISOL1, ISOL2, ISOL5, PC8, PC8DN, PC850, PC852, PC8TK, WINL1, WINL2, WINL5, DESKTOP, PSTEXT, VNINTL, VNUS, MSPUBL, MATH8, PSMATH, VNMATH, PIFONT, LEGAL, ISO4, ISO6, ISO11, ISO15, ISO17, ISO21, ISO60, ISO69, WIN30, WIN31J

PostScript-Specific Variables

The following table lists the currently defined PostScript-specific variables. These variables can be set using the LPARM : POSTSCRIPT option.

Variable	Description	Sample Value Range
JAMRECOVERY	Enables or disables the printing of jammed pages following a paper jam. The OFF setting boosts printer performance, but lost pages are not automatically printed after clearing the jam.	OFF, ON

Variable	Description	Sample Value Range
PRTPSERRS	This variable enables or disables the printing of a PostScript error page.	OFF, ON

ESC/P-Specific Variables (LaserJet 4PJ only) The following table lists the currently defined ESC/P-specific variables. These variables can be set using the LPARM : ESCP option. Note that the factory defaults for these variables are in parentheses.

Variable	Description	Sample Value Range
CARRIAGE-RETURN	Controls how ESC/P interprets the carriage return (CR) control character. The valid values for CARRIAGERETURN are: CR: CR maps to carriage return CRLF: CR maps to carriage return and linefeed.	(CR), CRLF
CHARACTER-SET	Default character set used for 1-byte printing. The valid values for CHARACTERSET are: KANA: Use katakana character set. EG: Use extended graphics character set.	(KANA), EG
TOPMARGIN	The valid values for TOPMARGIN are: TM19MM: sets top margin to 19 mm. TM6MM: sets top margin to 6 mm.	(TM19MM), TM6MM
ANKCONDENSE	Enables or disables whether alphanumeric/kana (ANK) characters are printed in condensed mode by default.	ON, (OFF)
FONT	Default font used when printing in Kanji mode.	(MSMINCHO), MSGOTHIC

Setting the Printer to a Desired State

At the beginning of each print job, printer features which affect the printed output must be set to a desired state to print the job as expected. This can be accomplished in two ways:

- If the printer has a control panel, the user sets the control panel to values that are appropriate for all users sharing the printer.
- For features that must be set on a job-by-job basis, use printer language commands. If a feature cannot be set with a printer language, use PJJ.

Applications that generate print data, such as word processors, spreadsheets, and graphics programs, should ensure that the printer is set to a desired state as follows (see Chapter 9 for a description of the various application types):

1. Send the UEL command (<ESC>%-12345X) to start PJJ and to default the print environment to the User Default Environment settings.
2. Use the @PJJ SET command to modify any currently defined environment variables that cannot be set using the desired printer language. For example, use PJJ to set variables such as RET or PAGE PROTECTION that cannot be set with a printer language; then use PCL or another printer language to set the remaining environment variables, such as orientation and number of copies.

Note



Do not set features that you do not enable users to set from your application. Any feature set by the application should enable the user to control that feature—this strategy prevents the user from being “locked out” of a particular feature.

3. Enter the desired printer language and use printer language commands to set all other environment variables to the desired settings.
4. If using a SET command to modify an environment variable, use a RESET command to return to its default state.

The following example demonstrates setting the HP LaserJet 4/4M printer to a known state.

**Example:
Setting the Printer
to a Desired State**

For the specific printer you are configuring, consider which environment features you can modify. The modifiable environment features for the LaserJet 4/4M printers are listed below (see Appendix A for a list of environment variables supported by each PJL printer):

COPIES	FORMLINES
PAPER	MANUALFEED
ORIENTATION	RET
PAGEPROTECT	PERSONALITY *
RESOLUTION	TIMEOUT *
FONTSOURCE	PTSIZE
FONTNUMBER	SYMSET
PITCH	PRTPSERRS
* PERSONALITY and TIMEOUT do not affect the printed output and generally should not be used.	

Of these LaserJet 4/4M features, only RET, PAGEPROTECT, and RESOLUTION affect the printed output and cannot be set using the printer language (in this case, PCL). These features are set using PJL, as the following lines show:

```
<ESC>%-12345X@PJL <CR><LF>
@PJL SET RET = MEDIUM <CR><LF>
@PJL SET PAGEPROTECT = OFF <CR><LF>
@PJL SET RESOLUTION = 300 <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . Use PCL to set copies, paper, orienta-
tion, line spacing, manual feed, and font selec-
tion- values not set using PJL <ESC>E
➡<ESC>%-12345X@PJL <CR><LF>
@PJL RESET <CR><LF>
<ESC>%-12345X
```

DEFAULT Command

The DEFAULT command sets the User Default Environment value for the specified environment variable. This value is stored in non-volatile RAM (if the printer has NVRAM) and is activated following a PJL reset condition. The DEFAULT command does not affect the current print environment, but takes effect when a PJL reset condition occurs. Use this command to change the default value for any environment setting.

For the LaserJet 4Si/4SiMx printer, the DEFAULT command will not take effect unless it is used within a secure job (a job that contains the correct password in the JOB command).

Note



In situations where the printer is shared by several users, such as networks, restrict the use of the DEFAULT command. This recommendation allows a standard print environment to be used and avoids having default features changed by different print jobs. Instead, if a printer feature must be changed from the default for a particular print job, use the SET command. In this way, jobs can be successfully printed in any order, since they are not affected by settings from previous jobs.

When the DEFAULT command is used to change the PAGEPROTECT or RESOLUTION status, the printer memory is reconfigured. Reconfiguring printer memory erases all downloaded fonts, PCL macros, and PostScript dictionaries, however no I/O data is lost. Refer to “Commands that Affect Printer Memory” in Appendix A.

Syntax:

```
@PJL DEFAULT [LPARM : personality |  
↳IPARM : port] variable = value [<CR>]<LF>
```

- **LPARM : *personality***—this optional parameter is used to set personality-specific environment variables. PCL is a valid personality. Other personalities, such as PostScript, can be added as hardware options. Use the @PJL INFO

CONFIG command to request the range of values for all personalities installed in a particular printer.

The LPARM : *personality* option must be used when setting personality-specific variables.

- **IPARM : *port*** — This optional parameter is used to set port-specific variables. The LaserJet 4PJ is the only printer which supports port-specific variables.

The IPARM : *port* option must be used when setting port-specific variables. Valid values for port for the LaserJet 4PJ printer are SERIAL and PARALLEL.

- ***variable = value***—this parameter sets one of the environment variables to the specified value. For example, the @PJM DEFAULT RESOLUTION = 600 command sets the default resolution to 600 dots per inch. See Appendix A for a list of variables and values for each printer. If you need a more detailed description of a particular variable, see the “Environment Variables” section earlier in this chapter.

Note 

The supported variables and range of values for each variable may not be the same in all HP LaserJet printer models. See Appendix A for a list of the variables and range of values for each PJL printer. You can also obtain valid variables and the range of values for each variable by sending the @PJM INFO VARIABLES command to request this information directly from the printer.

Parameters:

Parameter	Variable Names	
<i>personality</i>	PCL	Others (other personalities may be supported)
	POSTSCRIPT	
<i>port</i>	PARALLEL	Supported on LaserJet 4PJ only
	SERIAL	
<i>variable</i>	Valid variables for each printer are listed in Appendix A.	

Parameter	Variable Names
<i>value</i>	Appropriate values for each variable are also listed in Appendix A.

Comments: The DEFAULT command enables you to specify default values for either general variables, which are used by all personalities, or personality-specific variables. All personality-specific variables, such as the default PCL symbol set or the PostScript-specific variable PRTPSERRS, must be set using this option. Variables that are not personality-specific cannot be set using the LPARM : *personality* option.

All port-specific variables must be set using the IPARM: *port* option. Variables that are not port-specific cannot be set using the IPARM : *port* option.

Default values set with this command affect the printer control panel value and the feature setting stored in non-volatile RAM (in those printers that have a control panel and NVRAM). However, these values do not affect the print environment until a PJI reset condition occurs (see “PJI Reset Conditions” for a list of printer events that constitute a PJI reset). Consequently, if you want the default values to take effect immediately, send a PJI RESET command after sending the DEFAULT command(s).

A separate DEFAULT command must be sent for each environment variable you specify. The command may be used to set any environment variable except the read-only variables. See the “Environment Variables” section of this chapter for a description of each environment variable.

Example: This example sets page protection to LETTER for all personalities, and selects the PC8 symbol set for all PCL jobs. A PCL RESET command follows the DEFAULT commands so that the PCL Current Environment defaults to the new settings.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT User Defaults <CR><LF>  
@PJL DEFAULT PAGEPROTECT = LETTER <CR><LF>  
@PJL DEFAULT LPARM : PCL SYMSET = PC8 <CR><LF>  
@PJL RESET <CR><LF>  
<ESC>%-12345X
```

Related Commands: RESET, SET, JOB, EOJ, UEL

INITIALIZE Command

The INITIALIZE command resets the PJL Current Environment and the User Default Environment variables to their Factory Default values. This command does not affect the I/O configuration values, some of the configuration values, and the unsolicited status settings. Use the INITIALIZE command to set the printer environment values to their factory default state, such as when you move the printer to a new installation site. (This command is not intended for frequent use, since it resets most environments and control panel settings.)

For the LaserJet 4 Plus, 4M Plus, 4Si, and 4SiMx printers, the INITIALIZE command will not take effect unless it is used within a secure job (if a password is in use, a secure job is one that contains the correct password in the JOB command).

Note



In situations where the printer is shared by several users, such as networks, restrict the INITIALIZE command. This recommendation allows a standard print environment to be used and avoids having default features changed by different print jobs. In this way, jobs may be successfully printed in any order since they are not affected by settings from previous jobs.

Syntax: @PJL INITIALIZE [<CR>]<LF>

Parameters: The INITIALIZE command has no parameters.

Comments: The INITIALIZE command resets the following environment variables to their Factory Default values.

Note



Because personalities can be dynamically added to some HP LaserJet printers, these printers support more personality-specific variables than those listed here. In any case, the INITIALIZE command causes the PJL Current and User Default environment values for all personalities to default to their factory default state.

Variable Names	
BINDING	ORIENTATION
COPIES	OUTBIN
CPLOCK	PAGEPROTECT
DUPLEX	PAPER
ECONOMODE	PASSWORD
FORMLINES	PERSONALITY
IMAGEADAPT	RESOLUTION
JOBOFFSET	RET
MANUALFEED	TIMEOUT
PCL-Specific Variables	
FONTNUMBER	PTSIZE
FONTSOURCE	SYMSET
PITCH	
PostScript-Specific Variables	
JAMRECOVERY	PRTPSERRS

Note



The environment variables may vary with different HP LaserJet printer models. See Appendix A for a list of valid variables, or send the @PJL INFO VARIABLES command to request this information directly from the printer.

**Example:
Using the
INITIALIZE
Command**

This example initializes the printer:

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Initialize settings to <CR><LF>  
@PJL COMMENT factory defaults <CR><LF>  
@PJL INITIALIZE <CR><LF>  
<ESC>%-12345X
```

Related Commands: DEFAULT, RESET, SET

RESET Command

The PJP RESET command resets the PJP Current Environment variables to their User Default values. This command has the same effect on the PJP Current Environment as power-cycling the printer. Use this command at the end of PJP jobs that use the PJP SET command to set the printer back to its default state.

Syntax: @PJP RESET [<CR>] <LF>

Parameters: The RESET command has no parameters.

Comments: Any time an application such as a Spooler or Print Data Generator uses the SET command to set PJP variables, the application should conclude with the RESET command (before the closing UEL command) to return the variables to their previous state. (See Chapter 9 for more information about Spoolers and Print Data Generators.)

The RESET command resets the following environment variables to their user default values.

Note



Because personalities can be dynamically added to some HP LaserJet printers, those printers support more personality-specific variables than those listed here. In addition, the allowable variables and range of values for each variable may not be the same in all LaserJet printer models. To obtain valid variables and the range of values for each variable, send the @PJP INFO VARIABLES command to request this information directly from the printer. In any case, the RESET command causes the PJP Current Environment values for all personalities to default to the User Default values.

Variable Names	
BINDING	ORIENTATION
COPIES	OUTBIN
CPLOCK	PAGEPROTECT
DUPLEX	PAPER
ECONOMODE	PASSWORD
FORMLINES	PERSONALITY
IMAGEADAPT	RESOLUTION
JOBOFFSET	RET
MANUALFEED	TIMEOUT
PCL-Specific Variables	
FONTNUMBER	PTSIZE
FONTSOURCE	SYMSET
PITCH	
PostScript-Specific Variables	
JAMRECOVERY	PRTPSERRS

Example: The following example uses a PJL RESET command after the print job to return the features to their previous state:
Using the RESET Command

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Resets variables to <CR><LF>  
@PJL COMMENT control panel settings <CR><LF>  
@PJL SET RESOLUTION = 600 <CR><LF>  
@PJL SET RET = MEDIUM <CR><LF>  
@PJL ENTER LANGUAGE = PCL <CR><LF>  
<ESC>E . . . PCL job . . . <ESC>E  
➡<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Reset to return to <CR><LF>  
@PJL COMMENT control panel settings <CR><LF>  
@PJL RESET <CR><LF>  
<ESC>%-12345X
```

Related Commands: DEFAULT, INITIALIZE, SET

SET Command

The SET command enables you to change the value of PJJ Current Environment variables for the duration of a PJJ job, or until a PJJ reset condition defaults the value. Use this command to create a job-specific environment.

Note



When the SET command changes the PAGEPROTECT or RESOLUTION status, printer memory is reconfigured (except for printer memory in the LaserJet 4L printer). This erases all downloaded fonts, PCL macros, and PostScript dictionaries, however no I/O data is lost. Memory is not reconfigured unless the PAGEPROTECT or RESOLUTION status actually changes from its previous setting. When these settings are changed, performance is affected since all processed data is printed before memory reconfiguration occurs. (Refer to “Commands that Affect Printer Memory” in Appendix A.)

Syntax:

```
@PJJ SET [LPARM : personality | IPARM : port]  
variable = value [<CR>]<LF>
```

- **LPARM : *personality***—this optional parameter is used to set personality-specific environment variables. For example, you can use this option to set the PCL symbol set.

PCL is a valid personality; other personalities, such as PostScript, can be added into the printer as hardware options (cartridges or ROM SIMMs). Use the @PJJ INFO VARIABLES command to request the range of values for all personalities in a particular printer.

The LPARM : *personality* option must be used when setting personality-specific variables.

- **IPARM : *port*** — This optional parameter is used to set port-specific variables. The LaserJet 4PJ is the only printer which supports port-specific variables.

The IPARM : *port* option must be used when setting port-specific variables. Valid values for port for the LaserJet 4PJ printer are SERIAL and PARALLEL.

- ***variable = value***—this parameter sets one of the environment variables to the specified value. For example, the @PJL SET RESOLUTION = 600 command sets the current resolution to 600 dots per inch. See the table below for all valid variables and values. If you require a more detailed description of a particular variable, see the “Environment Variables” section earlier in this chapter.



The permissible environment variables and range of values for each variable may not be the same in all LaserJet printer models. See Appendix A for a list of valid variables and the range of values for each variable, or send the @PJL INFO VARIABLES command to request this information directly from the printer.

Parameters:

Parameter	Variable Names	
<i>personality</i>	PCL	Others (other personalities may be supported)
	POSTSCRIPT	
<i>port</i>	PARALLEL	Supported on LaserJet 4PJ only
	SERIAL	
<i>variable</i>	Valid variables for each printer are listed in Appendix A.	
<i>value</i>	Appropriate values for each variable are also listed in Appendix A.	

Comments: The SET command enables you to specify either general variables which are used by all personalities, or printer language-specific variables. Printer language-specific variables must be specified using the LPARM : *personality* option. Features that are not printer language-specific cannot be specified with the LPARM option.

All port-specific variables must be set using the IPARM : *port* option. Variables that are not port-specific cannot be set using the IPARM : *port* option.

Values modified with the SET command do not affect the User Default Environment values. Feature settings changed with the SET command are valid until the next PJL reset condition.

A separate SET command must be sent for each environment variable you specify. The command may be used to set any environment variable except CPLOCK, PASSWORD, and the read-only variables. See the “Environment Variables” section of this chapter for a discussion of each environment variable.



If the SET command is used in a job, use the RESET command after the job to reset features to the User Default (control panel) values. See the following example for a demonstration of how to use the RESET command to “clean up” after using SET.

**Example:
Using the
SET Command**

This example uses the SET command to create a desired state before sending a PostScript job. The SET command is used only to set those features that affect the printed output and that cannot be set using the desired personality. After the job has been sent, the RESET command is issued to return all features to their default values.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Setting PostScript Job <CR><LF>
@PJL COMMENT to Desired State <CR><LF>
@PJL SET RET = MEDIUM <CR><LF>
@PJL SET PAGEPROTECT = OFF <CR><LF>
@PJL SET RESOLUTION = 600 <CR><LF>
@PJL ENTER LANGUAGE = POSTSCRIPT <CR><LF>
%!PS-ADOBE ... PostScript print job- use POST-
SCRIPT code to set all values that are not set us-
ing PJL... ^D
␣<ESC>%-12345X@PJL <CR><LF>
@PJL RESET <CR><LF>
<ESC>%-12345X
```

Related Commands: DEFAULT, INITIALIZE, RESET, JOB, EOJ

Status Readback Commands

Introduction

PJL allows applications to request configuration and status information from the printer. The printer also can be programmed to send unsolicited status information to the application when printer events occur. For example, the printer can send status information indicating the printer door is open, toner is low, online/offline status, the text displayed on the control panel, and other pertinent information.

PJL status readback is especially useful during application development. Status readback enables you to determine that your application successfully changed feature settings to your specifications.

This chapter describes the requirements for using status readback, and explains the following status readback commands:

- INQUIRE—requests the *current* value (PJL Current Environment) for a specified environment variable.
- DINQUIRE—requests the *default* value (User Default Environment) for a specified environment variable.
- ECHO—returns a comment to the host computer to synchronize status information.
- INFO—requests a specified category of printer information.
- USTATUS—allows the printer to send unsolicited status messages, including device, job, page, and timed status.
- USTATUSOFF—turns off all unsolicited status.

This chapter also explains job recovery.

Printer Status Requirements

To receive status information from the printer, the application must have program code that handles the status information sent from the printer.

Synchronizing Status Readback Responses

Status responses are directed to the printer's I/O port from which the request is received. When using status readback, applications must synchronize status messages to ensure that status responses are indeed the requested status. To clear any possible unread status responses requested by previous applications, upon starting up, an application should use the ECHO command as described in the ECHO command section later in this chapter.

If unsolicited status is enabled, applications should properly handle receiving unsolicited status responses at any time. In particular, be aware that applications may receive an unsolicited status response after requesting printer status information.

The application and printer must be in a printer environment that supports two-way communication between the application and the printer. Printer sharing devices, networks, and other printing system components may not support this bi-directional communication. (Refer to “Using Status Readback in a Multi-User System” in Chapter 9.)

Format of Status Readback Responses

When PjL sends printer status information to the host, the response is in a readable ASCII format that always begins with the @PjL prefix and ends with a <FF> character. For example, the readback response for the @PjL INQUIRE command is:

```
@PjL INQUIRE [LPARM:personality | IPARM:port]  
↳variable<CR><LF>  
value<CR><LF>  
<FF>
```

Your application should be able to read all the data between the “@PjL” header and the <FF> control code.

Lines within the PjL status response begin with a specific keyword, as described in the command descriptions in this chapter, and end with the <CR><LF> control codes. Future printers may support new keywords in the PjL status response. Your application should ignore those lines which it does not understand.

The format of the printer response for each status readback command is described in the command descriptions.

INQUIRE Command

The INQUIRE command is used to obtain the current value of a specified PJI environment variable, including read-only variables. Use the INQUIRE command to find out the setting for a particular PJI feature, such as ORIENTATION.

Syntax: @PJI INQUIRE [LPARM : *personality* |
↳IPARM : *port*] variable [<CR>]<LF>

Response Syntax: @PJI INQUIRE [LPARM:*personality* |
↳IPARM:*port*] variable <CR><LF>
value <CR><LF>
<FF>

- **LPARM : *personality***—this optional parameter is used to inquire about printer language-specific environment variables. For example, you can use this option to request the current PCL symbol set stored in the PJI Current Environment.

PCL is a valid personality. Other personalities, such as POSTSCRIPT, can be added as hardware options. Use the @PJI INFO CONFIG command to request the personalities installed in a particular printer.
- **IPARM : *port*** — This optional parameter is used to set port-specific variables. The LaserJet 4PJ is the only printer which supports port-specific variables.

The IPARM : *port* option must be used when setting port—specific variables. Valid values for port for the LaserJet 4PJ printer are SERIAL and PARALLEL.
- ***variable***—this parameter specifies the environment variable you want. For example, the @PJI INQUIRE RET command requests the current value of the Resolution Enhancement technology feature. See Appendix A for a list of valid variables for each printer. If you require a more detailed description of a particular variable, see the “Environment Variables” section in Chapter 6.

Note

The permissible variables and range of values for each variable may not be the same in all LaserJet printer models. See Appendix A for a list of valid variables, or send the @PJJ INFO VARIABLES command to request this information directly from the printer.

- **value**—this parameter is the returned value of the requested variable. For example, if you send the @PJJ INQUIRE COPIES command, and the PJJ Current Environment setting is 65, the returned value is 65, indicating 65 copies. See Appendix A for variable names for each parameter.

Parameters:

Parameter	Variable Names	
<i>personality</i>	PCL	Others (other personalities may be supported)
	POSTSCRIPT	
<i>port</i>	PARALLEL	Supported on LaserJet 4PJ only
	SERIAL	
<i>variable</i>	Valid variables for each printer are listed in Appendix A.	
<i>value</i>	Acceptable values for each variable are also listed in Appendix A.	

Comments:

If your application has status readback capabilities, you can request the current setting of any valid environment variable. Since the INQUIRE command returns only the value for one feature, you can send multiple INQUIRE commands to request information about more than one feature. If you need information about many variables, the PJJ INFO VARIABLES command returns the PJJ Current Environment settings for all environment variables.

If the printer does not support the variable, the response is:

```
@PJL INQUIRE [LPARM:personality | IPARM:port]  
↳variable <CR><LF>  
"?" <CR><LF>  
<FF>
```

If a printer language-specific variable is not available because that printer language is not installed, or if a port-specific variable is not available because that port is not supported, the command is ignored and there is no response.

Note



The LPARM : *personality* option must be used when requesting printer language-specific information.

The IPARM : *port* option must be used when requesting port-specific information.

**Example:
Using INQUIRE to
Request Feature
Settings**

This example requests the current print environment settings for RET, PAGEPROTECT, RESOLUTION, PERSONALITY, and TIMEOUT. The printer response for this example is listed below.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT ***Inquiring About <CR><LF>  
@PJL COMMENT Environment Settings*** <CR><LF>  
@PJL ECHO 02:18:23.9 05-30-92 <CR><LF>  
@PJL INQUIRE RET <CR><LF>  
@PJL INQUIRE PAGEPROTECT <CR><LF>  
@PJL INQUIRE RESOLUTION <CR><LF>  
@PJL INQUIRE PERSONALITY <CR><LF>  
@PJL INQUIRE TIMEOUT <CR><LF>  
<ESC>%-12345X
```

For a LaserJet 4 printer, a sample printer response for this example is as follows. Other PJJ printers may respond differently.

```
@PJM ECHO 02:18:23.9 05-30-92<CR><LF>
<FF>
@PJM INQUIRE RET<CR><LF>
MEDIUM<CR><LF>
<FF>
@PJM INQUIRE PAGEPROTECT<CR><LF>
OFF<CR><LF>
<FF>
@PJM INQUIRE RESOLUTION<CR><LF>
600<CR><LF>
<FF>
@PJM INQUIRE PERSONALITY<CR><LF>
AUTO<CR><LF>
<FF>
@PJM INQUIRE TIMEOUT<CR><LF>
15<CR><LF>
<FF>
```

**Example:
Using INQUIRE
for Printer Language-
Specific Variables**

This example requests the PCL settings for pitch, point size, and symbol set.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Requesting PCL Settings <CR><LF>  
@PJL ECHO 12:22:23.9 11-05-92 <CR><LF>  
@PJL INQUIRE LPARM : PCL PITCH <CR><LF>  
@PJL INQUIRE LPARM : PCL PTSIZE <CR><LF>  
@PJL INQUIRE LPARM : PCL SYMSET <CR><LF>  
<ESC>%-12345X
```

For the LaserJet 4 printer, the response for this example is shown below. Other PJL printers may respond differently.

```
@PJL ECHO 12:22:23.9 11-05-92<CR><LF>  
<FF>  
@PJL INQUIRE LPARM:PCL PITCH<CR><LF>  
10.00<CR><LF>  
<FF>  
@PJL INQUIRE LPARM:PCL PTSIZE<CR><LF>  
12.00<CR><LF>  
<FF>  
@PJL INQUIRE LPARM:PCL SYMSET<CR><LF>  
ROMAN8<CR><LF>  
<FF>
```

Related Commands: DINQUIRE, ECHO, INFO, SET, DEFAULT, USTATUS

DINQUIRE Command

The DINQUIRE command is used to obtain the default value of a specified PJL environment variable. Use the DINQUIRE command to find the User Default Environment setting for any environment variable, including read-only variables.

Syntax: @PJL DINQUIRE [LPARM : *personality* |
↳IPARM : *port*] *variable* [<CR>]<LF>

Response Syntax: @PJL DINQUIRE [LPARM:*personality* |
↳IPARM:*port*] *variable* <CR><LF>
value<CR><LF>
<FF>

- **LPARM : *personality***—this optional parameter is used to inquire about printer language-specific environment variables. For example, you can use this option to request the default PCL pitch setting.

In addition to PCL, other personalities such as POSTSCRIPT may be added later. Use the @PJL INFO CONFIG command to request all of the personalities installed in a particular printer.

- **IPARM : *port***— This optional parameter is used to set port-specific variables. The LaserJet 4PJ is the only printer which supports port-specific variables.

The IPARM : *port* option must be used when setting port-specific variables. Valid values for port for the LaserJet 4PJ printer are SERIAL and PARALLEL.

- ***variable***—this parameter specifies the environment variable about which you are inquiring. For example, the @PJL DINQUIRE DENSITY command requests the default toner density setting. See Appendix A for a list of valid variables for each printer. If you require a more detailed description of a particular variable, see the “Environment Variables” section in Chapter 6.

Note

The supported variables and range of values for each variable may not be the same in all PJL printer models. See Appendix A for a list of valid variables for each printer, or send the @PJL INFO VARIABLES command to request this information directly from the printer.

- **value**—this parameter is the returned value of the requested variable. For example, if you sent the @PJL DINKQUIRE LOWTONER command, the returned value is either ON or OFF (or CONTINUE/STOP), indicating whether or not you want the printer to stay online when the toner is low. See Appendix A for valid variable values.

Parameters:

Parameter	Variable Names	
<i>personality</i>	PCL	Others (other personalities may be supported)
	POSTSCRIPT	
<i>port</i>	PARALLEL	Supported on LaserJet 4PJ only
	SERIAL	
<i>variable</i>	Valid variables for each printer are listed in Appendix A.	
<i>value</i>	Appropriate values for each variable are also listed in Appendix A.	

Comments: If your application has status readback capability, you can request the default setting of any valid environment variable. The returned value indicates the User Default Environment value for the feature. Since the DINQUIRE command returns only the value for one feature, you must send multiple DINQUIRE commands for data about more than one feature.

If the printer does not support the variable, the response is:

```
@PJL DINQUIRE [LPARM:personality | IPARM:port]  
↪variable <CR><LF>  
"?"<CR><LF>  
<FF>
```

If a printer language-specific variable is not available because that printer language is not installed, or if a port-specific variable is not available because that port is not supported, the command is ignored and there is no response.

Note



The LPARM : *personality* option must be used when requesting printer language-specific information.

The IPARM : *port* option must be used when requesting port-specific information.

**Example:
Using DINQUIRE to
Request Feature
Settings**

This example requests the default settings for resolution and personality. The printer returns values of 600 and AUTO.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Inquiring Default Settings  
↵<CR><LF>  
@PJL ECHO 08:10:33.7 04-17-93 <CR><LF>  
@PJL DINQUIRE RESOLUTION <CR><LF>  
@PJL DINQUIRE PERSONALITY <CR><LF>  
<ESC>%-12345X
```

For the LaserJet 4 printer, a sample response for this example is as follows. Responses from other PJJ printers may vary.

```
@PJL ECHO 08:10:33.7 04-17-93<CR><LF>  
<FF>  
@PJL DINQUIRE RESOLUTION<CR><LF>  
600<CR><LF>  
<FF>  
@PJL DINQUIRE PERSONALITY<CR><LF>  
AUTO<CR><LF>  
<FF>
```

**Example:
Using DINQUIRE for
Printer Language-
Specific Variables**

This example requests the default PCL pitch and symbol set using the DINQUIRE command. The printer returns values of 10.00 and ROMAN8.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Inquiring Default PCL Settings  
↵<CR><LF>  
@PJL ECHO 11:03:05.9 07-04-92 <CR><LF>  
@PJL DINQUIRE LPARM : PCL PITCH <CR><LF>  
@PJL DINQUIRE LPARM : PCL SYMSET <CR><LF>  
<ESC>%-12345X
```

A sample LaserJet 4 printer response for this example is as follows. Other PJL printer responses may vary.

```
@PJL ECHO 11:03:05.9 07-04-92<CR><LF>  
<FF>  
@PJL DINQUIRE LPARM:PCL PITCH<CR><LF>  
10.00<CR><LF>  
<FF>  
@PJL DINQUIRE LPARM:PCL SYMSET<CR><LF>  
ROMAN8<CR><LF>  
<FF>
```

Related Commands: INQUIRE, ECHO, INFO, SET, DEFAULT, USTATUS

ECHO Command

The ECHO command prompts the printer to return a specified message to the host computer. Use the ECHO command to synchronize the printer with the host computer to ensure that the status received is the requested status information.

Syntax: @PJL ECHO [<words>] [<CR>]<LF>

Response Syntax: @PJL ECHO [<words>] <CR><LF>
<FF>

Parameters:

Parameter	Functional Range	Default
<words>	ASCII 33 thru 255, <SP>, <HT>	N/A

- **<words>** — The <words> parameter must begin with a printable character, and can contain any character from ASCII 33 through 255, in addition to space characters and horizontal tabs. The <words> parameter is not a string variable, and therefore need not be enclosed in quotation marks. The parameter should be unique, such as the time indicated by the real time clock at the moment the ECHO command is issued. A unique message eliminates the possibility of duplicate messages being echoed by different applications. The maximum length for <words> is 80 bytes.

Comments: In a multi-user environment, the printer may respond to many different status requests. Since the status messages are buffered in the printer until they are received, the current application may receive status messages that were requested by a previous application. (This happens in situations where the application requests information, or unsolicited status is enabled, and the application closes before receiving the status messages.)

Use the ECHO command to synchronize status so that you know the status you are receiving is the requested status. To do this, send an ECHO command to the printer, and then dis-

card the incoming status messages until your message is echoed back. Eliminate all data received from the printer up to the echoed response string. For the remainder of your print job, you can be sure that all status messages you receive after your echoed message were requested by your application. If you turned on USTATUS, you may receive unsolicited status information at any time.

**Example:
Using the
ECHO Command**

This example sends the `Testing 68394 10:57:06.4` message using the ECHO command. After the application receives the `Testing 68394` response, all succeeding solicited messages received during the current job are those requested by the current application.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Using the ECHO command <CR><LF>  
@PJL ECHO Testing 68394 10:57:06.4 <CR><LF>  
<ESC>%-12345X
```

A sample LaserJet 4 printer response for this example is shown below. Other PJJ printers may have different responses.

```
@PJL ECHO Testing 68394 10:57:06.4<CR><LF>  
<FF>
```

Related Commands: INQUIRE, DINQUIRE, INFO, SET, DEFAULT, USTATUS

INFO Command

The INFO command is used to request a specified category of information (see the table below). Use this command to find the printer model, printer configuration, memory available, page count, status information, and a list of the printer variables, including environmental, printer language-dependent, and unsolicited status variables.

Syntax: @PJL INFO *category* [<CR>]<LF>

Response Syntax: @PJL INFO *category*<CR><LF>
[1 or more lines of printable characters or <WS>
followed by <CR><LF>]
<FF>

Parameters:


Category	Description
ID	Provides the printer model number, such as "LaserJet 4."
CONFIG	Provides configuration information, such as how many and which paper sizes are available in this printer.
MEMORY	Identifies the amount of memory available.
PAGECOUNT	Returns the number of pages printed by the print engine.
STATUS	Provides the current printer status.
VARIABLES	Lists environmental and printer language-dependent variables, the possible variable values, and the current variable settings.
USTATUS	Lists the unsolicited status variables provided by the printer, the possible variable values, and the current variable settings.

Comments: When the printer receives the INFO command, it returns the requested information. Only one *category* can be used for each INFO command. Each category is described below, with the format of the printer's response. If the printer does not support the specified category, the returned information is as follows:

```
@PJL INFO category <CR><LF>
"?" <CR><LF>
<FF>
```

ID Category The @PJL INFO ID command provides a way to identify the type of printer used. For the LaserJet 4 printer, the @PJL INFO ID command prompts the printer to return the following response:

```
@PJL INFO ID<CR><LF>
"LASERJET 4" <CR><LF>
<FF>
```

Note  To maintain compatibility with future printers, applications should not use the @PJL INFO ID command to identify printer features. Instead, the more detailed @PJL INFO CONFIG command should be used (see the following discussion on "The CONFIG Category").

Some printers, such as the HP LaserJet 4ML printer, return "HP" in front of the model name, for example:

```
@PJL INFO ID<CR><LF>
"HP LASERJET 4ML" <CR><LF>
<FF>
```

CONFIG Category

The @PJL INFO CONFIG command returns a series of lines listing configuration information. Use this command to request information such as which printer languages are installed, how many input and output trays are installed, and how many font cartridge slots are in the printer.

Variables appear in the response only if they are installed in the printer. For example, if a LaserJet 4 printer does not have the lower paper cassette installed, the INTRAY3 option is not returned in the response.

The general format of the returned information is:

```
@PJL INFO CONFIG<CR><LF>
feature[=value][<value> feature information]<CR><LF>
[<HT>returned option[ attribute]<CR><LF>]
. . .
. . .
feature[=value][<value> feature information]<CR><LF>
[<HT>returned option[ attribute]<CR><LF>]
<FF>
```

The returned information can list multiple features, with the format of the feature information enclosed in brackets. For “[<value> feature information]”, the square brackets ([]) in the format indicate an optional item as well as indicating that brackets enclose the feature information. For example, [4 ENUMERATED] indicates there are 4 returned options for the feature. Refer to the sample printer response in the “Using the @PJL INFO CONFIG Command” example for the format of an actual response.

Parameter	Format	Description
<i>feature</i>	alphanumeric value (any combination of letters [ASCII 65-90 or 97-122] and/or digits [ASCII 48-57], beginning with a letter)	Name of a printer feature, such as DUPLEX or FONT CARTRIDGE SLOTS.
<i>value</i>	numeric value	Indicates a feature value, such as MEMORY=500000, or how many and what type of options follow, such as [2 ENUMERATED].
<i>feature information</i>	one or more alphanumeric values, separated by spaces	Indicates what type of information follows, such as RANGE, TABLE ENUMERATED, or READONLY.
<i>returned option</i>	alphanumeric or numeric value, or string	An option of a feature listed in the returned data, such as TIMED, describing a type of USTATUS.
<i>attribute</i>	alphanumeric or numeric value, or string	Adds more information about a particular returned option, such as INTRAY1 MP, indicating that tray 1 is a multipurpose (MP) tray.

**Example:
Using the
@PJL INFO CONFIG
Command**

This example requests the current configuration information. The printer, a LaserJet 4 printer in this case, responds with a list of features. For example, the returned information shows there is an envelope tray and three input trays: IN-TRAY1 MP, the multi-purpose tray, INTRAY2 PC, the paper cassette tray, and INTRAY3 LC, the optional lower cassette tray. Other configuration information also is listed, including the total amount of installed memory available and the number of display lines and characters.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Using @PJL INFO CONFIG <CR><LF>
@PJL ECHO 09:51:48.3 12-24-92 <CR><LF>
@PJL INFO CONFIG <CR><LF>
<ESC>%-12345X
```

A sample LaserJet 4 printer response for this example is shown below. Other printers may respond differently.

```
@PJL ECHO 09:51:48.3 12-24-92<CR><LF>
<FF>
@PJL INFO CONFIG<CR><LF>
IN TRAYS [3 ENUMERATED]<CR><LF>
    INTRAY1 MP<CR><LF>
    INTRAY2 PC<CR><LF>
    INTRAY3 LC<CR><LF>
ENVELOPE TRAY<CR><LF>
OUT TRAYS [1 ENUMERATED]<CR><LF>
    NORMAL FACEDOWN<CR><LF>
PAPERS [9 ENUMERATED]<CR><LF>
    LETTER<CR><LF>
    LEGAL<CR><LF>
    A4<CR><LF>
    EXECUTIVE<CR><LF>
    MONARCH<CR><LF>
    COM10<CR><LF>
    DL<CR><LF>
    C5<CR><LF>
    B5<CR><LF>
LANGUAGES [2 ENUMERATED]<CR><LF>
    PCL<CR><LF>
    POSTSCRIPT<CR><LF>
USTATUS [4 ENUMERATED]<CR><LF>
    DEVICE<CR><LF>
    JOB<CR><LF>
    PAGE<CR><LF>
    TIMED<CR><LF>
FONT CARTRIDGE SLOTS [1 ENUMERATED]<CR><LF>
    CARTRIDGE<CR><LF>
MEMORY=2097152<CR><LF>
DISPLAY LINES=1<CR><LF>
DISPLAY CHARACTER SIZE=16<CR><LF>
<FF>
```

MEMORY Category

The @PJL INFO MEMORY command returns the total number of bytes of free memory space and the largest free memory block.



To determine the amount of memory available for a particular personality, use the personality command instead of the @PJL INFO MEMORY command. For example, to find the amount of memory available for PCL 5, use the Free Space command (<ESC>*s1M). See the *PCL 5 Printer Language Technical Reference Manual* for more information about PCL status readback.

Example: Using the @PJL INFO MEMORY Command

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Using @PJL INFO MEMORY <CR><LF>
@PJL ECHO 14:51:48.3 12-18-92 <CR><LF>
@PJL INFO MEMORY <CR><LF>
<ESC>%-12345X
```

A sample LaserJet 4 printer response for this example is shown below. Other printers may respond differently.

```
@PJL ECHO 14:51:48.3 12-18-92<CR><LF>
<FF>
@PJL INFO MEMORY<CR><LF>
TOTAL=1494416<CR><LF>
LARGEST=1494176<CR><LF>
<FF>
```

PAGECOUNT
Category

The @PJL INFO PAGECOUNT returns the number of pages printed by the current print engine. This returned number is an indication of printer usage.

Example:
Using the
@PJL INFO PAGE-
COUNT
Command

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Using PJL INFO PAGECOUNT <CR><LF>  
@PJL ECHO 06:53:29.3 1-25-93 <CR><LF>  
@PJL INFO PAGECOUNT <CR><LF>  
<ESC>%-12345X
```

A sample LaserJet 4ML printer response for this example is shown here.

```
@PJL INFO PAGECOUNT<CR><LF>  
PAGECOUNT=183933<CR><LF>  
<FF>
```

STATUS Category

The @PJL INFO STATUS command returns online status (TRUE=online, FALSE=offline), the message currently displayed on the control panel, and a status code. In the following example, the status code is 10001, which means the printer is ready. (See Appendix D for a list of all printer status codes.)

The “string” portion of the “DISPLAY =” status message is localized; the same message as that displayed on the control panel appears in whichever language is used.

Example: Using the @PJL INFO STATUS Command

This example requests status information. The printer, in this case a LaserJet 4 printer, returns a status code (10001), the message displayed on the control panel (00 READY), and the online status (ONLINE=TRUE).

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Using @PJL INFO STATUS <CR><LF>  
@PJL ECHO 17:45:22.5 05-17-92 <CR><LF>  
@PJL INFO STATUS <CR><LF>  
<ESC>%-12345X
```

A sample LaserJet 4 printer response for this example is shown here. Other PJL printers may produce a different response.

```
@PJL ECHO 17:45:22.5 05-17-92<CR><LF>  
<FF>  
@PJL INFO STATUS<CR><LF>  
CODE=10001<CR><LF>  
DISPLAY="00 READY"<CR><LF>  
ONLINE=TRUE<CR><LF>  
<FF>
```

VARIABLES Category

The @PJL INFO VARIABLES command returns a list of the environment and printer language-dependent variables. Use this command to find a list of the variables, the current setting for each, and the possible values.

The set of printer language-specific variables returned by the printer depends on the current environment and the printer languages installed. Each add-on printer language has its own specific variables. Printer language-specific variables are always indicated by LPARM:*personality* in the response. Port-specific variables (LaserJet 4PJ only) are always indicated by IPARM:*port* in the response.

One portion of the returned information is a list of font sources (see the following example). This list varies depending on which font sources, such as ROM SIMMs and cartridges, are installed. Only those font sources which are installed and contain valid fonts appear on the list. For example, the **S** option appears only if one or more permanent soft fonts currently exist.

The FONTNUMBER range lists the range of fonts for the current font source only. The lower limit is 0 if the current font source contains a default-marked font; otherwise the lower limit is 1. The upper range limit varies depending on how many fonts are in the current font source.

Note



For information about any of the environment variables listed by the @PJL INFO VARIABLES command, see the “Environment Variables” section in Chapter 6.

**Example:
Using the
@PJL INFO
VARIABLES
Command**

This example uses the INFO VARIABLES command to obtain a list of the environment variables. The returned information lists the environment variables, the current setting, and the value or range of values for each. For example, the RESOLUTION section indicates the current setting is 600, and that there are two possible choices: 300 and 600.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL COMMENT Using the @PJL INFO <CR><LF>  
@PJL COMMENT VARIABLES Command <CR><LF>  
@PJL ECHO 07:22:03.8 12-03-92 <CR><LF>  
@PJL INFO VARIABLES <CR><LF>  
<ESC>%-12345X
```

A sample LaserJet 4 printer response for this example is shown below. Other PJJ printers may provide a somewhat different response:

```
@PJL ECHO 07:22:03.8 12-03-92<CR><LF>  
<FF>  
@PJL INFO VARIABLES  
COPIES=1 [2 RANGE]  
    1  
    999  
PAPER=LETTER [9 ENUMERATED]  
    LETTER  
    LEGAL  
    A4  
    . . .  
    B5  
ORIENTATION=PORTRAIT [2 ENUMERATED]  
    PORTRAIT  
    LANDSCAPE  
FORMLINES=60 [2 RANGE]  
    5  
    128  
MANUALFEED=OFF [2 ENUMERATED]  
    OFF  
    ON
```

```
RET=MEDIUM [ 4 ENUMERATED ]
    OFF
    LIGHT
    MEDIUM
    DARK
PAGEPROTECT=OFF [ 4 ENUMERATED ]
    OFF
    LETTER
    LEGAL
    A4
RESOLUTION=600 [ 2 ENUMERATED ]
    300
    600
PERSONALITY=AUTO [ 3 ENUMERATED ]
    AUTO
    PCL
    POSTSCRIPT
TIMEOUT=15 [ 2 RANGE ]
    5
    300
MPTRAY=CASSETTE [ 3 ENUMERATED ]
    MANUAL
    CASSETTE
    FIRST
INTRAY1=UNLOCKED [ 2 ENUMERATED ]
    UNLOCKED
    LOCKED
INTRAY2=UNLOCKED [ 2 ENUMERATED ]
    UNLOCKED
    LOCKED
INTRAY3=UNLOCKED [ 2 ENUMERATED ]
    UNLOCKED
    LOCKED
CLEARABLEWARNINGS=ON [ 2 ENUMERATED READONLY ]
    JOB
    ON
AUTOCONT=OFF [ 2 ENUMERATED READONLY ]
    OFF
    ON
```

```
DENSITY=3 [2 RANGE READONLY]
  1
  5
LOWTONER=ON [2 ENUMERATED READONLY]
  OFF
  ON
INTRAY1SIZE=LETTER [9 ENUMERATED READONLY]
  LETTER
  LEGAL
  A4
  EXECUTIVE
  COM10
  MONARCH
  C5
  DL
  B5
INTRAY2SIZE=LETTER [4 ENUMERATED READONLY]
  LETTER
  LEGAL
  A4
  EXECUTIVE
INTRAY3SIZE=LETTER [4 ENUMERATED READONLY]
  LETTER
  LEGAL
  A4
  EXECUTIVE
INTRAY4SIZE=COM10 [5 ENUMERATED READONLY]
  COM10
  MONARCH
  C5
  DL
  B5
LPRM:PCL FONTSOURCE=I [1 ENUMERATED]
  I
LPRM:PCL FONTNUMBER=0 [2 RANGE]
  0
  50
LPRM:PCL PITCH=10.00 [2 RANGE]
  0.44
  99.99
```

```

LPARM:PCL PTSIZE=12.00 [ 2 RANGE ]
    4.00
    999.75
LPARM:PCL SYMSET=ROMAN8 [ 31 ENUMERATED ]
    ROMAN8
    ISOL1
    ISOL2
    . . .
    . . .
    WIN30
LPARM:POSTSCRIPT PRTPSERRS=OFF [ 2 ENUMERATED ]
    OFF
    ON
<FF>

```

USTATUS Category

The @PJL INFO USTATUS command lists each type of unsolicited status supported by the printer, such as DEVICE, JOB, PAGE, and TIMED (see the “USTATUS Command” discussion on the next page for information about unsolicited status). The listing also contains the current setting and the possible values for each type of status. For more information concerning the different types of unsolicited status, see the “USTATUS Command” section later in this chapter.

Example: Using the @PJL INFO USTATUS Command

This example requests information about the unsolicited status variables. These are variables that can be used in the USTATUS command. In this example, the LaserJet 4 printer replies that there are 4 unsolicited status types: DEVICE, JOB, PAGE, and TIMED. The current setting for each type of unsolicited status is given, along with the possible variable values (for instance, OFF, ON, and VERBOSE for device status).

```

<ESC>%-12345X@PJL <CR><LF>
@PJL ECHO 08:10:09.1 08-22-92 <CR><LF>
@PJL INFO USTATUS <CR><LF>
<ESC>%-12345X

```

A sample LaserJet 4 printer response for this example is shown below. Responses for other PJJ printers may vary.

```
@PJL ECHO 08:10:09.1 08-22-92<CR><LF>
<FF>
@PJL INFO USTATUS<CR><LF>
DEVICE=OFF [ 3 ENUMERATED ]<CR><LF>
    OFF<CR><LF>
    ON<CR><LF>
    VERBOSE<CR><LF>
JOB=OFF [ 2 ENUMERATED ]<CR><LF>
    OFF<CR><LF>
    ON<CR><LF>
PAGE=OFF [ 2 ENUMERATED ]<CR><LF>
    OFF<CR><LF>
    ON<CR><LF>
TIMED=0 [ 2 RANGE ]<CR><LF>
    5<CR><LF>
    300<CR><LF>
<FF>
```

Related Commands: INQUIRE, ECHO, SET, DEFAULT, USTATUS

USTATUS Command

The USTATUS command is used to enable or disable unsolicited printer status. Unlike the status information solicited by sending the INQUIRE, DINQUIRE, or INFO commands, unsolicited status is sent automatically when the status changes. Use the USTATUS command when you want to know:

- Device status changes (such as printer open, paper jams, and paper out conditions)
- Job status changes (when a JOB command is encountered or the job completely prints)
- Page status changes (when each printed page reaches the output tray)
- Timed status (periodic status report at a specified time interval)

Note 

Unlike solicited status, the USTATUS command does not have an immediate response. Instead, unsolicited status messages are sent only when the printer status changes.

Syntax: @PJL USTATUS *variable* = *value* [`<CR>`]`<LF>`

Status Message @PJL USTATUS *variable* `<CR>``<LF>`

Syntax: [1 or more lines of printable characters or `<WS>` followed by `<CR>``<LF>`]
`<FF>`

Parameters:

Variable	Value	Description
DEVICE	ON	Enables unsolicited device status for all status changes (see the “DEVICE Variable” description below)
	VERBOSE	Enables unsolicited device status for all status changes plus notification of all PJL parser warnings and errors. The VERBOSE value should only be used during application development.
	OFF	Disables unsolicited device status
JOB	ON	Enables unsolicited job status so that the printer sends a status message every time a job begins or ends
	OFF	Disables unsolicited job status

Variable	Value	Description
PAGE	ON	Enables unsolicited page status so that the printer sends a status message every time a page reaches the output tray
	OFF	Disables unsolicited page status
TIMED	5 to 300	Enables timed unsolicited status so that the printer automatically sends status at a specified time increment (in seconds)
	0	Turns TIMED USTATUS off

Comments: Unsolicited status allows you to automatically receive device, job, page, or timed status without requesting it. Each type of unsolicited status provides different information and is described on the following pages.

Some printer models may have more (or fewer) types of unsolicited status than DEVICE, JOB, PAGE, and TIMED. You can have the printer list the various types of unsolicited status by issuing the INFO USTATUS command. See “Example: Using the @PJM INFO USTATUS Command” for an example of this.

Unsolicited status, except for TIMED, can be turned off individually using the OFF parameter, such as in the @PJM USTATUS JOB=OFF command. TIMED status is turned off by setting it to zero. Alternatively, all unsolicited device status can be turned off using the USTATUSOFF command.

DEVICE Variable The @PJM USTATUS DEVICE = value command prompts the printer to send status messages when device changes occur. When DEVICE = ON, the printer sends status information for all changes to printer status. When DEVICE = VER-

BOSE, the printer also sends status information for all PJJ parser warnings and errors.

Part of the unsolicited status message sent to the host is a 5-digit code that indicates the status condition. The first 2 digits divide the status codes into different categories. The general status categories are listed in the following table. (This is only a general summary of the specified categories. The full status code listing is located in Appendix D.)

If there is a “DISPLAY=*string*” portion of the status message, the string is localized; the same message as that displayed on the control panel appears in whichever language is being used.

Status Category	Description
10 (10-000 to 10-999)	Informational messages which do not indicate errors, such as “Device was put online and is ready” or “device was put offline.”
11 (11-000 to 11-999)	These messages indicate background paper mount messages, which means one of the available paper input sources is empty, but another paper source is available and is loaded with the correct paper size. The printer remains online during background paper mount conditions.
20 (20-000 to 20-999)	This type of message denotes a PJJ parser error. When this type of error occurs, the entire command line is ignored.
25 (25-000 to 25-999)	These messages are PJJ parser errors. When this type of message occurs, only part of the PJJ command is ignored, instead of the whole command as happens with 20-xxx errors.
27 (27-000 to 27-999)	These messages are PJJ semantic errors, indicating the command syntax is acceptable, but command execution is not possible for some reason. A situation that produces a semantic error is trying to lock a paper tray when all other paper trays are already locked.

Status Category	Description
30 (30-000 to 30-999)	Most conditions in this category are auto-continuable, indicating that if no operator action is taken, the printer automatically continues if the auto-continue feature is set to true; if auto-continue is set to false, the printer waits until an operator presses either the Continue or On Line key. Examples of these errors include non-fatal I/O errors or when a page is ejected because it is too complex to format without the page protection feature enabled.
35 (35-000 to 35-999)	Messages indicating that operator intervention <i>may</i> be required. The printer stays online and continues printing, with the potential for reduced capability. Data may be lost.
40 (40-000 to 40-999)	Messages indicating that operator intervention is required. Printing halts until the condition is resolved. Examples include paper jam, out of paper, and printer open conditions.
41 (41-000 to 41-999)	This category of messages indicates a foreground paper mount. These conditions occur when paper is out and there is no alternate paper source available loaded with the correct paper size. The printer is offline under these conditions.
50 (50-000 to 50-999)	Hardware errors. Examples include memory errors and fatal print engine errors.

**Example:
Using Unsolicited
Device Status**

The following example enables unsolicited status with the verbose option. The printer response indicates that the printer is open.


```
<ESC>%-12345X@PJL <CR><LF>
@PJL USTATUS DEVICE = VERBOSE<CR><LF>
<ESC>%-12345X
```

A sample LaserJet 4 printer response for unsolicited device status is shown here. For other printers, responses may vary.

```
@PJL USTATUS DEVICE<CR><LF>
CODE=40021<CR><LF>
DISPLAY="12 PRINTER OPEN" <CR><LF>
ONLINE=FALSE<CR><LF>
<FF>
```

JOB Variable The @PJL USTATUS JOB = ON command is used to notify the application every time a JOB command is encountered, and when the final page of a job is in the output tray and an EOJ command has been received. This is useful for spooling applications requiring feedback indicating that a particular job has started or completely printed.

If job status is enabled and the printer receives a JOB command, it resets the page count associated with the unsolicited page status and returns a job status message.

Note  Resetting the page count associated with unsolicited page status affects only future pages. Pages that are already processed, but not yet printed, are not affected.

The PAGES=*number of pages* information associated with unsolicited EOJ status indicates the number of pages printed on paper. It does not include any page images that were processed in non-printing mode (see the “PAGE Variable” discussion.) When in the duplex mode, each side of a duplex page counts as one page.

Example: Using Unsolicited Job Status

This example turns on unsolicited job status so that the spooler can be notified when the job starts and completely finishes. A job name is included so that the spooler can match the status information with the correct job. (The indented lines indicate a job sent to the spooler from another application.)

```
<ESC>%-12345X@PJL <CR><LF>
@PJL USTATUS JOB = ON <CR><LF>
@PJL JOB NAME = "JOB 14993" <CR><LF>

    <ESC>%-12345X@PJL <CR><LF>
    @PJL ENTER LANGUAGE = PCL <CR><LF>
    <ESC>E . . . PCL Job . . . <ESC>E
    ↳<ESC>%-12345X

↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "JOB 14993" <CR><LF>
<ESC>%-12345X
```

A sample unsolicited LaserJet 4 printer response for this example is as shown here. For other printers, the response may be different.

```
@PJL USTATUS JOB<CR><LF>
START<CR><LF>
NAME="JOB 14993"<CR><LF>      (from the JOB command)
<FF>

[ . . time period while job is printing . . .]

@PJL USTATUS JOB<CR><LF>
END<CR><LF>
NAME="JOB 14993"<CR><LF>      (from the EOJ command)
PAGES=3<CR><LF>
<FF>
```

The printer sends the unsolicited status associated with the JOB command when the JOB command is parsed. The printer sends the unsolicited status associated with the EOJ command when all of the pages received before the EOJ command have been printed. To maximize performance, HP printers start processing the next job before the last page of the current job has been printed. Therefore, the printer may return unsolicited JOB and EOJ status messages in an order different than sent by the application or spooler. For example, when printing two consecutive jobs, the unsolicited EOJ status message associated with the first job may not arrive at the host until after the JOB status message of the second job.

PAGE Variable

The @PJL USTATUS PAGE = ON command is used to notify the application that a particular page finished printing. This is useful for applications such as spoolers, where it is beneficial to monitor the job on a page-by-page basis. For job recovery, described later in this chapter, it is helpful to know which pages are completely printed.

The number of pages is incremented by one for each simplex page formatted, and by two for each duplex page formatted. The page count includes all pages printed and all pages processed in non-printing mode since the last JOB or EOJ command. (This is different than the PAGES = *page count* returned with the unsolicited JOB status, which does not include pages processed in non-printing mode.)

Example: Using Unsolicited Page Status

The following example enables unsolicited page status. The sample LaserJet 4 printer response indicates the status messages that the printer sends when processing a four-page job.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL USTATUS PAGE = ON <CR><LF>
@PJL JOB <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . . Four-page PCL Job . . . <ESC>E
A<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ <CR><LF>
<ESC>%-12345X
```

A sample LaserJet 4 printer response for unsolicited page status is shown here. Other PJJ printer responses may vary.

```
@PJJ USTATUS PAGE<CR><LF>
1<CR><LF>
<FF>
@PJJ USTATUS PAGE<CR><LF>
2<CR><LF>
<FF>
@PJJ USTATUS PAGE<CR><LF>
3<CR><LF>
<FF>
@PJJ USTATUS PAGE<CR><LF>
4<CR><LF>
<FF>
```

TIMED Variable

The TIMED variable allows “automatic polling” of the printer without host intervention and without exiting the current printer language (back to PJJ). Values from 5 to 300 indicate the time interval between status messages, in seconds. This feature is turned off by setting the value to 0. The status message returned when this command is enabled is similar to that solicited by the @PJJ INFO STATUS command.

The “CODE=” portion indicates a status code number. See Appendix D for a complete list of status code numbers. The “DISPLAY=” portion of the returned status indicates the message currently displayed on the control panel. The “ON-LINE=” portion indicates whether the printer is online or offline.

Note



The “*string*” portion of the “DISPLAY=*string*” status message is localized; the same message displayed on the control panel appears in whichever language is being used.

The accuracy of the timer may vary +/- 10% due to delays in data transmission and other system variables. To allow for this, use a timing window in your application.

**Example:
Using Timed
Unsolicited Status**

In this example, a status message is sent to the host every 30 seconds.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL USTATUS TIMED = 30 <CR><LF>  
<ESC>%-12345X
```

A sample LaserJet 4 printer response is shown below. Other PJJ printers may respond differently.

```
@PJL USTATUS TIMED<CR><LF>  
CODE=10001<CR><LF>  
DISPLAY="00 READY" <CR><LF>  
ONLINE=TRUE<CR><LF>  
<FF>
```

Related Commands: INFO, ECHO, INQUIRE, DINQUIRE, SET, USTATUSOFF

USTATUSOFF Command

The USTATUSOFF command turns off all unsolicited status. This command eliminates the need to send several commands to turn off different types of USTATUS.

Syntax: @PJL USTATUSOFF [<CR>]<LF>

Parameters: There are no parameters for this command.

**Example:
Using the
USTATUSOFF
Command**

This example uses the USTATUSOFF command to disable all unsolicited status before specifying the desired unsolicited status, which in this case is DEVICE status.

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL USTATUSOFF <CR><LF>  
@PJL USTATUS DEVICE = ON <CR><LF>  
<ESC>%-12345X
```

Related Commands: USTATUS

Job Recovery

PJL provides job recovery capability using the following combination of commands:

- The JOB and EOJ commands are used to reset the page count and inform the printer of the boundaries for the job—its beginning and end.
- The USTATUS PAGE command is used to determine how many pages are completely printed.

If you must reprint a portion of a job, the spooling application can re-issue the job using the START option to specify the remaining portion of the job.

The following PJL job shows an example that provides job recovery if a problem occurs. Notice that the USTATUS JOB and USTATUS PAGE commands are sent prior to the JOB command. If a power failure or another problem interrupts the job, the unsolicited page status indicates the last completely printed page.

Note



The USTATUS JOB command is not strictly required for job recovery. However, it is useful for tracking jobs by name, not just page number. The following example uses the command to show the difference between the page count returned by the unsolicited job status and the unsolicited page status.

Sending the Initial Job

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Providing for Recovery <CR><LF>
@PJL USTATUS JOB = ON <CR><LF>
@PJL USTATUS PAGE = ON <CR><LF>
@PJL JOB NAME = "1st Shot" <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E ... 100-page PCL job ... <ESC>E
➡<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "End of 1st Shot" <CR><LF>
<ESC>%-12345X
```


After Job Failure

Once the spooler senses that the job failed (in this case, due to a power failure), the job can be recovered by resending it using the JOB command with the START option. Set the page number in the START option to the number of the last page printed plus 1. For instance, in the previous example, if a power failure occurred after page 25 completely printed, you set the START option to start printing on page 26 (see below). In this case, the printer processes the first 25 pages in non-printing mode, and then prints from page 26 through the end of the job.

```
<ESC>%-12345X@PJJL <CR><LF>
@PJJL COMMENT Recovering Crashed Job <CR><LF>
@PJJL USTATUS JOB = ON <CR><LF>
@PJJL USTATUS PAGE = ON <CR><LF>
@PJJL JOB NAME = "2nd Try" START = 26 <CR><LF>
@PJJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E ...Same 100-page PCL job ...<ESC>E
↳<ESC>%-12345X@PJJL <CR><LF>
@PJJL EOJ NAME = "End of Recovery" <CR><LF>
<ESC>%-12345X
```

In the job above, the first unsolicited page status message is sent after page 26 lands in the output tray. For a LaserJet 4 printer, the response appears as shown below. Other PJJL printers may respond differently.

```
@PJJL USTATUS PAGE<CR><LF>
26<CR><LF>
<FF>
```

Additional page status messages are sent after each succeeding page lands in the output tray. After the remaining 75 pages of the job are completely printed, the host receives unsolicited page and job status as follows:

```
@PJL USTATUS PAGE<CR><LF>
100<CR><LF>
<FF>
@PJL USTATUS JOB<CR><LF>
END<CR><LF>
NAME="End of Recovery"<CR><LF>
PAGES=75<CR><LF>
<FF>
```

The unsolicited *page* status indicates that the 100th page printed (25 processed in non-printing mode and 75 printed pages). The *job* status indicates that the EOJ command was received and that 75 pages were printed in the recovery job.

Device Attendance Commands

Introduction

PJL enables you to change messages displayed on the printer control panel. This capability is useful for alerting operators to perform specific actions, such as loading paper or pressing keys. This chapter describes the following three device attendance commands:

- **RDYMSG**—this command specifies a “ready message” that replaces the “00 READY” message on the printer control panel. The RDYMSG command does not affect the online state.
- **OPMSG**—this command displays a specified “operator message” on the printer control panel and takes the printer offline.
- **STMSG**—this command displays the specified “status message” on the printer control panel and takes the printer offline. It returns the name of the key that the operator pressed to put the printer back online.

Note



Some PJL printers do not support the device attendance commands. See Appendix A for a list of features supported by each printer.

RDYMSG Command

The RDYMSG command replaces the control panel's "ready" message with the specified message. Use the RDYMSG command to modify the displayed message while keeping the printer online.

Syntax: @PJL RDYMSG DISPLAY = "message" [<CR>]<LF>

Parameters:

Parameter	Functional Range	Default
DISPLAY = "message"	ASCII 33 and ASCII 35 thru 255, <SP>	N/A

- **DISPLAY = "message"** —The variable *message* can be any combination of printable characters (except quotation marks, ASCII 34) and spaces, with a limit of 1 line of 16 characters (see "Comments" below). The *message* variable is a string and must be enclosed in double quotes as shown in the command syntax.

Comments: Since the RDYMSG command leaves the printer online, it can be used to display the name of the person printing the current job, or other pertinent information, while a job is printing. It also can be used in network environments to display the name of the printer.

The command @PJL RDYMSG DISPLAY = "" returns the display to the normal ready message.



This command replaces the lowest priority 00 READY message. If any higher priority message is displayed (for example, toner low, or printer open), the new ready message does not appear until these outstanding conditions are cleared.

For the LaserJet 4PJ printer, if the LANG variable is set to Japanese, the message is displayed using the JIS X0201-76 character set.

Some HP LaserJet printers may have a different limit for the number of display lines and number of display characters. To request the display limits, use the INFO CONFIG command. When this command is used, the printer returns DISPLAY LINES=*value* and DISPLAY CHARACTER SIZE=*value* as part of the response message. For example, the LaserJet 4/4M printers return DISPLAY LINES=1, DISPLAY CHARACTER SIZE=16, indicating that the displayed message is limited to 1 line of 16 characters.

**Example:
Using the RDYMSG
Command**

This example simulates a spooler that prints a job from another application. The spooler uses the RDYMSG command to display the name of the person printing the job (while the job is printing). After the job is printed, the spooler restores the normal ready message. (The indented command lines indicate those sent by the printing application; the remaining lines are sent by the spooler.)

```
<ESC>%-12345X@PJL <CR><LF>  
@PJL JOB NAME = "Terry's Job" <CR><LF>  
@PJL RDYMSG DISPLAY = "TERRY'S JOB" <CR><LF>
```

```
    <ESC>%-12345X@PJL <CR><LF>  
    @PJL ENTER LANGUAGE = PCL <CR><LF>  
    <ESC>E . . . PCL Job . . .<ESC>E  
    ↪<ESC>%-12345X
```

```
    ↪<ESC>%-12345X@PJL <CR><LF>  
    @PJL COMMENT Restore READY message <CR><LF>  
    @PJL RDYMSG DISPLAY = "" <CR><LF>  
    @PJL EOJ NAME = "End of Terry's Job" <CR><LF>  
    <ESC>%-12345X
```

Related Commands: OPMSG, STMSG, INFO CONFIG

OPMSG Command

The OPMSG command prompts the printer to display the specified message and go offline. Use this command to display a message and halt printing until the operator presses the On Line, Continue, or Reset key.

Syntax: @PJL OPMSG DISPLAY = "message" [<CR>]<LF>

Parameters:

Parameter	Functional Range	Default
DISPLAY = "message"	ASCII 33 and ASCII 35– 255, <SP>,<HT>	N/A

- **DISPLAY = "message"** —The variable *message* can be any combination of printable characters (except quotation marks, ASCII 34) and spaces or horizontal tab characters, with a limit of 1 line of 16 characters (see "Comments" below). The *message* variable is a string and must be enclosed in quotation marks as shown in the command syntax.

Comments: The first two display characters blink. To avoid blinking, you can begin your message with two blank spaces.

Some HP LaserJet printers may have a different limit for the number of display lines and number of display characters. To request the display limitations, use the INFO CONFIG command. The printer returns DISPLAY LINES=*value* and DISPLAY CHARACTER SIZE=*value* as part of the response message. For example, the HP LaserJet 4/4M printers return DISPLAY LINES=1, DISPLAY CHARACTER SIZE=16, indicating that the displayed message is limited to 1 line of 16 characters.

Note



For the LaserJet 4PJ printer, if the LANG variable is set to Japanese, the message is displayed using the JIS X0201-76 character set.

Example:
Using the OPMSG
Command

This example displays "LOAD LETTERHEAD" on the printer control panel and halts processing until the operator presses the On Line or Continue key. Once one of the keys is pressed, the first page is printed. Then "LOAD PLAIN PAPER" is displayed. When the On Line or Continue key is pressed, the printer prints the rest of the job.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL JOB NAME = "JOB 111753" <CR><LF>
@PJL OPMSG DISPLAY = "LOAD LETTERHEAD" <CR><LF>
@PJL <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E This is "Letterhead" (page 1) <ESC>E
↳<ESC>%-12345X@PJL <CR><LF>
@PJL OPMSG DISPLAY = "LOAD PLAIN PAPER"
↳<CR><LF>
@PJL <CR><LF>
<ESC>%-12345X@PJL ENTER LANGUAGE = PCL
↳<CR><LF>
<ESC>E This is "Plain Paper" (page 2) <ESC>E
↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "EOJ 111753" <CR><LF>
<ESC>%-12345X
```

Related Commands: RDYMSG, STMSG, INFO CONFIG

STMSG Command

The STMSG command prompts the printer to display the specified message, go offline, and return a status message indicating which key the operator pressed to return the printer online. Use this command to display a customized message, to halt printing until the operator presses the On Line, Continue, or Reset key, and to take a different action depending on which key the user presses.

Syntax: @PJL STMSG DISPLAY = "message" [<CR>]<LF>

Return Syntax: @PJL STMSG DISPLAY="message" <CR><LF>
key <CR><LF>
<FF>

Parameters:

Parameter	Functional Range	Default
DISPLAY = " <i>message</i> "	ASCII 33 and ASCII 35– 255, <SP>, <HT>	N/A
<i>key</i>	ONLINE, RESET, or CONTINUE	N/A

- **DISPLAY = "*message*"** —The variable *message* can be any combination of printable characters (except quotation marks, ASCII 34) and spaces or horizontal tab characters, with a limit of 1 line of 16 characters (see comments below). The *message* variable is a string and must be enclosed in double quotes as shown in the command syntax.
- ***key*** —this variable is returned with the status response after the operator presses one of three control panel keys. The *key* variable has a value of either ONLINE, RESET, or CONTINUE, depending on which key the operator presses to return the printer online.



For the LaserJet 4PJ printer, if the LANG variable is set to Japanese, messages are displayed using the JIS X0201-76 character set .

Comments: This command is useful for making a programming decision based on which key the operator presses. For example, the application can prompt the user to press Reset, and then wait until the Reset key is pressed.

Some HP LaserJet printers may have a different limit for the number of display lines and number of display characters. To request the display limits, use the INFO CONFIG command. The printer returns DISPLAY LINES=*value* and DISPLAY CHARACTER SIZE=*value* as part of the response message. For example, the LaserJet 4/4M printers return DISPLAY LINES=1, DISPLAY CHARACTER SIZE=16, indicating that the displayed message is limited to 1 line of 16 characters.

**Example:
Using the STMSG
Command**

This example prompts the printer to display “LOAD FORM 1040” and goes offline. The printer returns the name of the key that is pressed to resume operation—in this case, the Continue key.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL <CR><LF>
@PJL STMSG DISPLAY = "LOAD FORM 1040" <CR><LF>
@PJL <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . PCL job . .<ESC>E<ESC>%-12345X
```

The returned message, if the operator presses the Continue key, is:

```
@PJL STMSG DISPLAY="LOAD FORM 1040"
CONTINUE
<FF>
```

Related Commands: OPMSG, RDYMSG, INFO CONFIG

Programming Tips for Using PJJ

Introduction

When using most printer languages, there is usually more than one way to perform a certain printing function. PJJ is no exception. Properly formed PJJ jobs provide the developer with the desired features while eliminating glitches. This chapter provides tips for creating efficient PJJ jobs that eliminate potential problems.

Note



Improperly coded print jobs may work fine in a single-computer/single-printer environment running only one application, but cause problems in a multi-application or shared network environment.

The first part of this chapter categorizes PJJ applications into three general types, and provides guidance and examples for each type. The remainder of the chapter provides hints for handling specific situations, including using status readback in a multi-user system.

PJL Services

This section segments applications into three types based on the services provided. Applications using PJL can be categorized as one of the following:

- **Print Data Generators**—applications that generate print jobs, such as Lotus 1-2-3, Microsoft Word, and WordPerfect.
- **Printer Utilities**—applications that control printer features, or request and provide printer status. These applications also can monitor the current state of the printer.
- **Spoolers**—applications that control print jobs generated by other applications.

Many applications provide more than one of the services listed above. For example, a Spooler can be used to monitor the printer and provide control over printer features, and print jobs. If an application does provide more than one service, only use those PJL commands appropriate for the provided services.

If applications providing different printer services follow the guidelines described in this section, they can work together properly. This chapter lists the commands used by each application type, explains the functions of each command, and offers several examples illustrating different PJL functions.

Print Data Generators

Print Data Generators are applications used to create and print information. Examples include WordPerfect, Harvard Graphics, and Lotus 1-2-3.

Software applications of this type should work properly when the printer is under the direct control of the application, and also when there is a spooler between the application and the printer. This is accomplished by using the ENTER command to select the proper printer language before sending print data to the spooler or printer. The UEL command should precede and follow the print job.

Print Data Generators should only use PJI commands when a corresponding command does not exist in the printer language. This is recommended so that the application does not override feature settings and adversely affect future jobs. To change feature settings for the duration of the job, or until the next PJI reset condition, use the SET command. Do not use the PJI INITIALIZE command for Print Data Generators.

Commands Used by Print Data Generators

UEL	Use before and after every PJI job.
COMMENT	Use to add explanations within PJI code.
ENTER	To select the correct printer language for the print job.
SET	To select a desired feature when it is not possible using the desired printer language (such as PCL or PostScript).
RESET	Use at the end of the job if the SET command is used in the job.

Print Data Generator Examples

The following two examples demonstrate how applications categorized as “Print Data Generators” should use PJI. Both examples work well if sent directly to the printer or through a spooler.

Jobs That Select a Printer Language

This example selects a printer language using the ENTER command. It is the most common job format for Print Data Generators.

```
<ESC>%-12345X@PJI <CR><LF>
@PJI ENTER LANGUAGE = POSTSCRIPT <CR><LF>
%!PS-ADOBE ... PostScript code ... ^D
<ESC>%-12345X
```

Jobs That Set Printer Features

This example specifies two feature settings that cannot be selected using the specified printer language:

```
<ESC>%-12345X@PJI <CR><LF>
@PJI SET RET = LIGHT <CR><LF>
@PJI SET RESOLUTION = 600 <CR><LF>
@PJI ENTER LANGUAGE = PCL <CR><LF>
<ESC>E ... PCL print data ... <ESC>E
➡<ESC>%-12345X@PJI <CR><LF>
@PJI RESET <CR><LF>
<ESC>%-12345X
```

Printer Utilities

Printer utilities are those applications that perform one or more of the following functions:

- **Control printer resources**—these programs set printer features such as the print resolution and number of copies using the SET, RESET, DEFAULT, and INITIALIZE commands.
- **Request information from the printer**—printer status and feature settings can be requested from the printer using the ECHO, INFO, INQUIRE, and DINQUIRE commands. Applications should only use PJI commands that request status if the application is in direct control of the printer and there is a bi-directional communication channel between the printer and the application.
- **Monitor the printer status**—device status and timed status can inform the application of printer events such as printer open, paper out, or low toner. The USTATUS DEVICE and USTATUS TIMED commands are used to monitor printer status. Applications can continuously monitor the printer for changes in printer state. When the printer changes state, the application takes appropriate action, such as informing the user.

In general, the Printer Utilities described here are not used to print information, but enable the user to request the current printer feature settings and modify features as desired.

Commands Used by Printer Utilities

UEL	Use before and after every PJL job.
COMMENT	Use to add explanations within PJL code.
SET	To modify a printer feature until the next PJL reset condition.
RESET	To set the printer to its user default feature settings.
DEFAULT	To modify the user default value of a printer feature. (NOTE: In shared environments, this feature should be used by system administrators only.)
INITIALIZE	To set the printer to its factory default settings. (NOTE: In shared environments, this feature should be used by system administrators only.)

Printer utilities that are equipped for bi-directional communications can request printer status using the following commands:

INQUIRE	To request the current setting for a particular feature.
DINQUIRE	To request the default setting for a particular feature.
INFO	To find the printer model, printer configuration, memory available, status information, page count, or printer variables.
ECHO	To synchronize requested status information.
USTATUS DEVICE	To be informed when the printer status changes.
USTATUS TIMED	To receive unsolicited printer status at periodic intervals.

Printer Utility Examples

The following three examples demonstrate the kind of PJJ jobs used by Printer Utilities:

- Jobs that request information and perform printer setup
- Jobs that request information, set features, and print existing files
- Jobs that monitor printing status

Jobs that Request Information and Perform Print Setup

The following example demonstrates a job setup utility that first asks for printer information, then sets default features to a desired state. This application functions like a remote control panel. This type of utility enables users to select PJJ features before printing from another application that cannot select PJJ features. In this example, the DEFAULT command is used instead of the SET command, so that changes apply to all future print jobs.

Note



Since this application uses the DEFAULT command, it changes the User Default Environment and control panel settings. In multi-user situations, it should be used only by printer administrators to avoid unexpected results by other users.

(Reading Status Information)

```
<ESC>%-12345X@PJJ <CR><LF>
@PJJ COMMENT Requesting features <CR><LF>
@PJJ ECHO 15:18:25.3 07-25-92 <CR><LF>
[. . application discards any printer status read-
back information received before the ECHO response
. .]
@PJJ DINQUIRE RET <CR><LF>
@PJJ DINQUIRE RESOLUTION <CR><LF>
[. . application receives status readback from the
DINQUIRE commands showing that RET = OFF and RESO-
LUTION = 300. . .]
<ESC>%-12345X
```


(Changing the Default Values)

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Set desired values <CR><LF>
@PJL DEFAULT RET = DARK <CR><LF>
@PJL DEFAULT RESOLUTION = 600 <CR><LF>
@PJL COMMENT Reset PJL to ensure default
values take effect <CR><LF>
@PJL RESET <CR><LF>
<ESC>%-12345X
```

Jobs That Request Information, Set Features and Print Existing Files

The following example requests information using the INQUIRE command, sets printer features using the SET command, and then sends an existing application print file to the printer. To restore the default values, the RESET command is issued before the job closes.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Requesting features <CR><LF>
@PJL ECHO Job #53 11-17-92 08:52:03.7 <CR><LF>
[. . application discards any printer status read-
back information received before the ECHO response
. .]
@PJL INQUIRE RET <CR><LF>
@PJL INQUIRE PAGEPROTECT <CR><LF>
@PJL INQUIRE RESOLUTION <CR><LF>
<ESC>%-12345X
```

[. . application receives status readback from the INQUIRE commands showing that RET = OFF, PAGEPROTECT = LETTER, and RESOLUTION = 300, which are not the desired settings. The application then sends SET commands to modify the settings to the desired value . .]

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Set desired values <CR><LF>
@PJL SET RET = MEDIUM <CR><LF>
@PJL SET PAGEPROTECT = OFF <CR><LF>
```

```
@PJL SET RESOLUTION = 600 <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . . PCL file . . .<ESC>E
↳<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Reset PJJ to restore <CR><LF>
@PJL COMMENT control panel defaults <CR><LF>
@PJL RESET <CR><LF>
<ESC>%-12345X
```

Jobs That Monitor Printing Status

The following example enables unsolicited printer status using the USTATUS DEVICE command. After unsolicited device status is enabled, the printer automatically sends a status response whenever the printer's status changes.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL ECHO Acme #17 8-28-92 5:39:02.9 <CR><LF>
@PJL COMMENT Turn on unsolicited device
↳status <CR><LF>
@PJL USTATUS DEVICE = ON <CR><LF>
<ESC>%-12345X
```

Spoolers

Spoolers are applications that control and/or monitor print jobs generated by other applications.

Spooling applications should use only PJI job-related commands when controlling the flow of print jobs to the printer. Encapsulate each print job with the JOB command at the beginning and the EOJ command at the end (the UEL command is always the first and last command in all PJI jobs).

Spoolers perform one or more of the following operations:

- **Confirm job completion**—to notify the spooler when the job is completely processed, use the USTATUS JOB = ON command. When this command is used, the EOJ command at the end of the job triggers the printer to send unsolicited job status information when the last page of the job is printed and in the output tray.
- **Monitor job progress**—if you want the spooler to monitor the page-by-page progress of a job, enable the page status with the USTATUS PAGE=ON command. As each page lands in the output tray, the printer sends an unsolicited page status message to the spooler.
- **Interact with the user**—to flash a message on the printer's display and take the printer off-line, use the OPMSG or STMSG commands. These commands are used to notify the user of a required action before printing can continue. For example, you can display "LOAD BLUE PAPER" and then wait until the user presses the Continue or On Line key. To display a message without taking the printer off-line, use the RDYMSG command.
- **Select a Printer Language or Print a Banner Page**—if the spooler is responsible for printer language selection or printing banner pages, use the ENTER LANGUAGE command. (Performance is not adversely affected if both the application file and the spooler send the ENTER LANGUAGE command.)
- **Print selected pages of jobs**—use the JOB command with the START and END options to specify which pages you want to print.

Commands Used by Spoolers

UEL	Use before and after every PJJ job.
COMMENT	Use to add explanations within PJJ code.
DEFAULT	To modify the default value of a printer feature. (NOTE: In shared environments, this feature should be used by system administrators only.)
ENTER	Use if responsible for printer language selection or banner printing.
JOB/EOJ	Use to monitor printing status, name jobs, print portions of a job, mark job boundaries.
OPMSG	To display a customized message and take the printer off-line until the operator presses the On Line, Continue, or Reset key.
RDYMSG	To replace the control panel "00 READY" message with a customized message.

Spoolers equipped for bi-directional communications can monitor printer status using the following commands:

ECHO	To synchronize status readback information. The application should send an ECHO command before any other status readback commands; all status responses before the returned ECHO response should be discarded to ensure proper synchronization.
STMSG	To display a customized message and take the printer off-line until the operator presses the On Line, Continue, or Reset key. Returns the name of the key that the operator pressed.

USTATUSOFF	To turn off all unsolicited status before specifying the desired USTATUS.
USTATUS PAGE	To receive notification as each page lands in the output tray.
USTATUS JOB	To monitor job progress. Sends status message when job has completed.

Spooler Examples

The following examples show jobs used by spooling applications:

- Jobs that monitor job progress and confirm job completion
- Jobs that notify the user to load specific forms or paper
- Jobs that control printer resources and print selected pages
- Jobs that print a banner page followed by an application-generated job (application specifies printer language)
- Jobs that print a banner page followed by an application-generated job (application does not specify printer language)

In each example, the indented lines indicate commands belonging to a print file created by another application.

Jobs That Monitor Job Progress and Confirm Job Completion

This example enables the spooler to receive notification as each page is finished printing, and when the entire job has finished. The USTATUS JOB = ON command enables unsolicited job status and the USTATUS PAGE = ON command enables page status.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Monitoring Job Progress <CR><LF>
@PJL COMMENT and Completion <CR><LF>
@PJL ECHO 12:07:54.5 07-26-92 <CR><LF>
[. . application discards printer status readback
data received before ECHO response . .]
@PJL USTATUS JOB = ON <CR><LF>
@PJL USTATUS PAGE = ON <CR><LF>
@PJL JOB NAME = "Monitoring Job" <CR><LF>
  <ESC>%-12345X@PJL <CR><LF>
    @PJL ENTER LANGUAGE = PCL <CR><LF>
    <ESC>E... PCL print data ...<ESC>E
    ↵<ESC>%-12345X
  ↵<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "End of Monitor Job" <CR><LF>
@PJL USTATUS JOB = OFF <CR><LF>
@PJL USTATUS PAGE = OFF <CR><LF>
<ESC>%-12345X
```

When the printer processes the JOB command, the following unsolicited job status message is sent:

```
@PJL USTATUS JOB
START
NAME="Monitoring Job"
<FF>
```

When USTATUS PAGE = ON, the first unsolicited page status message is sent after page 1 lands in the output tray:

```
@PJL USTATUS PAGE
1
<FF>
```

Additional page status messages are sent after each succeeding page lands in the output tray. After the job is completely printed, the host receives unsolicited page and job status as follows (assuming a 38-page job):

```
@PJL USTATUS PAGE
38
<FF>
```

```
@PJL USTATUS JOB
END
NAME="End of Monitor Job"
PAGES=38
<FF>
```

The unsolicited *page* status indicates that the 38th page printed. The *job* status indicates that the EOJ command was received, and that 38 pages were printed. (The page count is incremented by one for each simplex page formatted, and by two for each duplex page formatted.)

Jobs That Notify the User to Load Specific Forms or Paper

This example displays a message to "LOAD FORM 1040" and takes the printer off-line. When the form is loaded and the On Line or Continue key is pressed, the form is printed.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL JOB NAME = "Job #65432" <CR><LF>
@PJL OPMSG DISPLAY = "LOAD FORM 1040" <CR><LF>
  <ESC>%-12345X@PJL <CR><LF>
    @PJL ENTER LANGUAGE = PCL <CR><LF>
    <ESC>E ... PCL print data ... <ESC>E
    ↵<ESC>%-12345X
  ↵<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ NAME = "Job #65432" <CR><LF>
<ESC>%-12345X
```

Jobs That Control Printer Resources and Print Selected Pages

The following job prints 1 copy of pages 5 through 8 of the print job. The START command tells the printer to process pages in non-printing mode until the specified page (in this case, page 5). The END command specifies the last page to print. If the END command is not included, the job prints from page 5 through the end of the document.

If you need to print more than one copy of each page, send the job multiple times using the START and END options to get collated copies. Using the SET command to print multiple copies of a selected page causes unexpected results because the printer counts physical pages, not multi-copy collated pages.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Printing selected pages <CR><LF>
@PJL JOB START = 5 END = 8 <CR><LF>
<ESC>%-12345X@PJL <CR><LF>
  @PJL ENTER LANGUAGE = PCL <CR><LF>
  <ESC>E . . . PCL print job . . .<ESC>E
  ↳<ESC>%-12345X
↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ <CR><LF>
<ESC>%-12345X
```


Spooler Job That Prints a Banner Page Followed by an Application-Generated Job (Application specifies printer language)

The following example demonstrates a spooling application that prints a banner page, and then prints a PostScript job. The application that produced the print file specifies the printer language.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT Spooling Job with Banner <CR><LF>
@PJL JOB NAME = "Spooler #1" <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . . Banner Page Data . . . <ESC>E
↳<ESC>%-12345X
    ↳<ESC>%-12345X@PJL <CR><LF>
        @PJL ENTER LANGUAGE = POSTSCRIPT <CR><LF>
            %!PS-ADOBE . . PostScript print data . . ^D
                ↳<ESC>%-12345X
↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ <CR><LF>
<ESC>%-12345X
```

Spooler Job That Prints a Banner Page Followed by an Application-Generated Job (Application Does Not Specify Printer Language)

The following example demonstrates a spooling application that prints a banner page. The application was not created with a PJL-ready driver, so it does not begin and end with UEL commands, or specify the printer language, so the printer implicitly switches to the correct printer language.

```
<ESC>%-12345X@PJL <CR><LF>
@PJL JOB NAME = "Spooler #2" <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E . . Banner Page Data. .<ESC>E
↳<ESC>%-12345X
    . . . PCL or PostScript print data . . .
↳<ESC>%-12345X@PJL <CR><LF>
@PJL EOJ <CR><LF>
<ESC>%-12345X
```

Requesting Printer Status

When querying the printer for status, the response is not immediate. Wait a fixed amount of time for a response and then time out. If the printer is still working on a previous print job, it may take a while before a response is received.

Your application should be able to discard unexpected status, such as unsolicited status, and discard unrecognizable lines. Lines within the PJI status response begin with a specific keyword, as described in the command description in Chapter 7, and end with the <CR><LF> control codes. Future printers may support new keywords in the PJI status response. Your application should ignore those lines which it does not understand.

Using Status Readback in a Multi-User System

The printing system consists of all components involved in the process of turning an application document into a printed sheet of paper. Common printing system components include the host computer, applications on the host computer, the operating system used by the host computer, the cable connecting the host computer to the printer, and the printer. Other printing system components can include printer sharing boxes, network servers, spoolers running on network servers, and I/O cards installed in the printer. For printer status readback to be useful, all components must be bi-directional.

Some operating system environments, like Microsoft's Windows, provide the components that interact with the printer so Windows applications generally do not need to support printer status readback.

The components that may generate printer queries include the host application, the printer sharing box, the network spooler, and the I/O card installed in the printer. Printer status readback can allow many printing system components to function more effectively, not just the host application. For example, a network I/O card may inject a PJI JOB command

at the beginning of each job and a PJJ EOI command at the end of each job. Using unsolicited PJJ job status, the I/O card could send a network packet to an application on the client that supplied the job, notifying the user the job had been printed. Printer status readback allows many printer system components to solve user's needs.

Example Printing System

Figure 9-1 contains an example printing system. The print system contains one I/O-switching LaserJet printer which is connected to seven computers. Host computer #1 is connected via the serial I/O interface. Host computers #2 and #3 are connected through an external printer sharing box that also buffers print job data. The printer sharing box is connected to the printer through the Bi-Tronics I/O interface. Network servers #4 and #5 spool print jobs from network clients #6 and #7.

Although all the network clients and spoolers are connected to the same network cable as the printer, only the two network servers are capable of communicating directly with the printer. In this example, the network clients spool print jobs to a network server; they can not interact directly with the printer.

Given the printing system as shown in Figure 9-1, not all of the printing system components can query the printer and expect a response back.

Printer Status Readback and Printer Sharing

Host computer #1 is directly connected to the printer via the bi-directional serial I/O link. If the software on the host computer supports bi-directional printer communication, applications on host computer #1 can expect the printer to respond to queries. However, at the time an application on host computer #1 requests information, the printer may be processing a print job from a different I/O interface, so the response to host computer #1's query may be delayed, as described in the "Printer Status Readback and Printer I/O Switching" section in this chapter.

Host computers #2 and #3 are connected to the printer via an external printer sharing box that buffers data. If the printer sharing box was not designed to support bi-directional communication with the printer, then applications on host computers #2 and #3 will not be able to receive printer status readback information. However, since the printer sharing box is connected to the printer via the Bi-Tronics I/O interface,




Figure 9-1. Sample Printing System Components

which does support bi-directional communication, it is possible for printer sharing boxes to be designed to support printer status readback. In fact, the printer sharing box itself may be able to inject a “print job” to query the printer for specific information.

External printer sharing boxes can be designed to support sending data from the printer to the host computer. However, the printer sharing box has to determine which host computer should receive the printer’s response. The simplest solution for printer sharing boxes is to forward all data received from the printer to all attached host computers, and let the applications on each host computer ignore any impertinent data, as described in the “Handling Unexpected Printer Responses” section in this chapter.

The printer in this example is also attached directly to a network via a network interface card installed into the printer’s MIO interface. Network servers #4 and #5 spool print jobs from network clients #6 and #7. In this example, the network clients can not interact directly with the network-attached printer. The network spoolers can inject a “print job” to query the printer and can expect to get responses back. However, for this example, the network operating system does not provide a mechanism which allows applications running on a network client to query the printer and get a response.

The printer’s I/O card, the printer sharing box, and the spoolers running on the network servers can query the printer and expect to receive a response since those components are connected directly to the printer (i.e. no other printing system component except for the communication cable is between the printer and those components).

In summary, an application running on host computer #1 can receive printer responses if the operating system on the host computer supports bi-directional communication over the serial I/O interface. The application may have to wait for the printer’s response if the printer is processing a job from either the Bi-Tronics I/O interface or the MIO interface.

An application running on host computer #2 or #3 may receive printer responses if the printer sharing box supports bi-directional printer communication. However, since the printer sharing box does not have enough information to route the response to the correct host computer, the printer sharing box can forward all printer responses to all attached host computers and let the application on the host computer ignore any unneeded printer responses.

Applications on network clients #6 and #7 cannot receive any printer responses due to the underlying network operating system. However, the printer sharing box, the I/O card installed in the printer, and spoolers running on network servers #4 and #5 can all query the printer and expect a printer response (although the response will not be immediate if the printer is processing a print job from a different I/O interface).

Printer Status Readback Usage

Applications use printer status readback for two primary purposes (although there are other uses): printer driver configuration and monitoring device status. Since printer configuration does not change often (i.e. the amount of installed printer memory does not change frequently) using printer status readback to assist in initial configuration (or when the printer's configuration changes) is straightforward. If the application determines printer status readback is unavailable (discussed in the "Determining If Printer Status Readback is Available" section), the application can ask the user for the information instead of querying the printer.

The other primary use for printer status readback is to allow applications to monitor the state of the printer. In particular, applications can inform the user when the printer requires intervention (e.g. fill paper trays). If the application enables unsolicited PJI device status, the printer will inform the application whenever the printer's status changes. Since the printer informs the application using unsolicited status, even when the printer is processing a print job from a different I/O interface, the application gets timely printer status information. If printer status readback is unavailable, the applica-

tion will not be able to provide the user with current printer state information.

Another use for printer status readback is to determine what volatile resources (e.g. soft fonts) are available in the printer right before a print job is sent to the printer. If an application optimizes the printer job using printer status readback (i.e. does not send soft fonts if the printer already has the font), then if printer status readback is unavailable, the application should assume worst case (i.e. the font is not in the printer) when generating print jobs.

In summary, the application should be designed to take advantage of printer status readback, if available, but still function if it is unavailable.

Determining If Printer Status Readback is Available

If the application sends a PJI ECHO command (preceded by the Universal Exit Language command, of course) to the printer and receives the expected response, then the application can assume bi-directional communication with the printer is available and supported solicited status queries will be answered in a timely fashion.

However, under some conditions the application will send, or attempt to send, a PJI ECHO command and not receive a timely response because of one of two reasons: the printer may not be accepting data (due to the printer processing a print job from a different I/O interface or the printer being off-line), or the printing system does not support printer status readback to the application. If the application does not receive a response within three seconds, then the application can assume printer status readback is currently unavailable.

In some printing environments, the application may be able to distinguish between the host operating system not being able to send the query, and the query being sent without receiving a response in a reasonable amount of time. Application developers should not assume that because a query was sent and a response was not received in a timely fashion, that the printer system does not support bi-directional communication. Printer sharing devices may buffer the query and the response may be available, however the data buff-

ered before the query may take more than three seconds to process, delaying the response by more than three seconds.

The application should notify the user that printer status readback is currently unavailable and query the user to determine how to proceed. The common choices are: 1) printer busy, continue retrying until printer status readback is available, 2) printer busy on a long printer job, temporarily do not use printer status readback, or 3) printer status readback unavailable due to host-printer configuration, do not use printer status readback. After obtaining the user's response, the application can continue as appropriate.

Printer Status Readback and Printer I/O Switching

I/O switching occurs when a printer contains more than one I/O interface and accepts data from any interface, based on a first-come first-served basis. Some PjL printers do not support I/O switching.

I/O switching adds complexity to printing solutions taking advantage of printer status readback. If the printer is currently processing a print job from a different I/O interface, applications querying the printer will have to wait for the printer to respond to the query, (or proceed without using printer status readback). The amount of time until the printer provides the response is dependent on the length of the current print job and the length of any other print jobs the printer may process before processing the application's query.

When processing a job, I/O switching paces off all I/O interfaces except for the one which is providing the current print job. However, it is possible for an application to get a few bytes of data into the inactive I/O interface before the printer paces off that I/O interface. If the application times out while trying to send the initial UEL command after one or more bytes of the command are sent, but before the entire UEL command is sent, then the application can proceed using one of the following choices: 1) continue attempting to send the data to the printer, 2) remember how much of the initial UEL command has been sent to the printer and attempt to send the rest of the command at a later time, or 3) stop trying to send the command, making sure the next command the

application sends to the printer is the UEL command. This is done so the parser inside the printer properly recognizes all commands following the previously sent partial UEL command. The printer will properly recognize the UEL command, even if the command appears after a partial UEL command.

For example, assume the initial query is :

```
<ESC>%-12345X@PJL ECHO 08/27/92 09:53:46.5  
➔033288925
```

If the printer only accepts “<ESC>%-12”, and if the application later sends:

```
<ESC>%-12345X@PJL ECHO 08/27/92 09:57:46.5  
➔6202323802 <LF>
```

The printer accepts the query and responds with:

```
@PJL ECHO 08/27/92 09:57:46.5 6202323802<LF>  
<FF>
```

One of the conditions I/O-switching printers use to determine when to switch to another I/O interface is the idle time of the I/O interface supplying the current print job. Idle time is defined as the time elapsed since the I/O interface received the last data byte. If the application queries the printer and waits for a response, it is possible for I/O interface idle time to exceed the set timeout value (the TIMEOUT environment variable). When the printer detects the current I/O interface timed out, the printer allows I/O switching and treats any data received over the I/O interface as unrelated to the data previously received over that interface.

To keep the I/O interface from timing out, the application can either send data to the printer more frequently than the timeout setting or can cause the printer to use a different setting by sending a PJL JOB command. When I/O-switching printers receive the PJL JOB command, the printer uses an I/O timeout value equal to ten times the TIMEOUT environment variable setting or five minutes, whichever is greater. (If the application sends the PJL JOB command, the application should send a PJL EOJ command at the end of the job.)

Old Printer Status Readback Responses

Applications need to be designed to handle receiving printer status readback responses that were generated because of an action performed by a different application. For example, a word processing application may send a query to the printer, but because the user turned off the host computer, the application never got a chance to retrieve the response from the printer before the host computer was turned off. When another application, or even the same application at a later time, queries the printer, the first response is the response to the word processing application's query.

The currently executing application should accept old printer status readback responses and discard them until the expected response is received. Applications should include unique information as part of the ECHO command, such as the current time and date and a random number, so that the application can resynchronize with printer status readback responses.

There is also a chance the PJI ECHO response will never be sent by the printer, due to overflowing of the printer's response data buffer as discussed in the following section.

Response Data Buffer Overflow

The printer contains a limited amount of memory. It is possible for an application to fill all available printer memory with printer status readback responses that have not yet been sent to the host computer, simply by sending many queries and never accepting the responses from the printer. Also, if an application enables unsolicited status and never accepts responses, the printer's response data buffer can overflow. The printer limits the amount of memory allotted to hold responses, and when that memory is full (and the host has not recently accepted any responses), the printer discards all future responses until the host accepts the currently queued responses in the printer.

When the printer discards responses, the printer inserts the PJI unsolicited “printer to host data buffer overflow” message:

```
CE
CODE=10010
DISPLAY="00 READY"
```

Note



Refer to the “HP LaserJet 4 Family Comments” section in Appendix A under “Printer Status Readback” for the exact “printer to host buffer overflow” message sent by the HP LaserJet 4 printer family.

The PJI unsolicited “printer to host data buffer overflow” message is always inserted when the printer discards one or more responses, even if unsolicited status is turned off.

I/O-switching printers set aside memory for each I/O interface. A response data buffer overflow on one I/O interface does not mean another I/O interface will also experience the overflow condition. To keep the printer’s response data buffer from overflowing, applications should not send more than five queries without accepting the printer’s response to those queries.

The application should always send a PJI ECHO command to resynchronize with the printer status readback responses (i.e. get rid of any old responses). However, if the printer’s response data buffer is full and the printer is discarding all future responses, then the host will receive a PJI unsolicited “printer to host data buffer overflow” message, but not the PJI ECHO response. Applications must be designed to handle situations where the printer’s response data buffer overflows and the printer does not provide the expected response, but instead provides a PJI unsolicited “printer to host data buffer overflow” message. The application should resend all unanswered queries whenever the application receives a PJI unsolicited “printer to host data buffer overflow” message.

Handling Unexpected Printer Responses

Printer sharing devices, like the external printer sharing box or the MIO card inserted into the printer as shown in Figure 9-1, do not have sufficient information to allow the printer sharing device to properly route printer status readback responses to the host computer (the one running the application that queried the printer). In particular, unsolicited PJI status is difficult for the printer sharing device to properly route since the unsolicited status response may be received by the printer sharing box hours after sending the data from the host computer to the printer that enabled unsolicited status.

Manufacturers of printer sharing devices can choose from the following options to solve this printer-to-host data routing problem.

- 1) A printer sharing device that is a uni-directional device and does not support printer-to-host data transfer. Applications need to be designed to work with uni-directional printer sharing devices.
- 2) A printer sharing device that examines the data received from the printer and only forwards solicited responses to the host computer.

A printer sharing device can track which of its I/O interfaces is currently sending data to the printer, and thus know which I/O interface to use when sending solicited printer responses. When the printer sharing device sends data to the printer from a different I/O interface, the printer sharing device must know to the exact byte boundary what printer response data should be sent to the previous I/O interface and what data should be sent to the current I/O interface.

Before the printer sharing device sends the printer data from a different I/O interface than the source of the current print job, the printer sharing device can inject a PJI ECHO command. All solicited printer responses received before the PJI ECHO response should be sent to the previously active I/O interface. All solicited printer responses received after the PJI ECHO response should be sent to the currently active I/O interface. The printer shar-

ing device should consume the PJI ECHO response which was a result of the PJI ECHO command injected by the printer sharing device.

Applications that use unsolicited PJI device, job, page, or timed status need to work properly with printer sharing devices that do not support unsolicited printer-to-host responses.

- 3) A printer sharing device that can route solicited responses as described in 2 above, plus send all unsolicited responses to all attached host computers. Applications must be designed to properly ignore unexpected printer status readback responses. Ideas on how to design an application to ignore unexpected printer status readback responses are described in the next section.

Application Design Ideas

The previous pages have described various printing system topologies and how components in those topologies can operate so each printer system component can receive printer status readback responses. This section discusses application design ideas that handle the complexities involved with using printer status readback information.

The obvious design approach of querying the printer and waiting for an answer to that query is sure to lead to failure. A busy printer, old printer responses, overflowed printer response buffer, and a uni-directional printing environment all cause the obvious design approach to be inadequate. A better design approach is to treat printer responses as events that cause the application to take some action.

Solicited and unsolicited printer status readback queries/responses are discussed separately.

Whenever the application sends a solicited query to the printer, the application should add the query to the “outstanding solicited query” list. Also, if the application can not proceed until the response is received, then a watchdog timer should be set so that some event will be guaranteed to occur in case the application does not receive a timely response. Whenever a solicited response is received, the response should be compared to the list of outstanding solicited

queries. If there is no match, then the solicited response should be discarded. If there is a match, then the query should be removed from the outstanding solicited query list, any associated watchdog timer should be disabled, and the application should process the response. If the application was blocked waiting for the response, then the application should become unblocked.

If the application does not need an unsolicited status response, then the application can discard the response.

If the application ever receives the unsolicited PJJ “printer to host data buffer overflow” message, then the application should resend all queries in the “outstanding solicited query” list. When the application resends the outstanding solicited queries, it is possible that the application will receive two responses (one generated because of the initial query and one generated because of the resent query). If the application is using an outstanding solicited query list, then when the first response is received, the query will be removed from the list. When the second response is received, the second response will be ignored because there is no matching query in the outstanding solicited query list.

Given the above structure for sending queries and processing responses, applications should adhere to the following guidelines:

- 1) If the application sends data to the printer in blocks, followed by long pauses between blocks (i.e. greater than five seconds), then it should cause the printer to use a larger I/O interface idle time value by using the PJJ JOB command as described in the “Printer Status Readback and Printer I/O Switching” section.
- 2) Check status readback availability as described in the “Determining if Printer Status Readback is Available” section.
- 3) Synchronize with the printer-to-host data stream as described in the “Old Printer Status Readback Responses” section.

- 4) Do not have more than five outstanding queries before accepting printer status readback responses. This prevents response data loss as described in the “Response Data Buffer Overflow” section.
- 5) Before quitting, turn off all unsolicited status enabled by the application. Also, accept all responses from the printer that were generated because of actions performed by the application.
- 6) Do not be dependent on the timing characteristics of a single printer model. For example, the response time of the LaserJet 4 printer’s built-in Bi-Tronics I/O interface will be different than the timing characteristics of a Bi-Tronics I/O interface in an I/O card installed into the printer.

Product-Specific Feature Support

Introduction

This appendix helps you compare the differences in PJJ support for all PJJ printers. It includes a list of all the PJJ commands, showing which commands are supported by each PJJ printer. Also, a list of environment variables shows the range of environment variables supported by each printer. The final portion of the appendix describes some important product-specific information regarding the Hewlett-Packard LaserJet IIISi, 4Si, 4SiMx, 4, 4M, 4 Plus, 4M Plus, 4L, 4ML, 4P, 4MP, and 4PJ printers.

PJL Feature Support

The following two tables list the entire PJL feature set and show which features are supported by each printer/plotter. The letters “ns” indicate the command is not supported, and “YES” indicates it is supported.

PJL Command Name	PJL LaserJet Printer						
	IIISi	4/4M/ 4Si/4SiMx	4 Plus 4M Plus	4L	4ML	4P/4MP	4PJ
COMMENT	YES	YES	YES	YES	YES	YES	YES
DEFAULT	ns	YES	YES	YES	YES	YES	YES
DINQUIRE	ns	YES	YES	YES	YES	YES	YES
ECHO	ns	YES	YES	YES	YES	YES	YES
ENTER	YES	YES	YES	YES	YES	YES	YES
EOJ	ns	YES	YES	ns	YES	YES	YES
INFO	ns	YES *	YES	YES *	YES	YES	YES
INITIALIZE	ns	YES	YES	YES	YES	YES	YES
INQUIRE	ns	YES	YES	YES	YES	YES	YES
JOB	ns	YES	YES	ns	YES	YES	YES
OPMSG	ns	YES	YES	ns	ns	YES	YES
PJL (@PJL prefix followed by <LF>)	YES	YES	YES	YES	YES	YES	YES
RDYMSG	ns	YES	YES	ns	ns	YES	YES
RESET	ns	YES	YES	YES	YES	YES	YES
SET	ns	YES	YES	YES	YES	YES	YES
STMSG	ns	YES	YES	ns	ns	YES	YES
UEL	YES	YES	YES	YES	YES	YES	YES
USTATUS	ns	YES	YES	TIMED, DEVICE only	YES	YES	YES
USTATUSOFF	ns	YES	YES	YES	YES	YES	YES

* The LaserJet 4/4M/4L printers support all INFO categories except PAGECOUNT.

PJL Command Name	PJL Printer/Plotter			
	DeskJet 1200C	PaintJet XL300	DesignJet 200	DesignJet 600/650C
COMMENT	YES	YES	YES	YES
DEFAULT	ns	ns	ns	ns
DINQUIRE	ns	ns	ns	ns
ECHO	ns	ns	YES	YES
ENTER	YES	YES	YES	YES
EOJ	ns	ns	YES	ns
INFO	ns	ns	STATUS, USTATUS, CONFIG, and ID only	USTATUS only
INITIALIZE	ns	ns	ns	ns
INQUIRE	ns	ns	ns	ns
JOB	ns	ns	YES	ns
OPMSG	ns	ns	ns	ns
PJL (@PJL prefix followed by <LF>)	YES	YES	YES	YES
RDYMSG	ns	ns	ns	ns
RESET	ns	ns	ns	ns
SET	ns	ns	ns	ns
STMSG	ns	ns	ns	ns
UEL	YES	YES	YES	YES
USTATUS	ns	ns	TIMED and DEVICE only	TIMED and DEVICE only
USTATUSOFF	ns	ns	YES	YES

PJL Environment Variable Support

The following table lists all of the current environment variables for PJL, PCL 5 and PostScript, and shows which features are supported by which printers. The letters “ns” indicate the feature is not supported, “YES” indicates it is supported, and “RO” indicates it is supported as a read only variable. Factory default values are shown in parentheses. Products that do not support the SET or DEFAULT commands, such as the LaserJet IIISi printer, do not support any of the environment variables.

Environment Variable	Variable Values	LaserJet Printer with PJL						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
AUTOCONT*	(OFF)	RO	RO	RO	YES*	YES*	YES*	YES*
	ON	RO	RO	RO	YES*	YES*	YES*	YES*
BINDING	(LONGEDGE)	ns	YES	YES	ns	ns	ns	ns
	SHORTEDGE	ns	YES	YES	ns	ns	ns	ns
CLEARABLE-WARNINGS *	JOB	RO	RO	RO	ns	ns	YES*	YES*
	(ON)	RO	RO	RO	ns	ns	YES*	YES*
COPIES	(1) to 999	YES	YES	YES	YES	YES	YES	YES
CPLOCK (Only supported by DEFAULT, INQUIRE, or DINQUIRE)	(OFF)	ns	YES	YES	ns	ns	ns	ns
	ON	ns	YES	YES	ns	ns	ns	ns
DENSITY *	1 to 5 (3)	RO	RO	ns	YES*	YES*	YES*	YES*
DUPLEX	(OFF)	ns	YES	YES	ns	ns	ns	ns
	ON	ns	YES	YES	ns	ns	ns	ns
ECONOMODE	(OFF)	ns	YES	ns	YES	YES	YES	YES
	ON	ns	YES	ns	YES	YES	YES	YES
FORMLINES	5 to 128 (60)	YES	YES	YES	YES	YES	YES	YES

* When a SET or DEFAULT command is used with the AUTOCONT, CLEARABLEWARNINGS, or DENSITY variables, both the User Default and PJL Current Environment settings are modified. It is recommended these variables not be changed on a job-by-job basis.

Environment Variable	Variable Values	LaserJet Printer with PJJ						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
IMAGEADAPT	(AUTO)	ns	ns	ns	YES	ns	ns	ns
	OFF	ns	ns	ns	YES	ns	ns	ns
	ON	ns	ns	ns	YES	ns	ns	ns
INTRAY1	(UNLOCKED)	RO	RO	RO	ns	ns	ns	ns
	LOCKED	RO	RO	RO	ns	ns	ns	ns
INTRAY2	(UNLOCKED)	RO	RO	RO	ns	ns	ns	ns
	LOCKED	RO	RO	RO	ns	ns	ns	ns
INTRAY3	(UNLOCKED)	RO	RO	ns	ns	ns	ns	ns
	LOCKED	RO	RO	ns	ns	ns	ns	ns
INTRAY1SIZE	(LETTER)	RO	RO	RO	ns	ns	ns	ns
	LEGAL	RO	RO	RO	ns	ns	ns	ns
	A4	RO	RO	RO	ns	ns	ns	ns
	EXECUTIVE	RO	RO	RO	ns	ns	ns	ns
	COM10	RO	RO	ns	ns	ns	ns	ns
	MONARCH	RO	RO	ns	ns	ns	ns	ns
	C5	RO	RO	ns	ns	ns	ns	ns
	DL	RO	RO	ns	ns	ns	ns	ns
	B5	RO	RO	ns	ns	ns	ns	ns
INTRAY2SIZE	(LETTER)	RO	RO	RO	ns	ns	ns	ns
	LEGAL	RO	RO	RO	ns	ns	ns	ns
	A4	RO	RO	RO	ns	ns	ns	ns
	EXECUTIVE	RO	RO	RO	ns	ns	ns	ns

Environment Variable	Variable Values	LaserJet Printer with PJJ						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
INTRAY3SIZE	(LETTER)	RO	RO	ns	ns	ns	ns	ns
	LEGAL	RO	RO	ns	ns	ns	ns	ns
	A4	RO	RO	ns	ns	ns	ns	ns
	EXECUTIVE	RO	RO	ns	ns	ns	ns	ns
	COM10	ns	RO	RO	ns	ns	ns	ns
	MONARCH	ns	RO	RO	ns	ns	ns	ns
	DL	ns	RO	RO	ns	ns	ns	ns
INTRAY4SIZE	(COM10)	RO	RO	ns	ns	ns	ns	ns
	MONARCH	RO	RO	ns	ns	ns	ns	ns
	C5	RO	RO	ns	ns	ns	ns	ns
	DL	RO	RO	ns	ns	ns	ns	ns
	B5	RO	RO	ns	ns	ns	ns	ns
IOBUFFER *	ON	ns	YES	ns	ns	ns	ns	ns
	OFF	ns	YES	ns	ns	ns	ns	ns
	AUTO	ns	YES	ns	ns	ns	ns	ns
IOSIZE *	10 to max. available memory	ns	YES	ns	ns	ns	ns	ns
JOBOFFSET	OFF	ns	ns	YES	ns	ns	ns	ns
	(ON)	ns	ns	YES	ns	ns	ns	ns

* The IOBUFFER and IOSIZE variables can only be used with the DEFAULT, DINQUIRE, and INQUIRE commands.

Environment Variable	Variable Values	LaserJet Printer with PJJ						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
LANG	DANISH	ns	ns	ns	ns	YES	YES	ns
	GERMAN	ns	ns	ns	ns	YES	YES	ns
	ENGLISH	ns	ns	ns	ns	(YES)	(YES)	YES
	SPANISH	ns	ns	ns	ns	YES	YES	ns
	FRENCH	ns	ns	ns	ns	YES	YES	ns
	ITALIAN	ns	ns	ns	ns	YES	YES	ns
	DUTCH	ns	ns	ns	ns	YES	YES	ns
	NORWEGIAN	ns	ns	ns	ns	YES	YES	ns
	POLISH	ns	ns	ns	ns	YES	YES	ns
	PORTUGUESE	ns	ns	ns	ns	YES	YES	ns
	FINNISH	ns	ns	ns	ns	YES	YES	ns
	SWEDISH	ns	ns	ns	ns	YES	YES	ns
	TURKISH	ns	ns	ns	ns	YES	YES	ns
JAPANESE	ns	ns	ns	ns	ns	ns	(YES)	
LOWTONER	(ON)	RO	ns	ns	ns	ns	ns	ns
	OFF	RO	ns	ns	ns	ns	ns	ns
	(CONTINUE)	ns	RO	RO	ns	ns	ns	ns
	STOP	ns	RO	RO	ns	ns	ns	ns
MANUALFEED	(OFF)	YES	YES	YES	YES	YES	YES	YES
	ON	YES	YES	YES	YES	YES	YES	YES
MPTRAY	MANUAL	RO	RO	ns	ns	ns	ns	ns
	CASSETTE	(RO)	RO	ns	ns	ns	ns	ns
	FIRST	RO	(RO)	ns	ns	ns	ns	ns
ORIENTATION	(PORTRAIT)	YES	YES	YES	YES	YES	YES	YES
	LANDSCAPE	YES	YES	YES	YES	YES	YES	YES
OUTBIN	(UPPER)	ns	ns	YES	ns	ns	ns	ns
	LOWER	ns	ns	YES	ns	ns	ns	ns

Environment Variable	Variable Values	LaserJet Printer with PJL						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
PAGEPROTECT	OFF	(YES)	ns	(YES)	YES	YES	YES	YES
	LETTER	YES	ns	YES	ns	YES	YES	YES
	LEGAL	YES	ns	YES	ns	YES	YES	YES
	A4	YES	ns	YES	ns	YES	YES	YES
	ON	ns	YES	ns	YES	ns	ns	ns
	AUTO	ns	(YES)	ns	(YES)	(YES)	(YES)	(YES)
PAPER (Letter, Legal, A4, Executive, and JISB5 are paper sizes; Com10, C5, DL, Monarch, and B5 are envelope sizes; JPOST and JPOSTD are Japanese post card sizes; CUSTOM is for feeding other sizes, such as 3 x 5 cards and labels)	LETTER	(YES)	(YES)	(YES)	(YES)	(YES)	(YES)	YES
	LEGAL	YES	YES	YES	YES	YES	YES	YES
	A4	YES	YES	YES	YES	YES	YES	(YES)
	EXECUTIVE	YES	YES	YES	YES	YES	YES	YES
	COM10	YES	YES	YES	YES	YES	YES	YES
	MONARCH	YES	YES	YES	YES	YES	YES	YES
	C5	YES	YES	ns	YES	YES	YES	YES
	DL	YES	YES	YES	YES	YES	YES	YES
	B5	YES	YES	ns	YES	YES	YES	YES
	CUSTOM	ns	ns	ns	ns	YES	YES	YES
	JPOST	ns	ns	ns	ns	ns	ns	YES
JPOSTD	ns	ns	ns	ns	ns	ns	YES	
JISB5	ns	ns	ns	ns	ns	ns	YES	
PASSWORD (Only supported by DEFAULT, INQUIRE, or DINQUIRE)	(0) to 65535	ns	YES	YES	ns	ns	ns	ns

Environment Variable	Variable Values	LaserJet Printer with PJJ						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
PERSONALITY *	AUTO	(YES)	(YES)	(YES)	ns	(YES)	(YES)	ns
	PCL	YES	YES	YES	ns	YES	YES	YES
	POSTSCRIPT	YES	YES	YES	ns	YES	YES	ns
	ESCP	ns	ns	ns	ns	ns	ns	(YES)
POWERSAVE	ON	ns	YES	YES	ns	ns	ns	ns
	OFF	ns	YES	YES	ns	ns	ns	ns
POWERSAVE-TIME	15	ns	YES	YES	ns	ns	ns	ns
	30	ns	(YES)	YES	ns	ns	ns	ns
	60	ns	YES	(YES)	ns	ns	ns	ns
	120	ns	YES	YES	ns	ns	ns	ns
	180	ns	YES	YES	ns	ns	ns	ns
RESOLUTION	300	YES	YES	YES	ns	(RO)	YES	YES
	600	(YES)	(YES)	(YES)	ns	ns	(YES)	(YES)
RESOURCESAVE **	ON	ns	YES	ns	ns	ns	ns	ns
	OFF	ns	YES	ns	ns	ns	ns	ns
	AUTO	ns	YES	ns	ns	ns	ns	ns
RET	OFF	YES	YES	YES	YES	YES	YES	YES
	LIGHT	YES	YES	ns	YES	YES	YES	YES
	MEDIUM	(YES)	(YES)	ns	(YES)	(YES)	(YES)	(YES)
	DARK	YES	YES	ns	YES	YES	YES	YES
	ON	ns	ns	(YES)	ns	ns	ns	ns
TIMEOUT	5 to 300 (15)	YES	YES	YES	ns	YES	YES	YES

* For the LaserJet 4PJ printer, PERSONALITY is a port-specific variable.

** The RESOURCESAVE variable can only be used with the DEFAULT, DINQUIRE, and INQUIRE commands.

Environment Variable	Variable Values	LaserJet Printer with PJJ						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
PCL-Specific Variables								
FONTSOURCE	(I)	YES	YES	YES	YES	YES	YES	YES
	M1,M2,M3 . . Mn	YES	YES	YES	ns	ns	YES	YES
	C	YES	YES	ns	ns	ns	ns	ns
	C1	ns	ns	YES	ns	ns	ns	ns
	C2	ns	ns	YES	ns	ns	ns	ns
	S	YES	YES	YES	YES	YES	YES	YES
FONTNUMBER	(0) to n (maximum value depends on the currently set font source)	YES	YES	YES	YES	YES	YES	YES
PITCH	0.44 to 99.99 (10.00)	YES	YES	YES	YES	YES	YES	YES
PTSIZE	4.00 to 999.75 (12.00)	YES	YES	YES	YES	YES	YES	YES

Environment Variable	Variable Values	LaserJet Printer with PJJ						
		4/4M	4 Plus/ 4MPlus	4Si/ 4SiMx	4L	4ML	4P/ 4MP	4PJ
SYMSET	DESKTOP	YES	YES	YES	YES	YES	YES	YES
	ISO4	YES	YES	YES	YES	YES	YES	YES
	ISO6	YES	YES	YES	YES	YES	YES	YES
	ISO11	YES	YES	YES	YES	YES	YES	YES
	ISO15	YES	YES	YES	YES	YES	YES	YES
	ISO17	YES	YES	YES	YES	YES	YES	YES
	ISO21	YES	YES	YES	YES	YES	YES	YES
	ISO60	YES	YES	YES	YES	YES	YES	YES
	ISO69	YES	YES	YES	YES	YES	YES	YES
	ISOL1	YES	YES	YES	YES	YES	YES	YES
	ISOL2	YES	YES	YES	YES	YES	YES	YES
	ISOL5	YES	YES	YES	YES	YES	YES	YES
	LEGAL	YES	YES	YES	YES	YES	YES	YES
	MATH8	YES	YES	YES	YES	YES	YES	YES
	MSPUBL	YES	YES	YES	YES	YES	YES	YES
	PC8	YES	YES	YES	YES	YES	YES	YES
	PC850	YES	YES	YES	YES	YES	YES	YES
	PC852	YES	YES	YES	YES	YES	YES	YES
	PC8DN	YES	YES	YES	YES	YES	YES	YES
	PC8TK	YES	YES	YES	YES	YES	YES	YES
	PIFONT	YES	YES	YES	YES	YES	YES	YES
	PSMATH	YES	YES	YES	YES	YES	YES	YES
	PSTEXT	YES	YES	YES	YES	YES	YES	YES
	ROMAN8	(YES)	(YES)	(YES)	(YES)	(YES)	(YES)	YES
	VNINTL	YES	YES	YES	YES	YES	YES	YES
	VNMATH	YES	YES	YES	YES	YES	YES	YES
VNUS	YES	YES	YES	YES	YES	YES	YES	

Environment Variable	Variable Values	LaserJet Printer with PJJ						
		4/4M	4 Plus/4MPlus	4Si/4SiMx	4L	4ML	4P/4MP	4PJ
SYMSET	WIN30	YES	YES	YES	YES	YES	YES	YES
	WINL1	YES	YES	YES	YES	YES	YES	YES
	WINL2	YES	YES	YES	YES	YES	YES	YES
	WINL5	YES	YES	YES	YES	YES	YES	YES
	WIN31J	ns	ns	ns	ns	ns	ns	YES
Port-Specific Variables								
RESOURCESAVE SIZE **	0 to max. available memory	ns	YES	ns	ns	ns	ns	ns
ESC/P-Specific Variables								
CARRIAGE-RETURN	(CR)	ns	ns	ns	ns	ns	ns	YES
	CRLF	ns	ns	ns	ns	ns	ns	YES
CHARACTER-SET	(KANA)	ns	ns	ns	ns	ns	ns	YES
	EG	ns	ns	ns	ns	ns	ns	YES
TOPMARGIN	(TM19MM)	ns	ns	ns	ns	ns	ns	YES
	TM6MM	ns	ns	ns	ns	ns	ns	YES
ANKCONDENSE	ON	ns	ns	ns	ns	ns	ns	YES
	(OFF)	ns	ns	ns	ns	ns	ns	YES
FONT	(MSMINCHO)	ns	ns	ns	ns	ns	ns	YES
	MSGOTHIC	ns	ns	ns	ns	ns	ns	YES
PostScript-Specific Variables								
JAMRECOVERY	(OFF)	ns	YES	YES	ns	ns	ns	ns
	ON	ns	YES	YES	ns	ns	ns	ns
PRTPSERRS	(OFF)	YES	YES	YES	ns	YES	YES *	ns
	ON	YES	YES	YES	ns	YES	YES *	ns

* PostScript is an optional upgrade on the HP LaserJet 4P printer.

** The RESOURCESAVESIZE variable can only be used with the DEFAULT, DINQUIRE, and INQUIRE commands.

HP LaserJet IIISi Comments

The LaserJet IIISi printer implements the three PJJ kernel commands: ENTER, COMMENT, and the UEL command.

As with other PJJ printers, the HP LaserJet IIISi printer performs explicit printer language switching using the ENTER command. To enable the printer for language switching, the SYS SWITCH control panel setting must be set to ON. To select a default printer language for implicit switching, set SYS = to the desired language (PCL or PostScript) from the control panel. The LaserJet IIISi printer does not perform context switching.

The HP LaserJet IIISi printer does not support any PJJ status readback commands, environment variable commands, or device attendance commands.

For an example that uses the PJJ features found in the HP LaserJet IIISi printer, see the “Using the ENTER Command” example in Chapter 4.

HP LaserJet 4 Family Comments

This section explains some important points that should be considered when using PJL with the LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4L, 4ML, 4P, 4MP, or 4PJ printers. Support for the features described in this section varies. The HP LaserJet 4 family printers that support a particular feature are listed at the beginning of each feature description.

Printer Language Switching

Printers supporting printer language switching:
HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P, 4MP, 4PJ

Printers that perform context switching automatically switch printer languages when both of the following conditions are met:

- The PJL “PERSONALITY” environment variable is set to AUTO.
- The print job contains printable data but does not contain a PJL ENTER LANGUAGE command immediately before the printable data.

Note



The LaserJet 4PJ printer performs implicit language switching, but not context switching.

Under these conditions, the printer samples the incoming printable data and looks for indications of a particular printing language. Once it recognizes the printer language, the printer backs up to the beginning of the sampled print data and switches to the printer language determined to be most appropriate. Then the printer begins to parse the data in the newly selected printer language.

Although the printer can accurately select printer languages this way, we recommend that every job containing printable data include an ENTER LANGUAGE command to explicitly switch to the correct printer language. This method improves

performance and eliminates errors in printer language switching. It also guarantees that the correct language is always selected.

Printer Status Readback

Printers supporting printer status readback:
HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4L, 4ML, 4P, 4MP, 4PJ

HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4L, 4ML, 4P, 4MP, 4PJ

When requesting status information from the printer, ignore all status information that you did not request. For example, if you request INFO ID and get USTATUS or some other response, ignore that response and read the next one until you receive the INFO ID response.

Due to other printer users in a multi-user system, there may be situations where the printer status buffer overflows, and instead of receiving requested status information, you receive the 10010 error. (For the LaserJet 4 family printers except for the LaserJet 4PJ, the 30010 error is returned for “buffer overflow” instead of the normal 10010 error code. The LaserJet 4PJ returns the 10010 error code.) Reading the 10010 or 30010 error clears the status buffer; if you receive either error, resend the status request.

Commands That Affect Printer Memory

Printers which reconfigure memory due to PJJ commands:
HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P, 4MP, 4PJ

HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P, 4MP, 4PJ

Three conditions may cause the printer to reconfigure user memory:

- When the printer language changes, either explicitly by using the ENTER command, or implicitly.
- When the page protection setting changes, either using the SET, DEFAULT, RESET, or INITIALIZE commands, or the control panel.

- When the resolution is changed using either the SET or DEFAULT commands, or by using the control panel.

Reconfiguring printer memory erases all volatile personality-specific resource information, including downloaded fonts, PCL macros, and PostScript dictionaries (however no I/O data is lost). Memory can be reconfigured only when these conditions actually change the page protection, resolution, or printer language status. For example, if the resolution is at 600 dpi and an application sends the @PJL SET RESOLUTION = 600 command, memory is not reconfigured.

If resource saving is enabled, memory is reconfigured, but all volatile personality-specific resource information (such as fonts, macros, and PostScript dictionaries) are not lost (HP LaserJet 4Si/4SiMx printers only).

Resource Saving

Printers that support resource saving:
HP LaserJet 4 Plus, 4M Plus, 4Si, 4SiMx

Resource saving is a feature that allows you to prevent loss of permanent resources (such as fonts, macros, and PostScript dictionaries) when the printer language, page protection, or resolution status changes. Resource saving is configured from the control panel.

Printer-Specific Job Boundaries

Printers that support PJJ job boundaries:
HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P, 4MP, 4PJ

The printers listed above handle the following conditions as PJJ job boundaries. When any of these conditions occur, the User Default Environment values are loaded into the PJJ Current Environment, which then are loaded into the Modified Print Environment.

- Control panel reset
- Printer language-specific exit command, such as ^D for PostScript. (Printer language-specific exit commands are not job boundaries when within a PJJ JOB/EOJ command pair.)
- Data stream idle timeout (this occurs when a PJJ job is in progress and there is no data received over the I/O for a specified length of time). To avoid a timeout, use the PJJ JOB or ENTER LANGUAGE commands, since using the JOB or ENTER commands increases the time the printer waits for I/O data. This increase is because the printer is processing a job with clearly indicated start-of-job and end-of-job data stream commands. See the following “Timeouts” section.
- Using the control panel to perform a self test, or to print a typeface list or demo page.
- A job boundary indicated by the I/O card, such as the AppleTalk end-of-file.

Timeouts

Printers that support the TIMEOUT variable:
HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P, 4MP, 4PJ

HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4ML, 4P, 4MP, 4PJ

These printers have a timeout capability which is used to recover when jobs are interrupted by situations such as power failures. The timeout duration varies depending on the data received by the printer.

The TIMEOUT variable set using PJL or the control panel establishes the job timeout duration for those jobs that do not contain JOB or ENTER LANGUAGE commands. For jobs that do contain the JOB or ENTER LANGUAGE commands, the printer uses an extended timeout duration, which is equal to five minutes or ten times the TIMEOUT value, whichever is greatest.

Backward-Compatibility Mode

Printers that support the backward-compatibility mode:
HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4L, 4ML, 4P, 4MP, 4PJ

HP LaserJet 4, 4M, 4 Plus, 4M Plus, 4Si, 4SiMx, 4L, 4ML, 4P, 4MP, 4PJ

If the printer detects PCL data immediately after a job boundary, it enters a backward-compatibility mode that responds like an HP LaserJet III printer. This lasts until the next job boundary is detected. For backward-compatibility mode to occur, the PERSONALITY variable must be set to AUTO or PCL, and the job must contain only PCL data—if any PJL commands are received during the job, the printer does not enter backward-compatibility mode.

There are two differences between backward-compatibility mode and normal operating mode. In backward-compatibility mode, when a PCL printer language reset (<ESC>E) is executed, instead of causing the PJL Current Environment variables to be loaded into the Modified Print Environment, the User Default Environment settings (control panel values) are loaded. This is the same way the LaserJet III printer works.

Note



The LaserJet 4L printer, since it does not support job boundaries (JOB/EOJ), always loads the PJL Current Environment variables into the Modified Print Environment after receiving an <ESC>E reset.

Also, when a backward-compatible job ends with a partial page (one not terminated with a form feed or PCL printer language reset) and the job times out, the job does not immediately end, printing the partial page. Instead, the printer waits to see if the next job sent consists of more PCL data (from the same I/O port), which it then appends to the partial page already in the printer. (This works the same way as the LaserJet III printer, which does not have a job timeout.) If PJL data is received instead, the partial page is printed before the new PJL job is executed.

PJL Job Security

Printers that support PJL job security:
HP LaserJet 4 Plus, 4M Plus, 4Si, 4SiMx

The printers listed above provide two PJL security features: password protection and control panel lockout. As discussed in Chapter 5, the DEFAULT command can be used to set a PJL password. Once the password is set, all succeeding jobs must issue the correct password in order to enable the DEFAULT and INITIALIZE commands. The password can only be changed from within a secure PJL job.

The control panel can also be “locked out” so that users cannot modify settings using the control panel keys. This is accomplished using the DEFAULT command to set the CPLOCK variable to ON. For more information, see “PJL Job Security” in Chapter 5.

LaserJet Printers Without a Control Panel

The LaserJet 4L and 4ML printers have no control panel. These printers have several features that are different than those of other PJJ printers. This section describes those differences and how they affect the use of PJJ.

- No device attendance commands are supported—these printers rely on unsolicited status to communicate with the user.
- No NVRAM (LaserJet 4L only)—since this printer is designed to conserve energy and does not have a power switch, it is never turned off. Therefore, it does not need NVRAM to store feature settings. To simulate a power cycle, use the RESET command to initialize all PJJ variables except PAPERSIZE.
- No multiple I/Os or job boundaries supported (LaserJet 4L only)—this printer is designed for single-user environments. It does not support I/O switching or the concept of job boundaries. Therefore, the JOB and EOJ commands are not supported.
- No multiple language support (LaserJet 4L only)—there is no support for multiple printer languages. PCL 5 is the sole printer language. Even though there is only one language, use the PJJ ENTER LANGUAGE command to specify PCL.
- EconoMode—the LaserJet 4L and 4ML printers both support EconoMode, a toner-saving feature that produces draft-like pages when top-quality printing is not necessary.

PJL Command Summary

COMMENT

```
@PJL COMMENT <words> [<CR>]<LF>
```

DEFAULT

```
@PJL DEFAULT [LPARM : personality | IPARM : port]  
↳variable = value [<CR>]<LF>
```

DINQUIRE

```
@PJL DINQUIRE [LPARM : personality | IPARM : port]  
↳variable [<CR>]<LF>
```

Response

```
@PJL DINQUIRE [LPARM:personality | IPARM:port]  
↳variable <CR><LF>  
value <CR><LF>  
<FF>
```

ECHO

```
@PJL ECHO [<words>] [<CR>]<LF>
```

Response

```
@PJL ECHO [<words>] <CR><LF>  
<FF>
```

ENTER

```
@PJL ENTER LANGUAGE = personality [<CR>]<LF>
```

EOJ

@PJL EOJ [NAME = "*job name*"] [<CR>]<LF>

INFO

@PJL INFO *category* [<CR>]<LF>

Response

@PJL INFO *category* <CR><LF>
[1 or more lines printable characters or <WS> followed by <CR><LF>]
<FF>

INITIALIZE

@PJL INITIALIZE [<CR>]<LF>

INQUIRE

@PJL INQUIRE [LPARM : *personality* | IPARM : *port*]
↳*variable* [<CR>]<LF>

Response

@PJL INQUIRE [LPARM:*personality* | IPARM:*port*]
↳*variable* <CR><LF>
value <CR><LF>
<FF>

JOB

@PJL JOB [NAME="*job name*"][START=*first page*][END=*last page*]
↳[PASSWORD = *number*] <CR><LF>

OPMSG

@PJL OPMSG DISPLAY = "*message*" [<CR>]<LF>

PJL

@PJL [<CR>]<LF>

RDYMSG

@PJL RDYMSG DISPLAY = "message" [<CR>]<LF>

RESET

@PJL RESET [<CR>]<LF>

SET

@PJL SET [LPARM : *personality* | IPARM : *port*]
variable = value [<CR>]<LF>

STMSG

@PJL STMSG DISPLAY = "message" [<CR>]<LF>

Response

@PJL STMSG DISPLAY="message" <CR><LF>
key <CR><LF>
<FF>

UEL

<ESC>%-12345X

USTATUS

@PJL USTATUS variable = value [<CR>]<LF>

Unsolicited Status Message (not a response, but returned when printer events occur)

@PJL USTATUS variable <CR><LF>
[1 or more lines of printable characters or <WS> followed by <CR><LF>]
<FF>

USTATUSOFF

@PJL USTATUSOFF [<CR>]<LF>

Programming Examples

Introduction

This appendix demonstrates two examples: one PJJ example using the C programming language, and one simple batch file. The first example is listed on the left-facing page in the generic format used throughout the rest of the manual. The C code is then listed on the opposite page so that you can compare the C code with the generic code. The second example is a batch file that demonstrates the use of the RDYMSG command to create your own “ready” message while printing your job.

Example: Switching Printer Languages

The job in this example prints two pages: one in PCL and one in PostScript. The program first enters PCL, and then immediately enters HP-GL/2 to draw a box and print "PCL Print Job." Next, PostScript is entered and PostScript data is sent to the printer to draw a box and print "PostScript Job."

```
<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT **Beginning of PCL Job** <CR><LF>
@PJL COMMENT **Enter PCL (& HP-GL/2)* <CR><LF>
@PJL ENTER LANGUAGE = PCL <CR><LF>
<ESC>E<ESC>%0BIN;SP1;PA1010,1010;PW2.2;
↳PD5310,1010,5310,5310,1010,5310,1010,1010;
↳PU;PA2280,3040;
↳SD1,277,2,1,4,20,5,0,6,0,7,4148;
↳DT*;SS;LBPCL Print Job*;
↳<ESC>%0A<FF><ESC>E
↳<ESC>%-12345X@PJL <CR><LF>
@PJL COMMENT *** END OF PCL JOB & *** <CR><LF>
@PJL COMMENT ** START OF POSTSCRIPT * <CR><LF>
@PJL ENTER LANGUAGE = POSTSCRIPT <CR><LF>
5 setlinewidth<CR>
100 100 moveto<CR>
0 300 rlineto<CR>
300 0 rlineto<CR>
0 -300 rlineto<CR>
closepath<CR>
stroke<CR>
185 240 moveto<CR>
/Helvetica findfont 20 scalefont setfont<CR>
(PostScript Job) show<CR>
showpage<CR>
^D
↳<ESC>%-12345X
```



```

/*****
/*      SWITCH.C (Switching Printer Languages)      */
/*****
#include <stdio.h>
main()
{
    FILE *prn; /* initialization section */
    /***** open PRN for writing *****/
    prn = fopen("lpt1","wb");
    /***** Send UEL command and @PJL<CR><LF> *****/
    fprintf(prn,"\033%-12345X@PJL \n");
    fprintf(prn,"@PJL COMMENT **Beginning of PCL Job** \n");
    fprintf(prn,"@PJL COMMENT **Enter PCL (& HP-GL/2)* \n");
    fprintf(prn,"@PJL ENTER LANGUAGE = PCL \n");
    fprintf(prn,"\033E\033%OBIN;SP1;PA1010,1010;PW2.2;");
    fprintf(prn,"PD5310,1010,5310,5310,1010,5310,1010,1010;");
    fprintf(prn,"PU;PA2280,3040;");
    fprintf(prn,"SD1,277,2,1,4,20,5,0,6,0,7,4148;");
    fprintf(prn,"DT*;SS;LBPCL Print Job*"); /** Print text **/
    fprintf(prn,"\033%0A\f\033E"); /*Exit HP-GL/2, <FF>, <Esc>E*/
    fprintf(prn,"\033%-12345X@PJL \n"); /** UEL & @PJL ***/
    fprintf(prn,"@PJL COMMENT *** END OF PCL JOB & *** \n");
    fprintf(prn,"@PJL COMMENT ** START OF POSTSCRIPT * \n");
    fprintf(prn,"@PJL ENTER LANGUAGE = POSTSCRIPT \n");
    fprintf(prn,"5 setlinewidth\r"); /** PostScript Code **/
    fprintf(prn,"100 100 moveto\r");
    fprintf(prn,"0 300 rlineto\r");
    fprintf(prn,"300 0 rlineto\r");
    fprintf(prn,"0 -300 rlineto\r");
    fprintf(prn,"stroke\r");
    fprintf(prn,"185 240 moveto\r");
    fprintf(prn,"/Helvetica findfont 20 scalefont setfont\r");
    fprintf(prn,"(PostScript Job) show\r"); /** Print text **/
    fprintf(prn,"showpage\r");
    fprintf(prn,"\004"); /** ^D *****/
    fprintf(prn,"\033%-12345X"); /** UEL Command ***/

    fclose(prn);
}

```

Notice the %% required to print the %

Example: Using RDYMSG in a Batch File

This example demonstrates how to use a batch file to send PJJL commands to the printer. In this example, the batch file acts as a spooler, using the RDYMSG command to display the file name while a print file is being downloaded.

To send PJJL commands this way, first create an ASCII file named UEL, containing only the UEL command (<ESC>%-12345X). In this file, be sure to substitute ASCII character 27, the escape character, for <ESC>, and do not add any spaces or characters after the X.

Then create a batch file as shown here, and save it as PRINTPJJL.BAT, in the same directory as the "UEL" file. The batch file uses the DOS ECHO command to send PJJL commands, and the DOS COPY command with the binary option to send the UEL file and the pre-existing print file to the printer.

```
@ECHO OFF
CLS
ECHO Printing the %1 Job!
COPY UEL /B PRN:
ECHO @PJJL > PRN:
ECHO @PJJL JOB > PRN:
ECHO @PJJL RDYMSG DISPLAY = "%1" > PRN:
ECHO @PJJL ENTER LANGUAGE = PCL > PRN:
COPY %1 /B PRN:
COPY UEL /B PRN:
ECHO @PJJL COMMENT Restore READY message > PRN:
ECHO @PJJL RDYMSG DISPLAY = "" > PRN:
ECHO @PJJL EOJ > PRN:
COPY UEL /B PRN:
@ECHO ON
```

To use this batch file, type the name of the batch file, followed by the name of the print file, as follows:

```
PRINTPJJL printfilename
```

The *printfilename* is displayed while the job is being downloaded to the printer.

PJL Status Codes

The status codes listed in this appendix are sent to the host in many of the status readback responses as “CODE = xxxxx,” where each “x” stands for a single digit 0 through 9. For example, if unsolicited status is enabled and the toner runs low, the following message is returned:

```
@PJL USTATUS DEVICE
CODE=10006
DISPLAY="16 TONER LOW"
ONLINE=TRUE
```

If you consult the status code table, code 10006 means “toner low.” Note that since the string portion of the “DISPLAY=string” is localized, developers should use the “CODE=” value in applications.

Status Code Groupings

PJL status codes are grouped as follows, with the first two digits indicating a message category:

- Informational Messages (10xxx)
- Background Paper Mount (11xyy)
- PJL Parser Errors (20xxx)
- PJL Parser Warnings (25xxx)
- PJL Semantic Errors (27xxx)
- Auto-Continuable Conditions (30xxx)
- Possible Operator Intervention Conditions (35xxx)
- Operator Intervention Required (40xxx)
- Foreground Paper Mount (41xyy)
- Hardware Errors (50xxx)

The following pages list the status codes in numerical order, by groups. For a complete description of each control panel display string, see the user and service manuals for each printer.

Informational Messages (10xxx) *

Status Code	Control Panel Display String or Code Meaning
10001	00 READY (online) [Personality-specific ready message] (online) [PJL RDYMSG] (online) 68 READY/SERVICE (online)
10002	00 READY (offline) or [Personality-specific ready message] (offline) or [PJL RDYMSG] (off-line) or 68 READY/SERVICE (offline). Form-feeding printable data due to key press
10003	02 WARMING UP or initializing (DesignJet)
10004	05 SELF TEST
10005	07 RESET
10006	16 TONER LOW
10010 **	STATUS BUFFER OVERFLOW
10011	18 AUX IO INIT or 18 AUX IO NT RDY or 18 MIO INIT or 18 MIO NOT RDY
10013	04 SELF TEST
10014	06 PRINTING TEST
10015	06 TYPEFACE LIST
10016	15 ENGINE TEST
10017	06 DEMO PAGE
10018	09 MENU RESET
10019	09 RST ACTIVE IO
10020	09 RESET ALL I/O
10021	08 COLD RESET
10022	06 CONFIG PAGE

* All of these messages are localized. They appear in the currently selected language as displayed on the control panel.

** If creating applications for the HP LaserJet 4 family of printers, see “Printer Status Readback” in the “HP LaserJet 4 Family Comments” section in Appendix A.

Background Paper Loading (11xyy)

Background paper loading messages appear when a paper input source is out of paper, but another paper source is available and loaded with the correct paper size. The printer stays online in these situations since it can switch to the other paper source. (“Foreground” paper loading messages are sent when there are no alternate paper sources loaded with the same size paper. The printer goes offline and waits for someone to load paper. Foreground error messages are listed later in the chapter [41xyy].)

Background paper loading messages are in the format 11xyy. The following tables list the X and Y values for these messages. For example, 11202 is a background paper loading message indicating to load the PC tray with letter-size paper.

X = Tray Code	Tray
0	MP Tray
1	Manual Feed
2	PC Tray or Upper Cassette
3	LC Tray or Lower Cassette
4	EE Tray

YY = Media Code	Media Size
00	Unknown Paper
01	Unknown Envelope
02	Letter Paper
03	Legal Paper
04	A4 Paper
05	Exec Paper
06	Ledger Paper
07	A3 Paper
08	COM10 Envelope

09	Monarch Envelope
10	C5 Envelope
11	DL Envelope
12	B4 Paper
13	B5 Paper
14	B5 Envelope
15	Custom media
16	Japanese postcard (Hagaki)
17	Japanese round-trip postcard (Oufuku-Hagaki)

PJL Parser Errors (20xxx)

These status codes denote PJL parser errors. The entire PJL command line is ignored. (Some of the status codes refer to portions of PJL commands such as “command modifiers” and “alphanumeric values.” For a description of the PJL command format, see “Format of PJL Commands” in Chapter 2.)

20001	Generic syntax error (entire PJL command ignored)
20002	Unsupported command
20004	Unsupported personality, system, or I/O port
20005	PJL command buffer overflow
20006	Illegal character or line terminated by the Universal Exit Language command
20007	<WS> or [<CR>]<LF> missing after closing quotes
20008	Invalid character in an alphanumeric value
20009	Invalid character in a numeric value
20010	Invalid character at the start of a string, alphanumeric value, or numeric value

20011	String missing closing double-quote character
20012	Numeric value starts with a decimal point
20013	Numeric value does not contain any digits
20014	No alphanumeric value after command modifier
20015	Option name and equal sign encountered, but the value field is missing
20016	More than one command modifier
20017	Command modifier encountered after an option (command modifier must precede option)
20018	Command not an alphanumeric value
20019	Numeric value encountered when an alphanumeric value expected
20020	String encountered when an alphanumeric value expected
20021	Unsupported command modifier
20022	Command modifier missing
20023	Option missing
20024	Extra data received after option name (used for commands like SET that limit the number of options supported)
20025	Two decimal points in a numeric value

PJL Parser Warnings (25xxx)

This group of status codes denote PJL parser warnings, which indicates that part of the PJL command is ignored.

25001	Generic warning error (part of the PJL command ignored)
25002	PJL prefix missing
25003	Alphanumeric value too long
25004	String too long
25005	Numeric value too long
25006	Unsupported option name
25007	Option name requires a value which is missing
25008	Option name requires a value of a different type
25009	Option name received with a value, but this option does not support values
25010	Same option name received more than once
25011	Ignored option name due to value underflow or overflow
25012	Value for option experienced data loss due to data conversion (value truncated or rounded)
25013	Value for option experienced data loss due to value being out of range; the value used was the closest supported limit
25014	Value is of the correct type, but is out of range (value was ignored)
25016	Option name received with an alphanumeric value, but this value is not supported
25017	String empty, option ignored

PJL Semantic Errors (27xxx)

This group of status codes denote PJL semantic errors. As much of the command is executed as possible, depending on the current configuration of the printer.

27001	Generic semantic error
27002	EOJ command encountered without a previously matching JOB command. An EOJ command does not have a matching JOB command if the number of valid EOJ commands received is greater than the number of valid JOB commands received.
27004	Cannot modify the value of a read-only variable.
27005	Can only use DEFAULT with this variable; cannot use SET.

Auto-Continuable Conditions (30xxx)

This list specifies the set of PJJ error codes and corresponding control panel display strings for auto-continuable conditions. If no action is taken, the device automatically continues if auto-continue is set to true (except for 30035 and 30036 errors).

Status Code	Display String or Code Meaning
30010 *	STATUS BUFFER OVERFLOW
30016	20 MEM OVERFLOW
30017	21 PRINT OVERRUN
30018	40 ERROR
30027	22 I/O CONFIG ERROR
30034	41.x ERROR
30035	68 ERROR
30036	68 SERVICE
30072	49 REMOVE PAGE
30076	PERSONALITY MEMORY OVERFLOW/ OUT OF MEMORY

* If creating applications for the HP LaserJet 4 Family printers, see “Printer Status Readback” in the “HP LaserJet 4 Family Comments” section in Appendix A.

Potential Operator Intervention Conditions (35xxx)

This list specifies the set of PJJ error codes and corresponding control panel display strings for conditions where operator intervention may be required. The device says “online” and continues to operate, possibly with reduced functionality. Data may be lost.

Status Code	Display String or Code Meaning
35029	W1 IMAGE ADAPT
35031	W2 INVALID PERS
35037	W3 JOB ABORTED
35039	W9 JOB 600/LTR
35040	W0 JOB 600/A4
35041	W8 JOB 600/OFF
35042	W7 JOB 300/LGL
35043	W5 JOB 300/LTR
35044	W6 JOB 300/A4
35045	W4 JOB 300/OFF
35073	CHECK MEMORY MANAGEMENT
35074	MEMORY MANAGEMENT NOT AVAILABLE
35075	USER MAINTENANCE REQUESTED
35076	PERSONALITY MEMORY OVERFLOW/ OUT OF MEMORY
35078	Printer has entered powersave mode (00 POWERSAVE)
35081	WM JOB 300

Operator Intervention Conditions (40xxx)

This list specifies the set of PJJ error codes and corresponding control panel display strings for conditions where operator intervention is required. Printing cannot continue until the condition is resolved.

Status Code	Display String or Code Meaning
40000	SLEEP MODE (STANDBY) *
40005	Cartridge error during align cartridges or reading setup sheet (DesignJet)
40010	14 NO EP CART or no electrical contact with one or more ink cartridges (DesignJet)
40011	Accessing ink cartridges (DesignJet)
40020	NO MICR TONER
40021	12 PRINTER OPEN OR NO EP CART or lower lever or lower window (DesignJet)
40022	13 PAPER JAM
40024	FE CARTRIDGE
40026	PC INSTALL
40038	16 LOW TONER
40046	FI INSERT CART
40047	FR REMOVE CART
40048	[PJJ OPMSG]
40049	[PJJ STMSG]
40050	50 SERVICE
40051	51 ERROR
40052	52 ERROR
40053	53-xy-zz ERROR
40054	54 ERROR
40055	55 ERROR

* This is not an error. The printer is waiting for data.

Status Code	Display String or Code Meaning
40056	56 ERROR
40057	57 SERVICE
40058	58 SERVICE
40059	59 ERROR
40061	61.x SERVICE
40062	62.x SERVICE
40063	63 SERVICE
40064	64 SERVICE
40065	65 SERVICE
40067	67 SERVICE
40068	69 SERVICE
40069	70 ERROR
40070	71 ERROR
40071	72 SERVICE
40079	PRINTER MANUALLY TAKEN OFFLINE
40080	EE INCOMPATIBLE or LC INCOMPATIBLE

Foreground Paper Loading (41xyy)

Foreground paper loading messages are sent when one of the paper input sources is out of paper and there is no other input source available and loaded with the correct paper size. When this occurs, the printer goes offline until someone loads paper.

The messages are in the format 41xyy. The following tables list the X and Y values for these messages. For example, 41303 is a foreground paper loading message indicating to load the LC tray with legal-size paper.

X = Tray Code	Tray
0	MP Tray or Envelope Tray
1	Manual Feed
2	PC Tray
3	LC Tray
4	EE Tray

YY = Media Code	Media Size
00	Unknown Paper
01	Unknown Envelope
02	Letter Paper
03	Legal Paper
04	A4 Paper
05	Exec Paper
06	Ledger Paper
07	A3 Paper
08	COM10 Envelope
09	Monarch Envelope
10	C5 Envelope
11	DL Envelope
12	B4 Paper

13	B5 Paper
14	B5 Envelope
15	Custom Media
16	Japanese postcard (Hagaki)
17	Japanese round-trip postcard (Oufuku-Hagaki)

Hardware Errors (50xxx)

These status codes are sent out when a hardware problem exists and a printer is working well enough to send status messages.

Status Code	Display String or Code Meaning
50000	General Hardware Failure
50001	ROM Error, ROM Checksum Failed (or interface error [DesignJet])
50002	RAM Error, RAM Test Failed (or part malfunction [DesignJet])
50003	Engine Fuser Error
50004	Engine Beam Detect Error
50005	Engine Scanner Error
50006	Engine Fan Error
50007	Engine Communications Error
505xx	Firmware Error, Power Cycle
50599	Processor Error, Power Cycle

Glossary

↳

This character indicates that the current command line is a continuation of the previous line. For example, “These words are all part of the same line.”

|

The vertical bar, when shown in a command, indicates that either one or the other options may be selected, but not both.

Active I/O Port

The I/O port which is providing the data for the current print job. For LaserJet printers with automatic I/O switching, if there is no current print job, then automatic I/O switching is enabled and all I/O ports are active.

Auto-Continue

If the auto-continue mode is configured to ON, the printer continues printing during certain non-fatal error conditions. If auto-continue is OFF and these same conditions occur, the printer goes off-line until the Continue or On Line key is pressed. Auto-continue mode can be configured using the printer’s control panel or using PJI commands (refer to the user’s manual for the specific PCL 5 printer).

Automatic I/O Switching

Automatic I/O switching allows data to be sent to any of the printer's I/O ports without reconfiguring the active I/O port from the control panel.

When the printer is turned on, all I/O ports are enabled to accept data. The first port to receive data is called the active I/O port. The active I/O port is the source for the current print job. All other I/O ports temporarily are disabled until the next job boundary.

After a job boundary is encountered and there is no data available from the active I/O port, all the I/O ports are enabled and checked for available data. The first port to receive data is the new active I/O port. The other ports are temporarily disabled, the print job processed, and then the automatic I/O switching process repeats.

Configuration

Configuration is the process of changing printer settings. The printer is configured using the control panel or PJI.

Context-Sensitive Printer Language Selection

Context-sensitive printer language selection is a method of selecting a printer language by looking at the first portion of a job to discover clues as to which printer language to use. The syntax differences in each printer language allow the language to be determined. Context-sensitive language selection is only operational if the control panel variable PERSONALITY is set to AUTO and the print job does not contain a PJI ENTER command before non-PJI data.

Control Code

A control code is a non-printable ASCII character that initiates a printer function, for example carriage return (<CR>), line feed (<LF>), and form feed (<FF>).

Default

A value used instead of a programmatically selected value. A factory default is a value programmed into the printer at the factory; this value is stored in read-only memory and cannot be changed by a user or operator. A user default is a default value, stored in non-volatile RAM (in printers that have NVRAM), that is selectable using the control panel or the PJI DEFAULT command.

Download

The process of transferring data, including soft fonts, macros, or raster data from a host computer to the printer.

Environment

See “Print Environment.”

Explicit Switching

Explicit switching occurs when a printer language is activated due to processing a PJI ENTER command.

Factory Default

Factory defaults refer to the feature settings that are programmed into the printer at the factory. These values are stored in read-only memory and cannot be changed. Factory default settings are in use unless you override them using either the control panel or by sending printer commands.

Factory Default Environment

A factory default is a setting programmed into the printer at the factory. The group of all the printer's factory settings is referred to as the Factory Default Environment.

Implicit Switching

Implicit switching occurs when a printer language is activated due to reception of non-PJL data which is not preceded by a PJL ENTER command. (See context-sensitive printer language selection.)

Job Boundary

The beginning or end of a print job. The position between two characters of data in the data stream where the previous character is the last character of the previous print job, and the next character is the first character of the next print job.

Macro

A macro is a collection of escape sequences, control codes, and data downloaded to the printer. Its execution can be initiated using a single command.

Modified Print Environment

Once a printer language, such as PCL, is entered, the current feature settings constitute the modified print environment. Whenever a feature setting is altered using printer language commands, the new setting is recorded in the Modified Print Environment.

Non-Printing Mode

Printing selective pages in a print job by sending the entire print job, the desired starting page number, and the ending page number. The PJL JOB command options START and END are used to provide the starting page number and the ending page number. When the printer processes the pages that are not printed, the printer is said to be in non-printing mode.

Non-Volatile Memory

Random Access Memory where contents are preserved when the printer is powered off (volatile RAM is memory where contents are not preserved when the device is powered off).

Offline/Online

Online is a condition during which the printer accepts data from the host computer. When the printer is online, the ON LINE light is lit. When offline, the printer can not accept data from the host.

Personality

The printer firmware related to transforming a particular type of printer language data, like PCL or PostScript, into images that the printer's operating system can print. The printer uses different personalities (different firmware) to handle data from different printer languages. PCL and PostScript commands are each processed by separate firmware.

New personalities can be added to some LaserJet printers using means such as cartridges or ROM SIMMs. PJJ is not a personality (you cannot print using PJJ). See "Personality Switching."

Personality Switching

The process of shutting down the current personality and activating the appropriate personality to process the next print job. For example, when the printer is processing PCL data, the PCL personality is activated; for PostScript data, the PostScript personality is activated.

PJJ Current Environment

The PJJ Current Environment is the set of features that is active when a PJJ job is entered. As soon as a PJJ job is entered, the PJJ Current Environment settings are the same as the User Default Environment. Applications then can modify the PJJ Current Environment values

using the PJJ SET command. The PJJ Current Environment provides a base set of values when entering a printer language.

PJJ Job

A PJJ job is any print job containing PJJ commands. Properly formed PJJ jobs always begin and end with the UEL command.

PJJ Reset Condition

A PJJ reset condition prompts the printer to load the User Default values into the PJJ Current Environment, which are then loaded into the Modified Print Environment. In this document, the term PJJ reset condition refers to any of the following events: a power-on, UEL command (when not between a JOB/EOJ command pair), the @PJJ INITIALIZE, @PJJ RESET, @PJJ JOB, or @PJJ EOJ commands. Also included are other printer-specific events, such as control panel reset, a printer language-specific exit command (when not between a JOB/EOJ pair), such as ^D for PostScript, and data stream idle timeouts (see Appendix A for information about job boundaries and timeouts for the HP LaserJet 4 Family printers.)

Poorly Formed Print Job

A print job which either starts or ends with an invalid data stream sequence. For example, any job that does not begin *and* end with a UEL command is a poorly formed job. This manual describes how to create properly formed print jobs and contains many examples to demonstrate them. See Chapters 1 through 3 and Chapter 9 for more information about creating well-formed jobs.

Print Environment

The group of all the printer's current feature settings, collectively, is referred to as the print environment. The print environment is modified using printer commands and control panel settings.

Printer Language

A set of syntax and semantic rules used to control a printer. PCL and PostScript are both printer languages—they both contain commands that enable the user to control where marks are printed on a page. See “PDL.”

Ready Message

A ready message is displayed on the control panel display when no error conditions are present. When errors occur, an error message replaces the ready message until the situation is corrected or the printer auto-continues. The PJL RDYMSG command is used to specify a ready message to replace the “00 READY” message.

Secure PJL Job

A “secure” PJL job is a job that contains the correct password in the JOB command. For the LaserJet 4Si printer, secure jobs are able to use the DEFAULT and INITIALIZE commands. (The LaserJet 4Si is the only printer that supports the password option of the JOB command.)

Solicited Status

Solicited status is printer status information that is specifically requested. For example, the command @PJL INFO ID solicits the printer's ID. The printer responds to solicited status messages as they are received. See “unsolicited status.”

Status Readback

Sending printer status information from the printer to the host computer.

Universal Exit Language (UEL) Command

A PJL command, understood by all LaserJet personalities, that prompts the active personality to finish processing the current job and exit the personality. PJL also recognizes the UEL command and, when received, PJL discards any unprocessed partial PJL command and prepares to accept the next PJL command.

Unsolicited Status

Unsolicited status (USTATUS) is printer status information sent as a result of certain printer events occurring, such as when the printer runs out of paper, a job finishes printing, or when a certain time period elapses. There are several types of unsolicited status (DEVICE, JOB, PAGE, and TIMED); unsolicited status must be enabled with the USTATUS command.

User Default

A user default is a default value that is selectable by way of the operator control panel or the PJL DEFAULT command.

User Default Environment

The User Default Environment consists of the user default settings selected from the control panel or by way of the PJL DEFAULT command. The user default settings are stored in non-volatile memory (in those printers that have NVRAM). Those settings not selected using the control panel or PJL DEFAULT command are set to the factory default values.

Index

- !
- 10010 error 9-26
- ➔ (line continuation character) 2-1, G-1
- | (vertical bar) 2-1, G-1
- @PJL 2-4
- ^D 2-2

- A**
- active I/O port G-1
- alphanumeric variables 2-6
- ANKCONDENSE variable 6-23
- application design ideas 9-28
- application developers iii
- auto-continuable conditions D-8
- auto-continue G-1
- AUTOCONT variable 6-11
- automatic I/O switching G-2

- B**
- background paper loading D-3
- backward-compatibility mode A-18
- batch file example C-4
- Bi-Tronics interface 9-20
- BINDING variable 6-11
- blank lines 3-2
- buffer overflow 9-25, A-15

- C**
- C programming language C-1, C-3
- carriage return character (CR) 2-2
- CARRIAGERETURN variable 6-23
- CHARACTERSET variable 6-23
- CLEARABLEWARNINGS variable 6-11
- command
 - format 2-3
 - modifier 2-3
 - summary 3-5, B-1
- commands grouped by application 3-5
- COMMENT command 4-6
 - example 4-7
- compatibility of PJL 1-3
 - with LaserJet III A-18
 - with PCL 1-4
 - with PostScript 1-4
- configuration G-2
 - information, requesting 7-18
- configuration status 7-1
- context switching 4-8
- context-sensitive printer language selection G-2
- context-sensitive switching 4-3
- Continue key 6-11
- control codes 2-2, G-2
 - lock 5-9
 - messages, changing 8-1
 - settings 3-3
- conventions, manual 2-1
- COPIES variable 6-12
- CPLOCK variable 5-9, 6-12
- CR (carriage return character) 2-2
- current environment 6-2

- D**
- default G-3
- DEFAULT command 2-4, 6-3, 6-7, 6-9, 6-26
 - example 6-29
- default variables 7-9
- DENSITY variable 6-12
- design ideas 9-28
- DesignJet 1-3
- DesignJet family A-3
- DeskJet 1200C printer A-3
- device attendance commands 8-1
- device status 7-31
- DEVICE variable 7-31
- DINQUIRE command 7-9
 - example 7-12
 - example, language-specific 7-13
- document conventions 2-1
- download G-3
- DUPLEX variable 6-12

- E**
- ECHO command 7-2, 7-14, 9-27
 - example 7-15
- EconoMode A-20

ECONOMODE variable 6-12
 ENTER command 2-2, 4-4, 6-7
 example 4-5
 ENTER LANGUAGE command A-14
 environment G-3
 commands 6-1
 variable support A-4
 variables 6-10
 environments 6-2
 changing settings 6-5
 defaulting 6-2
 example (changing settings) 6-6
 Factory Default 6-2 - 6-3, 6-7
 Modified Print 6-2 - 6-3, 6-7
 PjL Current 6-2 - 6-3, 6-7
 printer language-specific 6-7
 summary 6-6
 User Default 6-2 - 6-3, 6-7
 EOJ command 5-7, 6-8
 errors, processing 2-8
 ESC/P printer language 4-4, 6-16, 6-18
 ESC/P-specific variables 6-23
 escape character (ASCII 27) 2-2
 example printing system 9-18
 examples, programming C-1
 explicit switching 4-8, G-3

F

Factory Default Environment 6-2, 6-7, G-3
 See also environments
 feature comparison A-1
 feature lock-out 6-24
 feature settings 6-1
 font sources 7-24
 FONT variable 6-23
 FONTNUMBER variable 6-19 - 6-20, 7-24
 FONTSOURCE variable 6-21
 foreground paper loading D-12
 form feed character (FF) 2-2
 format of PjL commands 2-3
 FORMLINES variable 6-12
 front panel control 1-2

H

hardware errors D-13
 HP Explorer Software iii
 HT (horizontal tab) 2-2

I

I/O Buffering 6-13
 I/O switching 9-23
 I/O timeouts 6-17
 identifiers 2-2
 IMAGEADAPT variable 6-12
 implicit switching 4-8, 6-16, 6-18, G-4
 INFO command 7-16
 INFO CONFIG command 7-18
 example 7-19
 INFO ID command 7-17
 INFO MEMORY command 7-21
 INFO PAGECOUNT command 7-22
 INFO STATUS command 7-23
 INFO USTATUS command 7-28
 INFO VARIABLES command 7-24
 informational messages D-2
 INITIALIZE command 6-3, 6-5, 6-7 - 6-8, 6-30
 example 6-32
 initializing printer 6-9, 6-24
 INQUIRE command 6-7, 7-4
 example (request feature settings) 7-6
 example, language-specific 7-8
 INTRAY1 variable 6-12
 INTRAY1SIZE variable 6-13
 INTRAY2 variable 6-12
 INTRAY2SIZE variable 6-13
 INTRAY3 variable 6-13
 INTRAY3SIZE variable 6-13
 INTRAY4SIZE variable 6-13
 introduction to PjL 1-1
 invalid commands 2-8
 IOBUFFER variable 6-13
 IOSIZE variable 6-13
 IPARM parameter (port-specific) 6-26 - 6-27, 6-36, 7-4, 7-9

J

JAMRECOVERY variable 6-22
 Japanese character set 2-7
 JIS X0201-76 character set 2-7, 8-2, 8-4, 8-6
 job boundaries 5-3
 job boundaries, printer-specific A-17
 job boundary G-4
 JOB command 5-2, 6-8
 example 5-4 - 5-5
 job recovery 7-40
 job requirements 4-2
 job security 5-9, A-19

job separation commands	5-1	MPTRAY variable	6-14
JOB variable	7-33	multi-user environment	7-14, 9-17
JOB/EOJ pairs	5-2, 5-7		
JOBOFFSET variable	6-14		
K			
kernel commands	4-1		
known state	6-24		
L			
LANG variable	6-14		
language switching	1-1 - 1-2, A-14		
example	C-2		
See also printer language switching			
languages, switching	3-3		
LaserJet 4 family comments	A-14		
LaserJet 4 Plus/4M Plus printers	5-9, A-14		
LaserJet 4 printer	1-3		
LaserJet 4L printer	A-1, A-20		
LaserJet 4ML printer	A-1, A-20		
LaserJet 4MP printer	A-1		
LaserJet 4P printer	6-18, 6-27, A-1		
LaserJet 4PJ printer	2-7, 6-16, 6-22, 6-23, 8-2, 8-4, 8-6, A-1 - A-2, A-4, A-14		
LaserJet 4Si/4SiMx printers	A-1, A-14		
LaserJet IIISi printer	1-3, A-13		
line feed character (LF)	2-2		
line spacing (FORMLINES)	6-12		
line termination	3-2		
LOWTONER variable	6-14		
LPARM	2-3		
LPARM : PCL	6-19		
LPARM : personality	6-11		
LPARM : POSTSCRIPT	6-22		
M			
macro	G-4		
manual organization	iv		
MANUALFEED variable	6-14		
memory available	7-21		
memory, commands that affect	A-15		
minimum set of PJJ commands	4-1		
MIO card	9-27		
Modified Print Environment	6-2, 6-7, G-4		
See also environments			
monitor printer status	9-5		
N			
naming jobs	5-2		
nested jobs	5-6		
networks	9-17		
non-printing mode	5-3, 5-8, 7-40, G-4		
non-volatile memory	G-5		
non-volatile RAM	6-7		
numeric variables	2-6		
O			
offline	G-5		
online	G-5		
operator intervention	D-9 - D-10		
operator message, changing	8-4		
OPMSG command	8-4		
example	8-5		
option name	2-4		
ORIENTATION variable	6-14		
OUTBIN variable	6-14		
overflow, data buffer	9-25		
overview	3-1		
P			
page count	5-4, 7-22		
PAGE variable	7-36		
PAGEPROTECT variable	6-15		
PaintJet XL300 printer	1-3, A-3		
PAPER variable	6-15		
parser errors	D-4		
parser warnings	D-6		
parsing errors	2-9		
password	5-3		
password protection	5-9		
PASSWORD variable	5-9, 6-15		
PCL 5 Comparison Guide	vii		
PCL-specific variables	6-18 - 6-19		
PCL/PJJ Technical Quick Reference Guide	vii		
PCL/PostScript switching	C-2		
personalities			
adding dynamically	6-33		
personality	6-3, G-5		
personality switching	1-1, G-5		
LaserJet IIISi	A-13		
PERSONALITY variable	6-16, 6-18		

PERSONALITY variable (port-specific)	6-18	PostScript	
PITCH variable	6-21	end-of-file (^D)	2-2
PJL		compatibility	1-4
adding comments	4-6	switching to	4-4
and I/O switching	9-23	specific variables	6-22
application types	9-2	PostScript/PCL switching	C-2
benefits	1-2	powersave mode	6-16
capabilities	1-1	POWERSAVE variable	6-16
command formats	2-3	POWERSAVETIME variable	6-16
command syntax and format	2-1	prefix (@PJL)	2-4, 3-2
command usage	3-1	print data generators	9-3
commands grouped by function	3-5	print environment	6-2, G-7
compatibility	1-3	print job initialization	6-9
environment variable support	A-4	printer feature comparison	A-1
feature support	A-2	printer I/O switching	9-23
getting to desired state	6-24	Printer Job Language (PJL)	1-1
handling unexpected responses	9-27	printer language	G-7
in multi-user systems	9-17	commands	6-3
introduction	1-1	printer language switching	1-1 - 1-2, 4-4, 4-8,
job requirements	3-2	and performance	A-14, C-2
job security	5-9	LaserJet IIISi	4-8
job separation commands	5-1	printer languages	A-13
minimum command set	4-1	other	1-4
prefix	2-4	PostScript	1-4
processing invalid commands	2-8	switching	3-3
programming tips	9-1	printer model	7-17
requesting printer status	9-17	printer resources	9-5
sample jobs	3-3	printer setup	6-24
status codes	D-1	printer sharing	9-17
syntax rules	2-4	devices	9-20, 9-27
using	3-1	printer status readback	1-2
well-formed jobs	3-2	usage	9-21
white space in commands	2-5	requirements	7-2
PJL		requesting	9-17
command formats	2-3	printer utilities	9-5
feature comparison	A-1	printing pre-existing jobs	9-10
job security	A-19	product-specific feature support	A-1
status requirements	7-2	programming examples	C-1
PJL (Printer Job Language)	1-1	programming tips	9-1
PJL command summary	B-1	PRTPSERRS variable	6-22
PJL Current Environment	6-2, 6-7, G-5	PTSIZE variable	6-22
See also environments			
PJL environment variables	6-10		
PJL job	G-6		
PJL reset conditions	6-8, G-6	R	
PJL security	5-1	RDYMSG command	8-2
PJL services	9-2	example	8-3
poorly formed print job	G-6	example (batch file)	C-4
port-specific variables	6-18, 6-37, 7-4, 7-9, 7-24	readback, printer status	1-2, 7-1
		ready message	G-7

ready message, changing 8-2
 related documentation vii
 RESET command 6-8 - 6-9, 6-24, 6-33
 example 6-35
 reset conditions, PJJ 6-8
 resetting printer 6-24
 Resolution Enhancement 6-17
 RESOLUTION variable 6-16
 resource saving A-16
 RESOURCESAVE variable 6-17
 RESOURCESAVESIZE variable 6-17
 response data buffer overflow 9-25
 RET variable 6-17

S

sample printing system 9-19
 security, PJJ 5-1
 semantic errors D-7
 semantic warnings 2-8
 SET command 6-3, 6-7, 6-9, 6-24, 6-33, 6-36
 example 6-38
 Shift-JIS parsing 6-22
 solicited status G-7
 space (SP) character 2-2
 space between characters 2-4
 spoolers 1-2, 4-5, 5-5, 9-10
 stale status responses 9-25
 status codes D-1
 status messages 7-32
 status readback 1-2, G-8
 determining if available 9-22
 LaserJet 4 A-15
 old responses 9-25
 unexpected responses 9-27
 and printer sharing 9-18
 commands 7-1
 format 7-3
 usage 9-21
 STMSG command 8-6
 example 8-7
 string variables 2-7
 switching languages 1-2, 3-3, A-14
 See also printer language switching
 symbol set 6-22
 SYMSET variable 6-20, 6-22
 synchronizing job and page status 5-2
 synchronizing status information 7-2, 7-14
 syntax errors 2-8
 syntax of PJJ commands 2-1

syntax rules 2-4
 syntax warnings 2-8
 SYS SWITCH A-13

T

tab character (HT) 2-2
 technical support personnel iii
 termination, line 3-2
 TIMED variable 7-37
 timeout A-18
 TIMEOUT variable 6-17
 TOPMARGIN variable 6-23

U

UEL (Universal Exit Language) command 2-3
 UEL command 1-2, 3-1, 4-2, 6-8, 6-24, G-8
 example 4-3
 Universal Exit Language (UEL) 2-3, 3-2, 4-2, G-8
 See UEL command
 unsolicited device status 7-33
 unsolicited job status 5-8, 7-33
 unsolicited page status 5-4, 7-36
 unsolicited status G-8
 determining choices 7-28
 turning off 7-39
 User Default Environment 6-2, 6-7, G-8
 See also environments
 using PJJ 3-1
 USTATUS command 2-9, 5-4, 7-29
 USTATUS DEVICE command 7-31
 USTATUS JOB command 7-33
 USTATUS PAGE command 7-36
 USTATUS TIMED command 7-37
 USTATUSOFF command 7-39
 utilities 9-5

V

value 2-3
 variable support A-4
 variable types 2-6
 variables 2-1
 environment 6-10
 INFO VARIABLES command 7-24
 PCL-specific 6-18 - 6-19
 PJJ environment 6-11
 PostScript-specific 6-22
 vertical bar (|) 2-1, G-1

W

well-formed jobs	3-2
white space (WS)	2-2, 2-4
white space, placement	2-5
WIN31J symbol set	6-22

Quick Index

Command	Page No.	Command Description
COMMENT	4-6	Causes PJJ to accept the command line as a comment.
DEFAULT	6-26	Sets default value for environment variables.
DINQUIRE	7-9	Requests the default value for a specified environment variable.
ECHO	7-14	Returns the comment portion of the command to the host computer.
ENTER	4-4	Selects a printer language for processing the current job.
EOJ	5-7	Tells printer the job has completed, resets the page count.
INFO	7-16	Requests a specified category of printer information.
INITIALIZE	6-30	Resets current and default PJJ variables to factory default values.
INQUIRE	7-4	Requests the current value for an environment variable.
JOB	5-2	Informs printer of the start of a print job, resets the page count, allows naming of the job, supports non-printing mode.
OPMSG	8-4	Displays specified message on control panel and takes printer offline.
RDYMSG	8-2	Specifies a message that replaces the READY message on the printer control panel. Does not affect on-line state.
RESET	6-33	Resets current PJJ variables to default values.
SET	6-36	Sets environment variable for the duration of a PJJ job.
STMSG	8-6	Displays specified message on printer control panel and takes printer offline. Returns name of the key pressed by operator to put the printer back online.
Universal Exit Language (UEL) <ESC>%-12345X	4-2	Exits current printer language and returns control to PJJ.
USTATUS	7-29	Enables printer to send unsolicited status messages.
USTATUSOFF	7-39	Turns off all unsolicited status.